

Moen 84025

Moen Ronan Chrome Two-Handle 4-inch Centerset Bathroom Faucet

MODEL: 84025

Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your Moen Ronan Chrome Two-Handle 4-inch Centerset Bathroom Faucet, Model 84025. Please read all instructions carefully before beginning installation and retain this manual for future reference.

Safety Information

- Always turn off the water supply to the faucet before beginning any work.
- Wear safety glasses and gloves during installation.
- If you are unsure about any part of the installation, consult a qualified plumber.
- Ensure all connections are secure to prevent leaks.

Included Components

Verify that all parts are present before beginning installation:

- Faucet Assembly
- Mounting Hardware
- Non-Metallic Spring-Loaded Pop-Up Drain Assembly
- Instruction Manual (this document)



Image 1: Moen Ronan Chrome Two-Handle Centerset Bathroom Faucet with its components.

Setup and Installation

The Moen Ronan faucet is designed for a three-hole, 4-inch centerset installation. It requires 1/2-inch IPS connections for flexible hoses. Do not use rigid or semi-rigid supply risers (3/8-inch Copper or Pex) with coupling nuts.

1. **Prepare the Sink:** Ensure the sink deck has three holes, each with a minimum diameter of 1 inch, spaced 4 inches on center. Clean the area around the faucet holes.
2. **Install the Faucet:** Place the faucet assembly onto the sink deck, aligning the hot and cold water inlets with the outer holes and the spout with the center hole.
3. **Secure the Faucet:** From underneath the sink, secure the faucet using the provided mounting hardware. Tighten nuts evenly to ensure a stable installation.
4. **Connect Water Supply Lines:** Connect the 1/2-inch IPS flexible supply lines (not included) to the hot and cold water inlets on the faucet and to your home's water supply valves. Ensure connections are hand-tightened, then use a wrench for a quarter turn. Do not overtighten.
5. **Install the Drain Assembly:** Follow the instructions provided with the non-metallic spring-loaded pop-up drain assembly for proper installation into the sink drain hole. Ensure a watertight seal.
6. **Test for Leaks:** Once all connections are made, slowly turn on the main water supply. Check all connections for leaks. If leaks occur, tighten the connections slightly until they stop.

Connection Size - **3/8"**Maximum Deck Thickness - **1.19"**

3 Hole Installation

Image 2: Faucet dimensions and installation requirements for a 3-hole setup.

Operating Instructions

The Moen Ronan faucet features two handles for precise control over water temperature and flow.

- **Cold Water:** Turn the right handle counter-clockwise to activate cold water flow.
- **Hot Water:** Turn the left handle counter-clockwise to activate hot water flow.
- **Temperature Adjustment:** Mix hot and cold water by adjusting both handles until the desired temperature is achieved.
- **Flow Control:** The further the handles are turned, the greater the water flow.
- **Drain Operation:** The included spring-loaded pop-up drain is operated by pushing down on the drain stopper to close it, and pushing again to open it.

Your browser does not support the video tag.

Video 1: Overview of the Moen Ronan Bath Collection, demonstrating various faucet styles and features.

Maintenance

To maintain the finish and performance of your Moen Ronan faucet, follow these guidelines:

- **Cleaning:** Clean the faucet regularly with a soft cloth and mild soap. Avoid abrasive cleaners, harsh chemicals, or polishes, as these can damage the chrome finish.
- **Aerator Maintenance:** If water flow decreases, the aerator may be clogged. Unscrew the aerator from the spout, clean any debris, and rinse thoroughly before reattaching.
- **Drain Cleaning:** Periodically clean the pop-up drain assembly to prevent buildup and ensure proper drainage.




Image 3: The high-gloss, reflective chrome finish of the Moen Ronan faucet.

Troubleshooting

If you encounter issues with your faucet, refer to the common problems and solutions below:

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator; partially closed supply valves.	Clean the aerator. Ensure supply valves are fully open.
Leaking from Spout	Worn cartridge.	Contact Moen customer support for a replacement cartridge.

Problem	Possible Cause	Solution
Leaking at Base	Loose mounting nuts; improper sealant.	Tighten mounting nuts. Reapply plumber's putty or silicone sealant if necessary.
Difficulty Operating Handles	Mineral buildup; worn cartridge.	Clean around handles. Contact Moen for cartridge replacement.

Specifications

Feature	Detail
Brand	Moen
Model Name	Ronan
Model Number	84025
Color	Chrome
Finish Type	Polished
Material	Zinc
Number of Handles	2
Mounting Type	Deck Mount
Installation Type	Centerset
Hole Count	3 (for 4-inch centerset)
Spout Height	7.1 Inches
Maximum Flow Rate	1.2 Gallons Per Minute (GPM)
Special Features	Easy Installation, Pop Up Drain, Valve Included
UPC	026508403051

Warranty

Moen faucets are backed by a limited lifetime warranty against leaks, drips, and finish defects to the original homeowner. For full warranty details and terms, please refer to the official Moen website or contact customer support.


Support

For further assistance, replacement parts, or warranty claims, please contact Moen customer support:

- **Website:** Visit the official [Moen website](#) for product information and support resources.

- **Phone:** Refer to the contact information provided on the Moen website or product packaging for customer service phone numbers.

Related Documents - 84025

 <p>MOEN Illustrated Parts Adler™ Two-Handle Lavatory Faucet</p>	<p>Moen Adler Two Handle Lavatory Faucet Illustrated Parts List</p> <p>Detailed illustrated parts list for the Moen Adler Two Handle Lavatory Faucet, providing part numbers, descriptions, and finish options for components like handles, cartridges, and mounting hardware. Includes model numbers 84603 and 84603SRN.</p>
 <p>MOEN Illustrated Parts Ronan™ One-Handle Lavatory Faucet</p>	<p>Moen Ronan One-Handle Lavatory Faucet Illustrated Parts List & Specifications</p> <p>Detailed illustrated parts list for the Moen Ronan One-Handle Lavatory Faucet (Models 84021BL, 84021SRN). Find part numbers, descriptions, and finishes for your Moen faucet.</p>
 <p>MOEN Specifications Traditional™ Two-Handle 4-Inch Centerset Lavatory Faucet</p>	<p>Moen Traditional Two-Handle 4-Inch Centerset Lavatory Faucet WS84003 Specifications</p> <p>Detailed specifications for the Moen Traditional Two-Handle 4-Inch Centerset Lavatory Faucet (WS84003 series), including features, operation, flow rate, cartridge type, standards, warranty information, and critical installation dimensions.</p>
 <p>MOEN ILLUSTRATED PARTS IVER™ Two-Handle 4" Centerset Lavatory Faucet</p>	<p>Moen IVER™ Two-Handle 4" Centerset Lavatory Faucet 6815 Series Illustrated Parts</p> <p>Illustrated parts list for the Moen IVER™ Two-Handle 4" Centerset Lavatory Faucet, 6815 Series. Find part numbers and finishes for your Moen faucet.</p>
 <p>MOEN Illustrated Parts Traditional™ Centerset Lavatory Faucet</p>	<p>Moen Traditional Centerset Lavatory Faucet Illustrated Parts List</p> <p>Comprehensive illustrated parts list for the Moen Traditional Centerset Lavatory Faucet, detailing models WS84003, WS84003BRB, and WS84003SRN with part numbers for handles, spout, waste assemblies, and mounting kits.</p>

