

[manuals.plus](#) /

› [ANSTEN](#) /

› [ANSTEN Wireless Speakers for TV Instruction Manual](#)

ANSTEN B007

ANSTEN B007 Wireless TV Speaker Instruction Manual

Model: B007

1. INTRODUCTION

The ANSTEN B007 Wireless TV Speaker is designed to enhance your television audio experience, especially for individuals with hearing difficulties. It features advanced voice highlighting technology, automatic gain control, and treble adjustment to ensure clear and loud dialogue. With its portable design and long wireless range, you can enjoy crystal-clear sound anywhere in your home.

This manual provides detailed instructions for setting up, operating, and maintaining your ANSTEN B007 Wireless TV Speaker.



Figure 1: ANSTEN B007 Wireless TV Speaker with its charging base and included cables.

2. WHAT'S IN THE Box

Please check the package contents to ensure all items are present:

- Wireless TV Speaker (x1)
- Wireless Transmitter & Charging Base (x1)
- Type-C USB Charging Cable (x1)
- USB Adapter (x1)
- RCA Cable (x1)
- AUX 3.5mm Cable (x1)
- Optical Cable (x1)



Figure 2: All components included in the ANSTEN B007 package.

3. SETUP

The ANSTEN B007 offers multiple connection options to suit various TV setups. Choose the option that best fits your television's audio output ports.

3.1. Connecting to Your TV

The transmitter connects to your TV's audio output. Ensure your TV has one of the following audio output interfaces: Optical, RCA, or AUX 3.5mm.

COMPATIBLE WITH ALMOST ALL TVs

3 ways to connect to TV to choose from, compatible with most TVs on the market.



NOTE: Please confirm whether your TV has the above **OUTPUT** interfaces before purchasing.

Figure 3: Overview of compatible TV audio output ports and transmitter connections.

3.1.1. Option 1: TV with Optical Audio Output

1. Connect the Optical cable from your TV's Optical Digital Audio Out port to the OPT IN port on the wireless transmitter.
2. On your TV's sound settings, set the audio output to PCM. (Refer to your TV's manual for specific steps).

Your browser does not support the video tag.

Video 1: Detailed instructions for connecting the ANSTEN B007 via Optical cable and setting TV audio to PCM.

3.1.2. Option 2: TV with RCA Audio Output

1. Connect the RCA cable (red and white plugs) from your TV's Audio Out ports to the corresponding RCA IN ports on the wireless transmitter.
2. On your TV's sound settings, set the audio output to External Speaker.

Your browser does not support the video tag.

Video 2: Step-by-step guide for connecting the ANSTEN B007 using RCA cables and configuring TV audio output.

3.1.3. Option 3: TV with AUX/3.5mm Audio Output

1. Connect the 3.5mm AUX cable from your TV's 3.5mm Audio Out port to the AUX IN port on the wireless transmitter.
2. On your TV's sound settings, set the audio output to External Speaker.



Figure 4: The control panel of the ANSTEN B007 speaker.

4. OPERATING INSTRUCTIONS

4.1. Power ON/OFF

- **Power ON:** To turn the speaker on, simply turn the volume knob clockwise. The LED indicator will turn Blue.
- **Power OFF:** To turn the speaker off, simply turn the volume knob counter-clockwise to the far left. The LED indicator will turn off.

Your browser does not support the video tag.

Video 3: Demonstrating the power ON/OFF function of the ANSTEN B007 speaker.

4.2. Volume Control

Adjust the volume by rotating the large knob on the top of the speaker. Turn clockwise to increase volume and counter-clockwise to decrease volume.



Figure 5: Adjusting the volume on the ANSTEN B007 speaker.

4.3. Special Features

- **Clear Voice:** Toggle the "Clear Voice" switch to enhance dialogue clarity, making conversations easier to understand by reducing background noise.
- **Treble Adjustment:** Use the "Treble" switch to adjust the high-frequency sounds for a personalized listening experience.
- **SOS Switch:** In case of an emergency, press the "SOS" button to activate an alarm, alerting those nearby for quick assistance.

LONG RANGE UP TO 100FT/30M

Use the portable tv speaker anywhere in your home.



Figure 6: The Clear Voice feature enhances dialogue for an improved listening experience.

Designed for the Elderly

An alarm sounds with just one switch to tell the people around you in case of emergency.



Figure 7: The SOS button provides an emergency alert for immediate assistance.

5. CHARGING

The ANSTEN B007 speaker offers two convenient charging methods:

1. **Charging Base:** Place the speaker onto the charging base. Ensure the charging pins align correctly. The LED indicator on the base will show charging status.
2. **Direct Charging:** Connect the Type-C USB charging cable directly to the speaker's charging port and plug the USB adapter into a wall outlet.

A full charge provides up to 10 hours of continuous playback.

PERSONAL WIRELESS TV SPEAKER

Enjoy the TV sound quietly by using your preferred wired headphones or earbuds.



NOTE: Headphones or earbuds not included.

Figure 8: The ANSTEN B007 can be charged via its base or directly with a USB cable.

6. MAINTENANCE

- Keep the speaker and transmitter away from water and moisture.
- Clean the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid dropping the device or subjecting it to strong impacts.
- Store in a cool, dry place when not in use for extended periods.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No Sound	Speaker not powered on. Incorrect TV audio output settings. Cables not connected properly.	Ensure speaker is turned on and LED is blue. Check TV sound settings (PCM for Optical, External Speaker for RCA/AUX). Verify all cables are securely connected.
Sound is Distorted	Volume too high. Treble/Clear Voice settings.	Lower the volume. Adjust or turn off Treble/Clear Voice features.
Short Wireless Range	Obstructions between speaker and transmitter. Interference from other 2.4GHz devices.	Ensure clear line of sight. Move speaker/transmitter away from other wireless devices.
Speaker Not Charging	Improper connection to charging base/cable. Faulty adapter/cable.	Ensure proper alignment on base or secure cable connection. Try a different USB adapter or cable.

8. SPECIFICATIONS

Feature	Detail
Model Name	B007
Brand	ANSTEN
Speaker Type	Soundbar
Connectivity Technology	Wireless (2.4G), RCA, AUX, Optical
Wireless Communication Technology	2.4G
Speaker Maximum Output Power	10 Watts
Battery Life	Up to 10 hours
Product Dimensions	7.87"D x 3.66"W x 4.33"H
Item Weight	1.86 pounds
Material	Acrylonitrile Butadiene Styrene (ABS)
Control Method	Button, Touch
Special Feature	Crystal sound, SOS Elderly friendly

9. WARRANTY & SUPPORT

ANSTEN provides comprehensive support for its products:

- **Warranty Type:** Limited Warranty
- **Replacement:** 12-month replacement policy.
- **Customer Service:** Replies within 24 hours.
- **Support:** Lifetime support.

For any questions or assistance, please contact ANSTEN customer support through the official channels provided at the time of purchase or on the product packaging.

Any Questions?

We are always here to support:


- 12-month replacement
- Reply within 24 hours
- Lifetime Support



Figure 9: ANSTEN is committed to providing excellent customer support.


© 2024 ANSTEN. All rights reserved.

Related Documents - B007



[Ansten Wireless Headphones for Smart TV Watching User Manual](#)

User manual for Ansten wireless headphones, providing setup guides, features, and troubleshooting for smart TV audio, with support for optical, AUX, and RCA inputs.



[AS30 Wireless Gaming Headset User Manual](#)

User guide for the AS30 Wireless Gaming Headset, covering product overview, power on/off, pairing, connections, microphone usage, charging, and system settings for Windows.



[HSV379HDMI Coaxial Extender: Instructions and Troubleshooting](#)

Comprehensive guide for the HSV379HDMI coaxial extender, covering setup, matters needing attention, and simple troubleshooting steps for optimal performance.

	<p><u>Shantou Hong XUN Jie Electronic Technology Co., Ltd. HJ819 Remote Control Racing Yacht User Manual</u></p> <p>Comprehensive user manual for the Shantou Hong XUN Jie Electronic Technology Co., Ltd. HJ819 Remote Control Racing Yacht, covering features, specifications, operation, setup, maintenance, and regulatory information.</p>
	<p><u>Hiseeu 10 -POE-1 B007-V2.0 5MP PoE PTZ Security Camera System User Manual</u></p> <p>Comprehensive user manual for the Hiseeu 10 -POE-1 B007-V2.0 outdoor video surveillance kit. Features 5MP PoE PTZ cameras with auto-tracking, human detection, 8CH NVR, 3TB HDD, 10-inch monitor, and 30m color night vision. Includes safety certifications.</p>
	<p><u>Beckhoff Automation Accessories: Cables, Connectors, and More</u></p> <p>Explore the comprehensive range of Beckhoff automation accessories, including I/O accessories, pre-assembled cables, connectors, and specialized components for seamless integration with Beckhoff products.</p>