

[Manuals.plus](#) /

› [WEQOEE](#) /

› WEQOEE 5-in-1 Electric Head Shaver User Manual

WEQOEE FK-8606

WEQOEE 5-in-1 Electric Head Shaver User Manual

Model: FK-8606 | Brand: WEQOEE

INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your WEQOEE 5-in-1 Electric Head Shaver. Please read all instructions carefully before first use and retain this manual for future reference.



Image: The WEQOEE 5-in-1 Electric Head Shaver, showcasing its main rotary shaving head and various included attachments like clipper guards, nose hair trimmer, and cleaning brush.

Key Features:

- **5D Floating Head Shaver Design:** Ultra-flexible heads adapt to contours for a smooth, close shave.
- **5-in-1 Grooming Kit:** Includes a 5-blade head shaver, hair trimmer with clipper guards, nose hair trimmer, facial cleansing brush, and beard sweep brush.
- **IPX7 Waterproof:** Suitable for both wet and dry shaving, and easy cleaning under running water.
- **Type-C Fast Charging:** Provides 90 minutes of working time after a 1.5-hour charge.
- **LED Display:** Indicates battery level for convenient monitoring.

IMPORTANT SAFETY INFORMATION

- Keep the appliance dry when charging.
- Do not disassemble the product yourself. Contact customer support for repairs.
- Keep out of reach of children.

- Ensure the charging port is dry before connecting the Type-C cable.
- This appliance is intended for personal use only.

SETUP AND FIRST USE

1. Charging the Shaver

Before first use, fully charge the shaver. Connect the provided Type-C charging cable to the shaver's charging port and plug the other end into a compatible USB power source (e.g., laptop, power bank, wall adapter). The LED display will show the charging progress. A full charge takes approximately 1.5 hours and provides up to 90 minutes of cordless operation.



Image: The shaver being charged via its Type-C port, illustrating its compatibility with various USB charging methods including USB chargers, car chargers, power banks, and laptops.

2. Attaching/Detaching Shaver Heads

The shaver comes with multiple interchangeable heads. To attach a head, align it with the main body and gently push until it clicks into place. To detach, pull the head away from the body. For the main 5-blade rotary head, it can be locked by turning it to the left.

**The head turns to the left to lock it
lefty tighty, righty loosey**



Image: A close-up of hands demonstrating the locking mechanism of the 5-blade rotary shaver head. The head is turned to the left to secure it, following the "lefty tighty, righty loosey" principle.

OPERATING INSTRUCTIONS

1. General Shaving (Head & Face)

Attach the 5-blade rotary shaver head. Press the power button to turn on the shaver. Gently move the shaver in circular motions over the desired area. The 5D floating heads will adapt to the contours of your head and face for an efficient

shave. You can use it for dry shaving or with shaving gel/foam for a wet shave.



Image: A man demonstrating the use of the 5D floating head shaver on his bald head, highlighting the smooth and close shaving experience provided by the double ring blades and 360-degree floating action.

2. Using the 5-in-1 Grooming Attachments

Your shaver includes several attachments for various grooming needs:

- **Hair Trimmer with Clipper Guards:** Use for precise trimming of hair or beard. Select the appropriate clipper guard for your desired length.
- **Nose Hair Trimmer:** Gently insert the trimmer into your nostril or ear canal to remove unwanted hair.
- **Facial Cleansing Brush:** Attach the brush head and use with your preferred facial cleanser for deep cleaning and exfoliation.
- **Beard Sweep Brush:** Use to clean up trimmed hair from your face or neck.



Image: An illustration of the complete 5-in-1 grooming set, detailing each attachment: sideburns trimmer, nose hair trimmer, 5-blade head shaver, facial cleansing brush, and beard sweep brush, with visual examples of their application.

3. Wet and Dry Use

The shaver is IPX7 waterproof, allowing for both wet and dry shaving. For a refreshing wet shave, apply shaving cream or gel to your skin before use. For dry shaving, ensure your skin is clean and dry. The waterproof design also makes it safe to use in the shower.

IPX7 Waterproof

Wet and dry shaver

 IPX7



Image: A man using the shaver in the shower, illustrating its IPX7 waterproof feature for convenient wet shaving.

MAINTENANCE AND CLEANING

1. Cleaning the Shaver Heads

After each use, especially with shaving cream or gel, it is recommended to clean the shaver head. The detachable shaving head can be easily removed and rinsed directly under running water. Use the included cleaning brush to remove any stubborn hair particles from the blades and internal components.

Easy to Clean Shaving Head

Waterproof body resists water bubbles



Image: The shaver head being cleaned under running water, demonstrating its IPX7 waterproof design for simple and effective rinsing.

2. Replacing Shaver Heads

For optimal performance, it is recommended to replace the shaver heads every 3 to 6 months, depending on usage frequency and hair type. Replacement heads can be purchased separately from authorized retailers.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaver does not turn on.	Low battery or no charge.	Charge the shaver fully using the Type-C cable.
Poor shaving performance / pulling hair.	Blades are dull or clogged with hair.	Clean the shaver head thoroughly. Consider replacing the shaver head if performance does not improve.
Shaver gets hot during use.	Prolonged use or excessive pressure.	Reduce shaving time or pressure. Ensure blades are clean and lubricated if applicable (check product specifics).
LED display not working.	Unit malfunction.	Contact customer support.

PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	FK-8606
Brand	WEQOEE
Power Source	Battery Powered (Rechargeable)
Battery Type	1 9V battery (included)
Charging Time	Approx. 1.5 hours
Operating Time	Approx. 90 minutes
Waterproof Rating	IPX7
Included Components	Cleaning Brush, Hair Trimmer, Nose Hair Trimmer, Facial Cleansing Brush, Beard Sweep Brush, Clipper Guards
Package Dimensions	7.68 x 6.89 x 2.09 inches
Item Weight	12.7 ounces

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact the manufacturer, Wenzhou Junpai Electric Co., Ltd., or your retailer. Keep your purchase receipt as proof of purchase.

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. This product is for personal grooming and not a medical device.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question