

## Juboos B0FB3T7H18

# Juboos Kids Learning Watch Instruction Manual

Model: B0FB3T7H18

## 1. INTRODUCTION


---

Thank you for choosing the Juboos Kids Learning Watch. This manual provides essential information for the proper setup, operation, and maintenance of your new watch. Designed for children, this watch aims to make learning time engaging and easy, while offering durability and water resistance for daily activities.

This product may include both analog and digital watch variations, each with specific features designed to aid in time education and provide practical functions.



3. Once the time is set, push the crown back into its original position to start the watch movement.



**Image 3.1:** A detailed view of the analog watch, highlighting the crown on the side used for adjusting the time.

### 3.2. Setting the Digital Time and Date

The digital watch typically features four buttons: LIGHT, MODE, START, and RESET.



**Image 3.2:** The digital watch face, illustrating the positions of the LIGHT, MODE, START, and RESET buttons around the bezel.

1. **Enter Setting Mode:** Press the **MODE** button repeatedly until the time setting (e.g., seconds flashing) is displayed.
2. **Adjust Values:** Use the **START** button to increase the flashing value (seconds, minutes, hours, date, month, day of week).
3. **Navigate Settings:** Press the **RESET** button to move to the next setting field.
4. **Exit Setting Mode:** Once all settings are adjusted, press the **MODE** button to return to the normal time display.

## 4. OPERATING INSTRUCTIONS

### 4.1. Digital Watch Functions

- **Backlight (LIGHT button):** Press the LIGHT button to illuminate the display for a few seconds, allowing visibility in low-light conditions.



**Image 4.1:** A child using the digital watch, illustrating the location and function of the backlight button.

- **Mode Cycling (MODE button):** Press the MODE button to cycle through different functions such as Stopwatch, Alarm, and Date display.
- **Stopwatch:** In stopwatch mode, use the **START** button to begin/pause timing and the **RESET** button to clear the time.
- **Alarm:** Set the alarm time using the START and RESET buttons in alarm setting mode. The alarm will sound at the set time.
- **12/24 Hour Format:** The watch supports both 12-hour and 24-hour time formats. This can typically be toggled in the time setting mode.

## 4.2. Analog Watch Features for Learning Time

The analog watch is designed with clear, colorful numerals to assist children in learning to tell time effectively.

- **12-Hour Numerals:** Large, colorful numbers (1-12) clearly indicate the hours.
- **24-Hour Numerals:** Smaller numerals (13-24) are often present inside the main hour track to introduce the 24-hour format.
- **60-Minute Scale:** Markings around the bezel or outer dial help in reading minutes accurately.



**Image 4.2:** A close-up of the analog watch face, highlighting the distinct 12-hour and 24-hour numerals, along with the 60-minute scale for easy time learning.

### 4.3. Water Resistance (3ATM / 30M / 98FT)


Your Juboos Kids Learning Watch is rated 3ATM (30 meters / 98 feet) water resistant. This means it is suitable for:

- Hand washing
- Face washing
- Rainy days
- Sweat

#### Important Limitations:

- **DO NOT** press any buttons while the watch is submerged in water.
- **NOT** suitable for bathing, showering, swimming, or diving.
- Avoid exposure to hot water or high temperatures (e.g., saunas, hot tubs), as this can compromise the water resistance seals.

# EASY LEARNING TIME



**Image 4.3:** A visual guide to the 30M water resistance, showing appropriate activities like handwashing and exposure to rain, alongside a warning against high temperatures.

## 5. MAINTENANCE

- **Cleaning:** Wipe the watch case and strap with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water and drying thoroughly.
- **Strap Care:** The resin strap is durable but should be kept clean to prevent skin irritation. Avoid prolonged exposure to direct sunlight or harsh chemicals, which can degrade the material over time.
- **Battery:** The watch uses an imported battery designed for long life. When the battery eventually runs out, it is recommended to have it replaced by a professional watch repair service to ensure the water resistance seal is maintained.

# PRODUCT DETAILS



*Stainless steel back cover*



*Stainless steel clasp*



*Resin Strap*



**Image 5.1:** Detailed view of the watch's construction, including the stainless steel back cover, stainless steel clasp, and the flexible resin strap.

## 6. TROUBLESHOOTING

- **Watch is not working:**
  - Ensure the crown on the analog watch is fully pushed in.
  - The battery may be depleted. Refer to the "Battery" section under Maintenance.
- **Time is incorrect:**
  - Re-set the time following the instructions in Section 3.
  - For digital watches, ensure you are in the correct 12-hour or 24-hour format.
- **Water appears inside the watch:**
  - This indicates a breach of the water resistance. Immediately stop using the watch and seek professional

repair. Review the water resistance limitations in Section 4.3 to prevent future occurrences.

## 7. SPECIFICATIONS

|                     |                            |
|---------------------|----------------------------|
| Brand               | Juboos                     |
| Model Number        | B0FB3T7H18                 |
| Movement            | Imported Quartz Movement   |
| Case Material       | Resin                      |
| Strap Material      | Resin                      |
| Mirror Material     | Acrylic Glass              |
| Back Cover & Clasp  | Stainless Steel            |
| Water Resistance    | 3ATM (30 meters / 98 feet) |
| Band Width          | 0.59 in / 1.5 cm           |
| Band Length         | 8.85 in / 22.5 cm          |
| Dial Case Diameter  | 1.37 in / 3.5 cm           |
| Dial Case Thickness | 0.5 in / 1.3 cm            |
| Minimum Wrist Fit   | 5.63 in / 14.3 cm          |
| Maximum Wrist Fit   | 7.68 in / 19.5 cm          |
| Product Weight      | 26 g / 0.057 lb            |



Image 7.1: A visual representation of the watch's dimensions and wrist fit measurements.

## 8. WARRANTY AND SUPPORT

Juboos stands behind the quality of its products. For specific warranty details, please refer to the product packaging or contact your retailer. If you encounter any issues or have questions regarding your Juboos Kids Learning Watch, please contact customer support through the retailer's platform or the official Juboos website.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**