

[Manuals.plus](#) /

› [WEQOEE](#) /

› WEQOEE 5-in-1 Rechargeable Body Shaver (Model FK-8608) User Manual

WEQOEE FK-8608

WEQOEE

WEQOEE 5-in-1 Rechargeable Body Shaver

MODEL: FK-8608 USER MANUAL

1. Product Overview

The WEQOEE 5-in-1 Rechargeable Body Shaver (Model FK-8608) is a versatile grooming device designed for effective and gentle hair removal across various body areas. It features multiple interchangeable heads for different applications, a waterproof design for wet or dry use, and a rechargeable battery with an LED display for convenience.




Image 1.1: The WEQOEE 5-in-1 Rechargeable Body Shaver main unit with its five-head rotary shaver attachment.

Package Contents:

- Main Shaver Unit
- 5-Head Rotary Shaver Attachment
- Precision Trimmer Attachment
- Nose Hair Trimmer Attachment
- Facial Cleaning Brush Attachment
- Soft Massage Brush Attachment
- USB Type-C Charging Cable
- Cleaning Brush

5-IN-1

Electric Razors for Women



Skin hair trimmer



Facial cleaning brush



Hair Trimmer



Nose hair Trimmer



Beard Sweep Brush

Image 1.2: The WEQOEE 5-in-1 Shaver showcasing all its interchangeable attachments, including the main shaver, trimmer, nose trimmer, and facial brushes.

2. Setup and Charging

2.1 Initial Charge

Before first use, fully charge the device. Connect the USB Type-C charging cable to the shaver and a compatible USB power source (e.g., USB charger, power bank, laptop). The LED display will show the charging progress. A full charge typically takes approximately 2 hours and provides extended usage time.

2.2 Attaching/Detaching Heads

1. To attach a head: Align the desired attachment with the main unit and gently push it down. Rotate the head clockwise until it clicks securely into place.
2. To detach a head: Hold the main unit firmly and rotate the attached head counter-clockwise until it loosens. Gently pull the head upwards to remove it.

**The head turns to the left to lock it
lefty tighty, righty loosey**



Image 2.1: Visual guide demonstrating how to securely attach and detach the shaver heads by twisting them into place.

3. Operating Instructions

3.1 Power On/Off

Press the power button once to turn the shaver on. The LED display will illuminate, showing the current battery

percentage. Press the power button again to turn the shaver off.

3.2 Wet and Dry Use

The WEQOEE FK-8608 is IPX7 waterproof, allowing for both wet and dry shaving. For a dry shave, ensure skin is clean and dry. For a wet shave, you may use it in the shower or with shaving cream/gel for added comfort.

IPX7

WATERPROOF

Can be used **wet** or **dry**



Wet Shave

Image 3.1: The shaver being used in a wet environment, highlighting its IPX7 waterproof rating and suitability for wet shaving.

3.3 Using the Attachments

- **5-Head Rotary Shaver:** Ideal for large areas like legs, arms, underarms, and bikini line. The 5D floating heads adapt to body contours for a close and comfortable shave. Move the shaver in small, circular motions against the direction of hair growth.



Image 3.2: A woman using the 5D floating head shaver on her underarm, illustrating its ergonomic design and close shaving capability.

- **Precision Trimmer:** Use for pre-trimming longer hair before shaving, or for shaping and detailing. Move the trimmer

against the hair growth.

- **Nose Hair Trimmer:** Gently insert the trimmer tip into the nostril or ear canal. Do not insert too deeply.
- **Facial Cleaning Brush:** Attach to the main unit. Apply your preferred facial cleanser to your face or the brush head. Gently move the brush in circular motions across your face for deep cleansing.
- **Soft Massage Brush:** Attach to the main unit. Use for gentle facial massage or to assist with exfoliation.




Image 3.3: A visual comparison showing the effectiveness of the shaver for underarm hair removal.

Designed For Your Whole Body



FACE



BODY



HANDS



LEGS



BUTTOCKS



BIKINIS

Long Hair For **Special Area Shaving**

☒ Armpit

☒ Bikini Area



Armpit **Bikini Area**

☒ Legs

☒ Arm

☒ Back

☒ Face




Image 3.4: An illustration indicating the various body parts (face, body, hands, legs, buttocks, bikinis) for which the shaver and its attachments are designed.

4. Maintenance and Cleaning

4.1 Cleaning the Shaver Heads

After each use, especially for wet shaving, detach the shaver head and rinse it thoroughly under running water. Use the provided cleaning brush to remove any trapped hairs from the blades and internal components. Ensure the head is completely dry before reattaching or storing.

4.2 Main Unit Cleaning

The main unit can be rinsed under water due to its waterproof design. However, avoid submerging the entire unit for extended periods. Wipe the body with a soft, dry cloth. Do not use abrasive cleaners or solvents.

4.3 Storage

Store the shaver and its attachments in a clean, dry place, away from direct sunlight and extreme temperatures. Keep out of reach of children.

5. Troubleshooting

- **Shaver not turning on:** Ensure the device is fully charged. If the battery is low, connect it to the charger.
- **Reduced shaving performance:** Clean the shaver head thoroughly to remove any hair or debris. Ensure the attachment is correctly secured. For longer hair, pre-trimming with the precision trimmer attachment may improve results.
- **Attachment feels loose or falls off:** Ensure the attachment is correctly aligned and rotated clockwise until it clicks firmly into place. A loose attachment may indicate improper installation.
- **Skin irritation:** Ensure your skin is clean before shaving. For sensitive skin, consider using the shaver wet with shaving cream or gel. Shave in the direction of hair growth for less irritation, or against for a closer shave, depending on skin sensitivity.

6. Specifications

Feature	Detail
Model Number	FK-8608
Power Source	Rechargeable (USB Type-C)
Waterproof Rating	IPX7 (Wet & Dry Use)
Attachments	5-Head Rotary Shaver, Precision Trimmer, Nose Hair Trimmer, Facial Cleaning Brush, Soft Massage Brush
Display	LED Battery Percentage
Dimensions (Package)	7.6 x 6.97 x 2.05 inches
Item Weight	0.36 Kilograms (12.63 ounces)
Manufacturer	Wenzhou Junpai Electric Co., Ltd.
UPC	684646262666

Easy to carry anywhere

Small and fast charging with Type-C



Image 6.1: The shaver demonstrating its portability and compatibility with various Type-C charging methods, including USB chargers, car chargers, power banks, and laptops.

7. Warranty and Support

For warranty information, please refer to the documentation provided with your purchase or contact the seller directly. If you encounter any issues or require technical assistance, please reach out to the manufacturer or the point of purchase.

for support.

Note: No specific video content with creator type 'Seller' was available in the provided data to embed in this manual.

© 2025 WEQOEE. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question