

[Manuals.plus](#) /

› [HOMCOM](#) /

› HOMCOM B31-561V00WT LED Ceiling Lamp Instruction Manual

HOMCOM B31-561V00WT

HOMCOM B31-561V00WT LED Ceiling Lamp Instruction Manual

Model: B31-561V00WT

INTRODUCTION

Thank you for purchasing the HOMCOM B31-561V00WT LED Ceiling Lamp. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions thoroughly before installation and retain them for future reference.

SAFETY INSTRUCTIONS

- Always disconnect power at the main circuit breaker before installation, maintenance, or cleaning.
- Installation must be performed by a qualified electrician or a person with sufficient knowledge of electrical wiring.
- Ensure the mounting surface can support the weight of the fixture.
- Do not modify the fixture or use it for purposes other than its intended use.
- Keep packaging materials out of reach of children.
- This product is designed for indoor use only.

PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with installation.

Produktdatenblatt			
DELEGIERTE VERORDNUNG (EU) 2019/2015 DER KOMMISSION zur Energieverbrauchskennzeichnung von Lichtquellen			
Name oder Handelsmarke des Lieferanten: HOMCOM			
Anschrift des Lieferanten: Product Development, Wendenstraße 309, 20537 Hamburg, DE			
Modellkennung: B31-561V00WT			
Art der Lichtquelle:			
Verwendete Beleuchtungstechnologie:	LED	Ungebündelt oder gebündelt:	NDLS
Art des Sockels der Lichtquelle (oder andere elektrische Schnittstelle)	Connec-tion by wire		
Netzspannung/Nicht direkt an die Netzspannung angeschlossen:	MLS	Vernetzte Lichtquelle (CLS):	Nein
Farblich abstimmbare Lichtquelle:	Nein	Hülle:	-
Lichtquelle mit hoher Leuchtdichte:	Nein		
Blendschutzschild:	Nein	Dimmbar:	Nein
Produktparameter			
Parameter	Wert	Parameter	Wert
Allgemeine Produktparameter:			
Energieverbrauch im Ein-Zustand (kWh/1000 h), auf die nächstliegende ganze Zahl gerundet	30	Energieeffizienzklasse	F
Nutzlichtstrom (φuse) mit Angabe, ob sich der Wert auf den Lichtstrom in einer Kugel (360° °), in einem breiten Kegel (120° °) oder in einem schmalen Kegel (90° °) bezieht	3 200 in Kugel (360° °)	ähnliche Farbtemperatur, gerundet auf die nächstliegenden 100 K, oder Spanne der einstellbaren ähnlichen Farbtemperaturen, gerundet auf die nächstliegenden 100 K	6 500
Leistungsaufnahme im Ein-Zustand (P _{in} in W)	30,0	Leistungsaufnahme im Bereitschaftszustand (P _{by} in W)	0,00

Image: The product packaging, indicating that one package is included.

- 1x HOMCOM B31-561V00WT LED Ceiling Lamp
- Mounting hardware (screws, wall anchors)
- Instruction Manual

SPECIFICATIONS

Feature	Specification
Brand	HOMCOM
Model Number	B31-561V00WT
Material	Acrylic, Plastic, Aluminum

Feature	Specification
Light Source	Integrated LED
Power	30 Watts
Voltage	240 Volts
Light Colors	3000K (Warm White), 4000K (Natural White), 6500K (Cool White)
Luminous Flux	3200 Lumens
Dimensions (L x W x H)	50 cm x 40 cm x 7.4 cm
Weight	1.3 kg
Mounting Type	Ceiling Mount
Control Type	Button (Wall Switch)
Assembly Required	Yes
Energy Efficiency Class	F




Image: Technical drawing showing the dimensions of the ceiling lamp: 50 cm length, 40 cm width, and 7.4 cm height.

SETUP AND INSTALLATION

Important: Ensure power is OFF at the circuit breaker before beginning installation.

1. **Prepare the Installation Area:** Choose a suitable location on the ceiling. Ensure the ceiling material can support the fixture's weight and that there are no hidden electrical wires or pipes.
2. **Mark Drilling Points:** Hold the mounting bracket against the ceiling at the desired location and mark the drilling points with a pencil.
3. **Drill Holes:** Drill holes at the marked points. Insert appropriate wall anchors if necessary.
4. **Attach Mounting Bracket:** Secure the mounting bracket to the ceiling using the provided screws.
5. **Electrical Connection:** Connect the household electrical wires to the fixture's wires according to local electrical codes. Typically, connect live (L) to live, neutral (N) to neutral, and ground (E) to ground. Ensure all connections are secure.
6. **Mount the Fixture:** Carefully align the lamp body with the mounting bracket and secure it in place using the provided screws or locking mechanism.

7. **Restore Power:** Once the fixture is securely installed and all connections are checked, restore power at the circuit breaker.



Image: The HOMCOM two-ring LED ceiling lamp beautifully installed in a modern living space, illuminating the room.

OPERATING INSTRUCTIONS

The HOMCOM B31-561V00WT ceiling lamp is operated via a standard wall switch.

- **Turning On/Off:** Flip the wall switch to turn the lamp on or off.
- **Changing Light Color:** The lamp features three adjustable light color temperatures. To cycle through 3000K (Warm White), 4000K (Natural White), and 6500K (Cool White), quickly toggle the wall switch OFF and ON. Each quick toggle will switch to the next color temperature.

ANPASSBARES LICHT

Erfüllen Sie alle Ihre
Beleuchtungsanforderungen



Image: Visual representation of the three light color options: 3000K (Warm Light), 4000K (Natural Light), and 6500K (Cool Light).

MAINTENANCE

To ensure the longevity and optimal performance of your ceiling lamp, follow these maintenance guidelines:

- **Cleaning:** Before cleaning, ensure the power is disconnected. Wipe the fixture with a soft, dry, or slightly damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish or electrical components.
- **Inspection:** Periodically check the fixture for any signs of damage, loose connections, or wear. If any issues are found, disconnect power and consult a qualified electrician.
- **LEDs:** The integrated LED light source is designed for long-term use and is not user-replaceable.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Lamp does not light up	No power supply, loose wiring, faulty switch	Check circuit breaker. Ensure all wire connections are secure. Test the wall switch.
Light flickers	Loose wiring, unstable power supply	Check all electrical connections. Ensure stable power supply. Consult an electrician if problem persists.
Cannot change light color	Incorrect operation	Ensure you are toggling the wall switch quickly OFF and ON to cycle through colors.

ENERGY INFORMATION

This product complies with energy efficiency regulations. For detailed energy information, please refer to the energy label below or visit the EPREL database.




Image: The energy efficiency label for the HOMCOM B31-561V00WT LED ceiling lamp, indicating an energy efficiency class of F and consumption of 30 kWh/1000h.

For more details, visit the EPREL database: <https://eprel.ec.europa.eu/qr/2285894>

WARRANTY AND SUPPORT

This HOMCOM product comes with a limited warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, replacement parts, or any inquiries regarding your product, please contact HOMCOM customer service through your retailer or the official HOMCOM website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FB3YNDXB>

More documents and user manuals: <https://manuals.plus/>