

COSTWAY TK32578FR

COSTWAY Children's Pine Wood Desk and Chair Instruction Manual

Model: TK32578FR | Brand: COSTWAY

1. INTRODUCTION

This manual provides essential instructions for the assembly, safe use, and maintenance of your COSTWAY Children's Pine Wood Desk and Chair set. Please read this guide thoroughly before assembly and use to ensure proper function and safety. This desk and chair set is designed to provide a comfortable and functional space for children aged 3 years and older for various activities such as studying, drawing, reading, and playing.

2. SAFETY INFORMATION

- **Weight Limits:** Adhere strictly to the indicated weight limits. The tabletop has a maximum weight capacity of 90 kg (198 lbs), and the chair has a maximum weight capacity of 50 kg (110 lbs). Exceeding these limits may cause damage or injury.
- **Assembly:** Ensure the furniture is correctly and securely assembled according to the instructions provided. Improper assembly can lead to instability and a risk of tipping.
- **Stability Check:** Regularly check the integrity and stability of the structure, especially after moving the furniture. Tighten any loose screws as needed.
- **Design Features:** The desk and chair are designed with rounded edges and concealed screws to enhance safety and prevent injuries. However, continuous supervision of children is recommended during use.
- **Placement:** Place the furniture on a flat, stable surface to prevent wobbling or tipping.

3. COMPONENTS LIST

Please verify that all components are present before beginning assembly:

- 1 x Children's Desk
- 1 x Chair
- 1 x User Manual (this guide)
- All necessary assembly hardware (screws, dowels, etc.)

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of the COSTWAY Children's Pine Wood Desk and Chair is required. A detailed assembly guide is included with your product to facilitate this process. Please follow the step-by-step instructions carefully.

1. **Unpack:** Carefully unpack all components and hardware from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Refer to the included assembly guide to identify each part and piece of hardware.
3. **Follow Steps:** Assemble the desk and chair by following the numbered steps in the assembly guide. Ensure all connections are secure but do not overtighten screws until instructed.
4. **Final Tightening:** Once all parts are assembled, gently tighten all screws to ensure stability.
5. **Safety Check:** Before first use, perform a thorough safety check to ensure the desk and chair are stable, all screws are tight, and there are no loose parts.

Note: Two people may be required for certain assembly steps to ensure ease and safety.

5. OPERATING AND USAGE INSTRUCTIONS

The COSTWAY Children's Desk and Chair set is designed for versatile use in a child's room or study area.

- **Spacious Tabletop:** The large tabletop (85 x 48 cm) provides ample space for various activities such as drawing, reading, homework, or crafts.
- **Integrated Storage:** Utilize the open storage compartment and the large pull-out drawer to organize toys, snacks, books, and school supplies. This helps maintain a tidy environment and encourages organizational skills.
- **Ergonomic Chair:** The included chair features an ergonomic high back designed to support proper sitting posture, promoting comfort during extended use.
- **Recommended Age:** This set is suitable for children aged 3 years and above. The height of the table (70 cm) and chair (36 cm) is adapted to promote a correct learning posture.

Rangement Pratique



Jouets



Collations



Livres



Fournitures Scolaires

Bureau Spacieux

Huche de Rangement

Grand Tiroir

This image illustrates the practical storage features of the desk, including a wide tabletop for activities, an open shelf for books or supplies, and a large drawer for organizing items.

Ensemble Table et Chaise Multifonctionnel pour Enfants



Étudier



Peindre




Lire



Jouer

The multifunctional design of the desk and chair set is shown here, suitable for various activities such as studying, painting, reading, and playing, providing a dedicated space for children.

Chaise à Dossier Haut Incluse



Dossier Ergonomique



Vis Cachées



Bords Arrondis
et Lisses

This image highlights the ergonomic high-back chair designed for comfortable posture, along with key safety features like concealed screws and smoothly rounded edges to prevent injuries.

6. MAINTENANCE

- **Cleaning:** The surface of the desk and chair is designed for easy cleaning. Use a soft, damp cloth to wipe down surfaces. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Spills:** Wipe up spills immediately to prevent staining or damage to the wood.
- **Inspection:** Periodically inspect all screws and connections to ensure they remain tight. Retighten as necessary to maintain structural integrity.
- **Avoid Extreme Conditions:** Do not expose the furniture to extreme temperatures, direct sunlight for prolonged periods, or high humidity, as this may cause warping or discoloration.



Surface Facile à Nettoyer



Poignée de Tiroir Pratique



Barre Transversale Renforcée



Pieds en Bois de Pin Massif

This collage demonstrates the quality construction and user-friendly aspects, including a surface that is easy to clean, a convenient drawer handle, a reinforced crossbar for enhanced stability, and durable solid pine wood legs.

7. TROUBLESHOOTING

If you encounter any issues with your COSTWAY Children's Desk and Chair, consider the following common solutions:

- **Wobbling/Instability:** Check all assembly screws. Ensure they are fully tightened. Verify that the furniture is placed on a level surface.
- **Drawer Sticking:** Ensure the drawer runners are clean and free of debris. Check if the drawer is properly aligned within its tracks.
- **Missing Parts:** If you find any parts missing during assembly, please refer to the support section for assistance.

8. SPECIFICATIONS

Feature	Detail
Model Number	TK32578FR
Color	White
Material	MDF + Pine Wood
Table Dimensions (L x W x H)	85 x 48 x 70 cm (33.5 x 18.9 x 27.6 inches)
Chair Dimensions (L x W x H)	36 x 33 x 69 cm (14.2 x 13 x 27.2 inches)
Drawer Interior Dimensions (L x W x H)	43 x 33 x 10 cm (16.9 x 13 x 3.9 inches)
Suitable Age	3+ Years
Tabletop Weight Capacity	90 kg (198 lbs)
Chair Weight Capacity	50 kg (110 lbs)
Net Weight	19.5 kg (43 lbs)
Number of Drawers	1
Number of Shelves	1 (open compartment)
Assembly Required	Yes

Dimensions






Âge Approprié : 3+ Ans



Capacité de Poids du
Plateau de Table : 90kg



Capacité de Poids
de la Chaise : 50kg



A detailed diagram providing all essential dimensions for the desk (85x48x70 cm) and chair (36x33x69 cm), along with weight capacities: 90 kg for the tabletop and 50 kg for the chair. Suitable for children aged 3+.

9. WARRANTY INFORMATION

Specific warranty information for this product is not available in the provided details. For warranty inquiries, please refer to your purchase documentation or contact COSTWAY customer support directly.

10. SUPPORT

For further assistance, missing parts, or any questions regarding your COSTWAY Children's Desk and Chair, please contact COSTWAY customer service. You may find contact information on the official COSTWAY website or through your retailer's support channels.

You can also visit the official COSTWAY store for more products and information: [COSTWAY Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question