Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ANCTOR HK-DCG-09

ANCTOR Fluted 9-Drawer Dresser User Manual

Model: HK-DCG-09

1. Introduction

Thank you for choosing the ANCTOR Fluted 9-Drawer Dresser. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read it thoroughly before beginning assembly and retain it for future reference.

2. Important Safety Information

- **Anti-Tipping Device:** Always install the included anti-tipping safety device to prevent accidental tipping, especially in households with children. This is crucial for safety.
- **Weight Capacity:** Do not exceed the recommended weight capacity for the tabletop (150 lbs) and drawers (28 lbs per drawer). Overloading can compromise stability and cause damage.
- **Assembly:** Assembly requires two adults. Ensure all parts are present and undamaged before starting. Do not use power tools for assembly unless specifically instructed, as overtightening can damage components.
- **Placement:** Place the dresser on a flat, level surface to ensure stability.
- **Maintenance:** Regularly check all fasteners to ensure they remain tight. Loose fasteners can lead to instability.




Image: Illustration of anti-tipping device installation. The left side shows correct installation with the dresser secured to the wall, indicated by a green checkmark. The right side shows the dresser tipping forward without the device, indicated by a red 'X', highlighting the safety risk.

3. Assembly Instructions

This dresser is designed for easy assembly by two adults. All necessary hardware and detailed instructions are included in the packaging. Please follow the step-by-step guide provided with your product. No special tools are required beyond standard household tools (e.g., screwdriver).

3.1 Unpacking and Part Identification

- Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches.
- Verify that all parts listed in the included parts list are present and undamaged. Contact customer support immediately if any parts are missing or damaged.

3.2 Assembly Steps (General Overview)

1. Assemble the main frame of the dresser according to the diagrams.
2. Attach the back panel.
3. Assemble each drawer individually, ensuring smooth glide mechanisms are correctly installed.
4. Insert the assembled drawers into the dresser frame.
5. Install the three side hooks as desired.
6. Secure the anti-tipping device to the dresser and the wall.



Image: The ANCTOR Fluted 9-Drawer Dresser, illustrating its sleek design and the arrangement of its nine drawers. This image provides a visual reference for the completed assembly.

4. Operation and Usage

4.1 Drawer Usage

- The dresser features nine spacious drawers designed for organizing clothing and other essentials.
- Each drawer has a weight capacity of 28 lbs. Distribute weight evenly to ensure smooth operation and longevity of the drawer slides.
- To open, gently pull the hidden handles. To close, push firmly until the drawer is fully seated.



Image: The dresser with several drawers partially open, demonstrating the internal storage space and suggesting capacity for various items such as underwear, socks, and shirts.

4.2 Elevated Tabletop and Side Hooks

- The elevated tabletop provides a secure surface for displaying decorative items, lamps, or as a TV stand for screens up to 65 inches. The tabletop has a weight capacity of 150 lbs.
- Utilize the three side hooks for convenient access to items like keys, headphones, or small bags.




Image: A detailed view of the dresser's elevated tabletop, designed to prevent items from rolling off, and the three integrated side hooks for hanging accessories.



Image: The ANCTOR dresser functioning as a TV stand, supporting a television up to 65 inches, demonstrating its versatility and robust tabletop.

5. Care and Maintenance

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Dusting:** Regularly dust with a dry, soft cloth.
- **Fasteners:** Periodically check all screws and bolts to ensure they are tight. Retighten as necessary to maintain structural integrity.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the wood finish.
- **Moisture:** Protect the dresser from excessive moisture and spills. Wipe up any liquids immediately.

6. Troubleshooting

Problem	Possible Cause	Solution
Dresser is wobbly.	Uneven floor; loose fasteners.	Ensure the dresser is on a level surface. Check and tighten all assembly screws.
Drawers do not slide smoothly.	Improper installation of drawer slides; overloaded drawer; debris in tracks.	Verify drawer slide installation. Reduce drawer contents if overloaded. Clean tracks of any obstructions.
Missing parts during assembly.	Packaging error.	Contact ANCTOR customer support with your purchase details and the specific missing part number.
Dresser appears unstable.	Anti-tipping device not installed; uneven weight distribution.	Install the anti-tipping device immediately. Redistribute contents in drawers for even weight.

7. Product Specifications

Brand: ANCTOR

Model Name: 9 Drawer Dresser

Model Number: HK-DCG-09

Product Dimensions: 59"W x 15.7"D x 36.2"H

Drawer Depth: 11.8"D

Tabletop Weight Capacity: 150 lbs

Drawer Weight Capacity: 28 lbs per drawer

Material: Engineered Wood

Color: Black (with natural wood fluted drawer fronts)

Assembly Required: Yes (Two adults recommended)

Special Features: Fluted design, elevated tabletop, 3 side hooks, anti-tipping safety device.




Image: Technical drawing illustrating the precise dimensions of the ANCTOR dresser, including its overall width (59"), depth (15.7"), height (36.2"), and the internal dimensions of the drawers.

8. Warranty and Support

ANCTOR stands behind the quality of its products. For warranty information, missing parts, or any other support inquiries, please refer to the warranty card included in your product packaging or contact ANCTOR customer service directly through their official website or the retailer where the product was purchased.

When contacting support, please have your model number (HK-DCG-09) and purchase date readily available.

© 2025 ANCTOR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FB44NBV2

More documents and user manuals: **https://manuals.plus/**