

## H2O 1124603

# H2O Steam Styler Ultimate 2-in-1 Hair Straightener & Curler

Model: 1124603 | Brand: H2O

### IMPORTANT SAFETY INFORMATION

Please read all safety instructions carefully before using the H2O Steam Styler. Failure to follow these instructions may result in electric shock, fire, or personal injury.

- **Burn Hazard:** Surfaces of the styler become extremely hot during use. Avoid direct contact with skin, especially the scalp, ears, and neck. Use caution when handling.
- **Electric Shock Risk:** Keep the appliance away from water. Do not use near bathtubs, showers, sinks, or any other water-filled containers. Never immerse the styler in water or other liquids. If the appliance falls into water, unplug it immediately. Do not reach into the water.
- **Fire Risk:** Unplug the styler immediately after use and when not in use. Do not leave the appliance unattended when plugged in. Ensure the styler is placed on a heat-resistant surface when hot.
- **Children:** Keep this appliance out of reach of children. This product is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- **Damage:** Do not operate the styler with a damaged cord or plug, or if it has been dropped or damaged in any manner. Contact customer support for repair or replacement.
- **Storage:** Allow the styler to cool completely before storing. Do not wrap the power cord around the appliance.

### PRODUCT OVERVIEW

The H2O Steam Styler is an advanced 2-in-1 hair styling tool designed to straighten and curl hair while minimizing heat damage. It incorporates steam, infrared heat, and ion therapy to deliver salon-quality results, promoting frizz control, enhanced shine, and improved hair hydration.

#### Key Features:

- **Triple Action Technology:** Combines Micro-steam, Infrared Heat, and Ion Therapy for comprehensive hair care.
- **Micro-steam Infusion:** Hydrates hair strands, reduces breakage, and enhances elasticity for softer, healthier-looking hair.
- **Infrared Heat:** Locks in moisture from the inside out, requiring less heat and reducing damage while boosting shine.
- **Ion Therapy:** Tourmaline plates release negative ions to smooth frizz, lock in moisture, and add shine.

- **Versatile Styling:** Capable of creating both sleek straight styles and defined curls.
- **Custom Heat Control:** Features 6 adjustable temperature settings (from 300°F to 450°F) suitable for various hair types.
- **Built-in Safety:** Includes dual voltage (100V-240V), a 360° swivel cord, secure lock, and automatic shut-off for user convenience and safety.
- **Removable Water Reservoir:** Facilitates easy refilling for continuous steam styling.



**Figure 1:** The H2O Steam Styler in its packaging, showcasing the sleek design of the 2-in-1 straightener and curler.



**Figure 2:** Illustration of the H2O Steam Styler's core technologies: Micro Steam for hydration, Infrared Heat for shine and moisture retention, and Ion Therapy for frizz reduction.

Your browser does not support the video tag.

**Video 1:** An overview of the H2O Steam Styler, demonstrating its triple-action technology including micro-steam, infrared heat, and ion therapy, and showing its use for both straightening and curling hair.

## COMPONENTS AND CONTROLS

Familiarize yourself with the different parts of your H2O Steam Styler for optimal use.

# EXPLORE OUR TECHNOLOGY



**Figure 3:** Detailed diagram highlighting key components: Heating Plate, 18 Conditioning Steam Vents, Removable Water Reservoir, Lock Switch, 6 Temperature Settings, and Infrared Heating Technology.

- **Heating Plates:** Ceramic tourmaline plates that heat up to style hair.
- **18 Conditioning Steam Vents:** Release micro-steam for hydration during styling.
- **Removable Water Reservoir:** Holds distilled water for steam generation. Located on the top of the styler.
- **Lock Switch:** Secures the plates together for storage or when not in use.
- **Temperature Control Buttons:** Used to select one of the 6 heat settings.
- **Power Button:** Turns the styler ON/OFF.
- **360° Swivel Cord:** Prevents tangling during use.

## INITIAL SETUP

1. **Prepare Hair:** Ensure your hair is clean, dry, and detangled before styling.
2. **Fill Water Reservoir:**

- Locate the removable water reservoir on the top of the styler.
  - Gently slide the reservoir out.
  - Open the rubber stopper and fill the reservoir with **distilled water only**. Do not use tap water, as mineral deposits can clog the steam vents.
  - Close the rubber stopper securely and reinsert the reservoir into the styler until it clicks into place.
3. **Plug In:** Plug the styler into a suitable electrical outlet (100V-240V compatible).
  4. **Power On:** Press and hold the Power button until the indicator light illuminates.
  5. **Select Temperature:** Use the temperature control buttons to select your desired heat setting. Refer to the "Operating Instructions" section for guidance on temperature selection. The styler will heat up quickly.

## OPERATING INSTRUCTIONS

The H2O Steam Styler is designed for both straightening and curling. Always ensure your hair is dry before using the styler.

### Temperature Settings:

The styler offers 6 temperature settings, ranging from 300°F to 450°F. Choose a setting appropriate for your hair type:


- **Low (300°F - 340°F):** For fine, delicate, or chemically treated hair.
- **Medium (350°F - 390°F):** For normal, medium, or wavy hair.
- **High (400°F - 450°F):** For thick, coarse, or very curly hair.

Start with a lower temperature and increase if necessary to achieve desired results without excessive heat exposure.

### Straightening Hair:

1. Ensure the water reservoir is filled and the styler is heated to your desired temperature.
2. Section your hair into small, manageable strands (approximately 1-2 inches wide).
3. Take one section of hair and place it between the heating plates, close to the roots.
4. Gently close the plates and glide the styler slowly and steadily down the hair section, from roots to ends. The steam will activate as you glide.
5. Repeat on all sections until your hair is smooth and straight. Avoid passing over the same section multiple times to prevent unnecessary heat exposure.

# FRIZZ-FREE, SILKY FINISH



**Controls the Frizz**



**Safe for All Hair Types**



**2-in-1 Straightener  
& Curler**



**Hydrates, Protects  
& Shine**



**Reduces Dryness  
& Breakag**

**BEFORE**

**AFTER**

**Figure 4:** A visual comparison demonstrating the effectiveness of the H2O Steam Styler in transforming frizzy hair into a smooth, silky finish.


## **Curling Hair:**

1. Ensure the water reservoir is filled and the styler is heated.
2. Section your hair into small, manageable strands.
3. Take one section of hair and clamp it between the heating plates, about halfway down the strand or closer to the roots for tighter curls.
4. Rotate the styler 180 degrees (either inwards or outwards, depending on desired curl direction) and slowly pull it down through the hair section to the ends. Maintain a consistent, slow pace.
5. Release the hair and allow the curl to cool before touching it to set the style.
6. Repeat on all sections. For a more natural look, alternate curl directions.

# STYLED FOR EVERY STRAND



Steam Styler



FROM CURLY TO STRAIGHT—WE'VE GOT YOU

Figure 5: Demonstrations of various hair types styled with the H2O Steam Styler, showing results for both straight and curled hair.

## CARE AND MAINTENANCE

Proper care ensures the longevity and optimal performance of your H2O Steam Styler.

### 1. Cleaning:

- Always ensure the styler is unplugged and completely cool before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Gently clean the heating plates with a soft, slightly damp cloth to remove any product residue.
- Empty any remaining water from the reservoir after each use to prevent mineral buildup. Rinse the reservoir with distilled water if necessary.

### 2. Storage:

- Ensure the styler is completely cool and dry before storing.

- Engage the lock switch to keep the plates closed.
- Store the styler in a safe, dry place, away from moisture and extreme temperatures.
- Do not wrap the power cord tightly around the appliance, as this can damage the cord.

### TROUBLESHOOTING

If you encounter issues with your H2O Steam Styler, refer to the following common problems and solutions:

| Problem                                        | Possible Cause                                                                                             | Solution                                                                                                                                               |
|------------------------------------------------|------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|
| Styler does not turn on.                       | Not plugged in correctly; power outlet issue; internal fault.                                              | Ensure the styler is securely plugged into a working outlet. Check the power button. If the issue persists, contact customer support.                  |
| No steam is being produced.                    | Water reservoir empty; reservoir not properly inserted; steam vents clogged; steam function not activated. | Check if the water reservoir is filled with distilled water and correctly inserted. Ensure the styler is fully heated. Clean steam vents if necessary. |
| Hair is not straightening/curling effectively. | Temperature setting too low; hair sections too large; styler glided too quickly.                           | Increase the temperature setting. Use smaller hair sections. Glide the styler more slowly and consistently. Ensure hair is completely dry.             |
| Styler is pulling hair.                        | Hair not properly detangled; styler plates misaligned.                                                     | Ensure hair is thoroughly detangled before use. If plates appear misaligned, discontinue use and contact customer support.                             |

### TECHNICAL SPECIFICATIONS

| Feature            | Detail                     |
|--------------------|----------------------------|
| Model Number       | 1124603                    |
| Brand              | H2O                        |
| Product Dimensions | 12.6 x 1.77 x 1.77 inches  |
| Item Weight        | 2.03 Pounds                |
| Color              | Purple                     |
| Material           | Tourmaline (Plates)        |
| Wattage            | 70 watts                   |
| Power Source       | Corded Electric            |
| Voltage            | 100V-240V (Dual Voltage)   |
| Temperature Range  | 300°F - 450°F (6 settings) |

### WARRANTY AND CUSTOMER SUPPORT

For warranty information, product registration, or technical assistance, please contact H2O customer support.

Please refer to the product packaging or the official H2O website for the most up-to-date contact details and warranty terms specific to your region.

**Online Support:** Visit the [H2O Store on Amazon](#) for additional product information and support resources.

**Ask a question about this manual**

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question