

BTHFST LED TV Stand 63-inch

BTHFST LED TV Stand 63-inch Instruction Manual

Model: LED TV Stand 63-inch

PRODUCT OVERVIEW

The BTHFST LED TV Stand is designed to accommodate televisions up to 75 inches, providing a functional and organized entertainment solution. This unit features integrated power outlets, multi-functional RGB LED lighting, and various storage options to meet diverse needs.

- **Convenient Power Outlets:** Equipped with 2 standard AC power outlets, 1 USB-A port, and 1 Type-C port for charging multiple devices simultaneously.
- **Multi-Functional Ambient Lights:** Smart RGB LED lights controllable via a mobile application or button. Offers over 60,000 colors, customizable brightness, various modes (including Music Sync), and timer settings.
- **Various Storage Spaces:** Includes 6 fabric drawers, 4 fabric pockets, an open shelf, and 2 height-adjustable metal mesh shelves for classified storage of different item sizes and types.
- **Sturdy and Stable Construction:** Manufactured from high-quality engineered wood, metal, and non-woven fabric for durability. Features an anti-tipping kit for enhanced safety and adjustable feet for stability on uneven surfaces.




Image: Overview of the BTHFST LED TV Stand, illustrating its dimensions (63 inches width, 20 inches height, 13.8 inches depth) and suitability for TV sizes up to 75 inches. Also shows the dimensions of the fabric drawers.

SETUP INSTRUCTIONS

This TV stand requires assembly. Please follow the included detailed instructions and ensure all parts are present before beginning. Assembly typically requires basic household tools.

- 1. Unpack Components:** Carefully unpack all parts and hardware. Verify that all components listed in the assembly guide are present and undamaged.
- 2. Assemble Frame:** Follow the step-by-step diagrams in the provided manual to assemble the main metal and engineered wood frame of the TV stand.
- 3. Install Shelves and Drawers:** Insert the adjustable metal mesh shelves into their designated positions. Assemble and insert the fabric drawers and fabric pockets.

4. **Attach Anti-Tipping Device:** Secure the anti-tipping kit to the TV stand and the wall according to the instructions to prevent accidental tipping.
5. **Connect LED Lights and Power Outlets:** Install the LED light strips in the designated areas. Connect the power outlets and ensure all wiring is neatly managed.
6. **Adjust Feet:** Adjust the height-adjustable feet to ensure the TV stand is level and stable on your floor.




Image: Illustration of the anti-tipping device installation, showing how to secure the TV stand to the wall for safety.



Image: Close-up of the adjustable feet, demonstrating how they can be rotated to balance the TV stand on uneven floors and protect surfaces from scratches.

OPERATING INSTRUCTIONS

LED Lighting System

The integrated RGB LED lights offer various customization options to enhance your viewing experience.

- **Control Methods:** The LED lights can be controlled via a dedicated mobile application or directly using the button control unit.
- **Color Selection:** Access over 60,000 colors through the mobile application to match your mood or room decor.
- **Brightness Adjustment:** Customize the light intensity to your preference.
- **Dynamic Modes:** Explore various pre-set dynamic lighting effects.

- **Music Sync Mode:** The lights can flash and change color in rhythm with music playing in the room.
- **Timer Settings:** Set schedules for the lights to turn on or off automatically.




Image: The TV stand illuminated with pink LED lights, showcasing the various control options including mobile app control, dynamic modes, music mode, mic mode, and timing function.

Integrated Charging Station

The TV stand includes a built-in charging station for convenient power access.

- **AC Outlets:** Two 125V/12A standard AC power outlets are available for larger electronics.
- **USB-A Port:** One 5V/2.1A USB-A port for charging compatible devices.
- **Type-C Port:** One 5V/2.1A Type-C port for charging compatible devices.

Convenient Charging Station



125V / 12A
[2 AC Outlets]



5V / 2.1A
[1 USB-C]



5V / 2.1A
[1 USB-A]



Image: Close-up view of the convenient charging station integrated into the TV stand, featuring two AC outlets, one USB-C port, and one USB-A port, with a device actively charging.

MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your BTHFST LED TV Stand.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Dusting:** Regularly dust all surfaces, including shelves and drawers, to prevent buildup.
- **Drawer Care:** The fabric drawers can be spot cleaned with a mild detergent if necessary. Ensure they are completely dry before reinserting.
- **Electrical Components:** Ensure power cords are not pinched or damaged. Unplug the unit from the power source before cleaning or performing any maintenance on electrical components.
- **Stability Check:** Periodically check all screws and fasteners to ensure they are tight. Re-adjust the feet if the stand

becomes unstable.



Image: Detailed view of the fabric drawer construction, highlighting the non-woven fabric and MDF board materials, indicating a sturdy design compared to typical fabric drawers.

TROUBLESHOOTING

If you encounter issues with your BTHFST LED TV Stand, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
LED lights not working	Power connection loose; LED strip damaged; Controller malfunction.	Check all power connections. Ensure the power adapter is plugged in. Verify the LED strip is correctly connected to the controller. If issues persist, contact customer support.
Power outlets not functioning	Power cord unplugged; Circuit breaker tripped; Device not compatible.	Ensure the TV stand's main power cord is securely plugged into a working wall outlet. Check your home's circuit breaker. Test with a different device.
Stand is unstable/wobbly	Uneven floor; Loose fasteners; Adjustable feet not properly set.	Adjust the height-adjustable feet to level the stand. Tighten all assembly screws. Ensure the anti-tipping device is correctly installed.
Drawers do not slide smoothly	Obstruction; Drawer overloaded; Improper assembly.	Check for any items blocking the drawer path. Reduce the weight in the drawer. Review assembly steps for correct drawer installation.

SPECIFICATIONS

Feature	Detail
Brand	BTHFST
Model	LED TV Stand 63-inch

Feature	Detail
Color	Rustic Brown
Material	Engineered Wood, Metal, Non-Woven Fabric
Dimensions (D x W x H)	13.8" x 63" x 20"
Recommended TV Size	Up to 75 inches
Power Outlets	2 x 125V/12A AC Outlets
USB Ports	1 x 5V/2.1A USB-A, 1 x 5V/2.1A Type-C
LED Lights	RGB, APP & Button Control, 60,000+ Colors, Dynamic Modes, Music Sync, Timer
Number of Drawers	6 Fabric Drawers
Number of Shelves	3 (including 2 adjustable metal mesh shelves)
Additional Features	4 Fabric Pockets, Anti-Tipping Kit, Adjustable Feet
Assembly Required	Yes



Image: Visual representation of the TV stand's compatibility with different television sizes, specifically showing it can accommodate TVs from 55 inches up to 75 inches.

Safety Information

Please read and adhere to the following safety guidelines to ensure safe use of your TV stand:

- Always follow the assembly instructions carefully.
- Use the anti-tipping kit and adjust the feet for stability.
- Keep the product away from heat sources.
- Do not place heavy objects on the top shelf to prevent tipping.
- Always unplug the power cord when not in use or when performing maintenance.

WARRANTY AND SUPPORT

BTHFST stands behind the quality of its products. For warranty information, technical support, or any questions regarding your LED TV Stand, please contact our customer service team.

Please refer to your purchase documentation or the official BTHFST website for specific warranty terms and contact details.

© 2026 BTHFST. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FB52BYK7>

More documents and user manuals: <https://manuals.plus/>