

- Manuals.plus /
- > OUTON /
- > OUTON White Drum Lamp Shades Instruction Manual

OUTON 16 Inch+White Shade(2 PCS)

OUTON White Drum Lamp Shades Instruction Manual

Model: 16 Inch+White Shade (2 PCS) | Brand: OUTON

INTRODUCTION

Thank you for choosing the OUTON White Drum Lamp Shades. This manual provides detailed instructions for the assembly, operation, and maintenance of your new lamp shades. Designed for versatility and elegance, these shades are perfect for enhancing the ambiance of your home with soft, comfortable light. Please read this manual thoroughly before assembly and use to ensure proper installation and longevity of your product.



Image: Two OUTON White Drum Lamp Shades, ready for assembly or use.

PRODUCT FEATURES

- **Optimal Size:** Each shade measures 16 inches at the top and bottom diameter, with a height of 9 inches. The screw thread is 1.65 inches, suitable for E26 & E27 lamp bases.
- **Easy Self-Assembly:** Features a folding design for simple, tool-free installation. The lampshade fixes around metal rings using clips, allowing for quick setup.
- **Versatile Application:** Ideal for various lighting fixtures including table lamps, floor lamps, and chandeliers, adding elegance to any room.
- **Professional Quality:** Crafted from natural linen material, ensuring no surface stains and designed for durability.
- **Soft, Comfortable Light:** The linen material provides excellent light transmittance, scattering light softly to prevent glare and create a pleasant environment.



Image: Detailed view of the lamp shade's natural linen fabric, sturdy metal frame, and secure buckle system.

Wide Application



Image: Examples of the lamp shade's wide application in different home environments, including floor lamps, pendant lights, and table lamps.

SPECIFICATIONS

Attribute	Detail
Brand	OUTON
Model	16 Inch+White Shade (2 PCS)
Color	White
Material	Linen
Shape	Round (Drum)

Product Dimensions (W x H)	16 inches x 9 inches
Screw Thread Diameter	1.65 inches (suitable for E26 & E27)
Mounting Type	Embedded (Spider Fitter)
Item Weight	2.68 pounds (for the set)

Please Confirm the Size Before Place Order









Image: Dimensional diagram of the lamp shade, highlighting the 16-inch diameter and 1.65-inch spider fitter.


Suitable for All Bulb Bases



E26/E27



E12/E14



Harp Holder

Image: Compatibility guide for various bulb bases, including E26/E27, E12/E14, and Harp Holders.

ASSEMBLY INSTRUCTIONS

The OUTON lamp shades are designed for quick and easy self-assembly without the need for any tools. Follow these steps to set up your new lamp shade:

1. **Form the Top Ring:** Take one of the metal rings. Connect the two ends of the metal ring to form a complete circle. Ensure the connection is secure.
2. **Form the Bottom Ring:** Repeat the process with the second metal ring to form another complete circle. This will be the bottom support for your lampshade.
3. **Unfold the Lampshade Fabric:** Carefully unfold the linen lampshade fabric. You will notice Velcro strips on the ends. Align and firmly press the Velcro ends together to form the cylindrical shape of the lampshade.
4. **Attach Rings to Fabric:** Insert the formed metal rings into the top and bottom edges of the fabric lampshade. The fabric has integrated clips or pockets designed to hold the rings securely in place. Ensure all buckles or clips are properly attached to the round brackets of the rings.

5. **Install on Lamp Base:** Once assembled, place the lampshade onto your lamp base. The 1.65-inch spider fitter (the central ring on the top metal frame) is designed to fit standard E26 & E27 lamp holders.

Note: The folding design is intentional to ensure the lampshade arrives in perfect condition and simplifies shipping.



Image: Step-by-step visual instructions for assembling the OUTON Drum Lamp Shade.

OPERATING INSTRUCTIONS

Once assembled and placed on your lamp base, the OUTON lamp shade functions as a standard lampshade, diffusing light from your bulb. Ensure your lamp is connected to a power source and the bulb is securely screwed in.

- **Light Diffusion:** The natural linen material is designed to scatter light softly, reducing harsh glare and creating a warm, inviting atmosphere.
- **Bulb Compatibility:** The shade is compatible with various bulb types (LED, incandescent, CFL) as long as they fit within the shade's dimensions and are suitable for your lamp's socket (E26/E27, E12/E14, or Harp Holder).
- **Optimizing Lighting Effect:** The appearance of the light (warm, daylight, white) will depend on the type of light

bulb you use. Experiment with different bulbs to achieve your desired lighting effect.



Image: Visual representation of various lighting effects achievable with different bulb types and brightness levels.

MAINTENANCE

To ensure your OUTON lamp shades remain in excellent condition and provide optimal light diffusion, follow these simple maintenance guidelines:

- **Dusting:** Regularly dust the lampshade with a soft, dry cloth or a feather duster to prevent dust buildup.
- **Spot Cleaning:** For minor spots or smudges, gently wipe the affected area with a slightly damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the linen fabric.
- **Deep Cleaning:** If a more thorough cleaning is required, it is recommended to carefully remove the fabric from the metal frame and gently hand wash it with mild soap and cold water. Allow it to air dry completely before reassembling.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause the linen fabric to fade over time. Position

your lamp in an area where it is not constantly exposed to intense sunlight.

- **Handle with Care:** While durable, avoid applying excessive force or bending the metal frame during handling or cleaning to prevent deformation.

TROUBLESHOOTING

If you encounter any issues with your OUTON lamp shades, please refer to the common problems and solutions below:

Problem	Possible Cause	Solution
Lampshade appears wrinkled or creased.	This is normal due to the folding design for shipping.	Once assembled and in place, minor creases should naturally relax. Gentle steaming from a distance may help, but avoid direct contact with steam.
Lampshade does not sit straight on the lamp.	Improper assembly of the metal rings or incorrect placement on the lamp holder.	Ensure both metal rings are perfectly circular and securely attached to the fabric. Verify the spider fitter is correctly aligned and tightened onto your lamp's bulb holder.
Light appears too dim or too bright.	This is related to the light bulb used, not the lampshade.	Replace the light bulb with one of a different wattage or color temperature (e.g., higher wattage for brighter light, warmer color temperature for a softer glow).
Fabric detaches from the metal rings.	Clips or buckles not fully engaged during assembly.	Carefully re-attach the fabric to the metal rings, ensuring all integrated clips or buckles are firmly secured around the ring brackets.

WARRANTY AND SUPPORT

OUTON is committed to providing high-quality products. Your OUTON Lamp Shades are covered by a standard manufacturer's warranty against defects in materials and workmanship. For specific warranty details, including duration and coverage, please refer to the product packaging or contact OUTON customer support.

If you have any questions, require assistance with assembly, or need to report a defect, please contact our customer support team:

Email: support@outon.com

Website: www.outon.com (for FAQs and additional resources)

Please have your product model number (16 Inch+White Shade) and purchase date ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FB8FRZQ3>

More documents and user manuals: <https://manuals.plus/>