

[Manuals.plus](#) /

> [MRSXWPY](#) /

> MRSXWPY T600-00 7-inch GPS Navigator User Manual

MRSXWPY T600-00

MRSXWPY T600-00 7-inch GPS Navigator User Manual

Model: T600-00

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your MRSXWPY T600-00 7-inch GPS Navigator. Please read this manual thoroughly before using the device to ensure proper functionality and safety.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- GPS Navigator Unit
- Car Charger
- USB Cable
- Suction Cup Bracket
- Rear Bracket
- Sunshade
- User Manual (this document)



USB Cable x 1



Car Charge x 1



Sunshade x 1



Mount x 1



Instructions x 1



Color Box x 1

Image: All components included in the MRSXWPY T600-00 GPS Navigator package, including the main unit, car charger, USB cable, mounting brackets, sunshade, and user manual.

SETUP

1. Mounting the GPS Navigator

1. Attach the rear bracket to the GPS Navigator unit.
2. Secure the suction cup bracket to the rear bracket.
3. Clean the desired mounting surface on your windshield or dashboard.
4. Press the suction cup firmly against the surface and engage the lever to create a secure seal.
5. Adjust the viewing angle of the GPS Navigator for optimal visibility without obstructing your view of the road.



Image: The MRSXWPY T600-00 GPS Navigator attached to its suction cup mount, ready for installation in a vehicle.



Image: The MRSXWPY T600-00 GPS Navigator mounted on a car windshield, displaying navigation information.

2. Powering On and Initial Charge

- Connect the car charger to the GPS Navigator's USB Type-C port and plug it into your vehicle's 12V power outlet.
- Press and hold the Power On/Off button located on the top edge of the device to turn it on.
- For initial use, ensure the device is fully charged. The internal battery provides approximately 6 hours of operation.



Image: Rear view of the MRSXWPY T600-00 GPS Navigator, highlighting the Power On/Off button, Earphone Slot, IF Card Slot, USB Type-C port, and Reset button.

3. Map Updates

Your GPS Navigator comes preloaded with the latest North American (USA, Canada, Mexico) maps. Free lifetime map updates are available. To update maps:

1. Connect the GPS Navigator to a computer using the provided USB cable.
2. Follow the instructions provided with the device or on the manufacturer's website for the specific map update software.



TRAFFIC LIGHT REMINDER

Navigation at the location of the traffic light will be reminded by voice in time

SPEED LIMIT REMINDER

On expressway sections with speed limits, voice prompts will remind you to maintain a safe speed



Image: The GPS Navigator connected via USB to a laptop, illustrating the process for lifetime free map updates for North America and other regions.

OPERATING INSTRUCTIONS

1. Basic Navigation

To begin navigation, tap the "Navigation" icon on the main screen. You can enter your destination using several methods:

- **Address:** Enter the street number, street name, city, and state/province.
- **Zip Code:** Enter the postal code for the destination area.
- **Coordinates:** Input specific GPS coordinates (latitude and longitude).
- **Points of Interest (POI):** Search for nearby gas stations, restaurants, parking lots, or other common destinations.
- **Favorites:** Select from previously saved destinations.



Image: The MRSXWPY T600-00 GPS Navigator screen showing a split-view navigation display with map and lane guidance.

2. Route Options and Customization

The GPS Navigator offers various route planning options:

- **Standard Options:** Choose between Fast, Green (eco-friendly), Short, or Convenient routes.
- **Custom Truck Routing:** For truck drivers, customize routes based on your vehicle's weight, length, height, and width to avoid restricted roads. Access this feature in the navigation settings.

3. Intelligent Voice Navigation Features

The device provides clear voice guidance and alerts to enhance your driving experience:

- **Turn-by-Turn Directions:** Voice prompts for upcoming turns and road names.
- **Speed Camera Reminder:** Alerts for surveillance cameras on the road.
- **Speed Limit Reminder:** Notifies you of current speed limits and warns if you exceed them.
- **Red Light Warning:** Provides alerts for upcoming traffic lights.
- **Height Limit Reminder:** Warns drivers of bridge and road height restrictions.
- **Lane Assistance:** Guides you to the correct lane for upcoming maneuvers.
- **Estimated Arrival Time (ETA):** Displays your projected arrival time and remaining distance.



SPEED CAMERA REMINDER

Remind the driver to pay attention to the surveillance camera on the road ahead on the road section with camera

HEIGHT LIMIT REMINDER

Remind drivers to pay attention to the road height limit on the road section of the bridge hole and the height limit pole



Image: Visual representation of the traffic light reminder and speed limit reminder features on the GPS Navigator.

Modes



Image: Visual representation of the speed camera reminder and height limit reminder features on the GPS Navigator.

4. Vehicle Service Types

The MRSXWPY T600-00 supports navigation for a wide range of vehicle types:

- Car
- Truck
- RV (Recreational Vehicle)

- Bus
- Taxi
- Bicycle
- Pedestrian
- Emergency Vehicle

Wide Applicability of 7 Vehicle Modes



Image: The GPS Navigator screen displaying a map alongside icons representing the wide applicability across different vehicle modes, including cars, trucks, RVs, buses, taxis, bicycles, and pedestrians.

MAINTENANCE

1. Cleaning the Device

- Use a soft, lint-free cloth to gently wipe the screen and device exterior.
- Do not use abrasive cleaners, alcohol, or solvents, as these can damage the screen and finish.
- Ensure the device is powered off before cleaning.

2. Battery Care

- To prolong battery life, avoid exposing the device to extreme temperatures.

- Charge the device regularly, especially if it will be stored for an extended period.
- The device uses a 12V battery and has a battery life of approximately 6 hours.

3. Map Updates

Regularly check for and install map updates to ensure the most accurate navigation data. Refer to the "Setup" section for instructions on updating maps.

TROUBLESHOOTING

If you encounter issues with your MRSXWPY T600-00 GPS Navigator, please refer to the following common solutions:

- **Device not powering on:** Ensure the device is charged. Connect it to the car charger or a USB power source.
- **No GPS signal:** Ensure the device has a clear view of the sky. Move away from tall buildings or dense foliage.
- **Incorrect route guidance:** Verify that the maps are up-to-date. Check your selected vehicle type and route preferences in the settings.
- **Screen unresponsive:** Perform a soft reset by pressing the reset button (often a small pinhole) on the back of the device using a thin object like a paperclip.
- **Map loading issues:** Ensure sufficient storage space on the device. Re-attempt map updates if necessary.

SPECIFICATIONS

Feature	Detail
Model Name	T600-00
Brand	MRSXWPY
Display Size	7 Inches
Product Dimensions	5.8 x 3 x 8.2 inches
Item Weight	1.25 pounds
Battery Type	12V (included)
Battery Life	Approximately 6 Hours
Connectivity Technology	USB
Map Type	Street (North America preloaded)
Special Feature	Turn-by-turn Navigation, Voice Guidance, Custom Truck Routing
Vehicle Service Type	Car, RV, Truck, Bus, Taxi, Bicycle, Pedestrian, Emergency Vehicle
Audio Output Mode	Stereo

WARRANTY INFORMATION

The MRSXWPY T600-00 GPS Navigator comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. Please retain your proof of purchase for warranty claims.

For detailed warranty terms and conditions, please refer to the documentation included with your product or contact customer support.

CUSTOMER SUPPORT

Should you require assistance with your MRSXWPY T600-00 GPS Navigator, our professional support team is available to help. Please contact us through the following channels:

- **Email:** [Insert Manufacturer's Support Email Here]
- **Phone:** [Insert Manufacturer's Support Phone Number Here]
- **Website:** [Insert Manufacturer's Support Website Here]

When contacting support, please have your product model (T600-00) and purchase information ready.

