

Hemobllo ZP01561CC3N50Q4E

Hemobllo Microwave Glass Turntable Plate Instruction Manual

Model: ZP01561CC3N50Q4E

INTRODUCTION

This manual provides instructions for the proper installation, operation, and maintenance of your Hemobllo Microwave Glass Turntable Plate, model ZP01561CC3N50Q4E. Please read this manual thoroughly before use to ensure safe and efficient operation.

The Hemobllo Microwave Glass Turntable Plate is designed as a replacement part for various microwave ovens, ensuring even heating of food. It is constructed from durable glass material.

PACKAGE CONTENTS

- 1 x Hemobllo Microwave Glass Turntable Plate

SAFETY INFORMATION

- Ensure the microwave oven is unplugged before installing or removing the turntable plate.
- Handle the glass plate with care to prevent breakage.
- Do not use a cracked or broken turntable plate, as this can be a safety hazard.
- Verify the dimensions of the replacement plate match your microwave oven's requirements.

SETUP AND INSTALLATION

1. **Unpack the Turntable Plate:** Carefully remove the glass turntable plate from its packaging. Inspect it for any damage.
2. **Prepare the Microwave:** Ensure your microwave oven is clean and free of debris. Locate the turntable support ring and coupler (if applicable) inside the microwave.

3. **Place the Plate:** Position the glass turntable plate onto the central coupler and the support ring. Ensure it sits securely and can rotate freely.

EASY TO USE



Image: The Hemoblo Microwave Glass Turntable Plate correctly installed inside a microwave oven, ready for use. A white mug is placed on the plate to demonstrate its function.

OPERATING INSTRUCTIONS

Once installed, the Hemoblo Microwave Glass Turntable Plate operates automatically with your microwave oven. No special operation is required for the plate itself.

- Place food items centrally on the turntable plate for optimal and even heating.
- Ensure the plate is clean before placing food on it.
- Avoid placing excessively heavy items that could exceed the microwave's internal weight capacity.



Image: Examples of the turntable plate in use, demonstrating its ability to hold various food containers for heating.

MAINTENANCE AND CLEANING

Regular cleaning of your turntable plate will ensure hygiene and prolong its lifespan.

- **Daily Cleaning:** Wipe the plate with a damp cloth after each use to remove food spills.
- **Deep Cleaning:** The glass plate can be removed and washed with warm, soapy water. Rinse thoroughly and dry completely before placing it back in the microwave.
- **Dishwasher Safe:** The glass turntable plate is typically dishwasher safe. Refer to your microwave oven's manual for specific care instructions regarding its components.
- Avoid abrasive cleaners or scouring pads that could scratch the glass surface.



Safe materials



Durable and sturdy



Easy to clean

Image: Visual representation of the product's key attributes: safe materials, durability, and ease of cleaning.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Plate does not rotate.	Plate not seated correctly on the coupler or support ring. Debris under the plate. Microwave motor issue.	Re-seat the plate, ensuring it aligns with the coupler and support ring. Clean any debris. If the issue persists, consult your microwave oven's manual or a qualified technician.
Plate is wobbly or unstable.	Incorrect plate size. Damaged support ring or coupler.	Verify the plate dimensions match your microwave. Inspect the support ring and coupler for damage; replace if necessary.
Food not heating evenly.	Plate not rotating. Food placed off-center.	Ensure the plate rotates. Place food centrally on the plate.

SPECIFICATIONS

- **Brand:** Hemoblo
- **Model Number:** ZP01561CC3N50Q4E
- **Material:** Glass
- **Color:** White
- **Product Dimensions:** 9.65 x 9.65 x 0.59 inches (24.50 x 24.50 x 1.50 cm)
- **Item Weight:** Approximately 1.36 - 1.4 Pounds




Image: Detailed dimensions of the glass turntable plate for compatibility verification.

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the retailer's return policy or contact Hemoblo customer service through the platform where the product was purchased. The standard return policy is typically 30 days for refund or replacement.

For further assistance, you may visit the [Hemoblo Store on Amazon](#).

© 2025 Hemoblo. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question