Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ACCOHOHO LM088

ACCOHOHO 22-inch Nightstand with Charging Station

Model: LM088
Brand: ACCOHOHO

Important Safety Information

Caution:

- This product features a handle-free design with Push-to-Open drawers. Keep fingers clear of the opening mechanism to prevent injury.
- While sturdy, this product is not designed for heavy-duty use.
- Ensure the nightstand is properly assembled and stable before use to prevent tipping or collapse.
- Always follow the assembly instructions carefully.

Product Overview

The ACCOHOHO 22-inch Nightstand is a modern bedside table designed for convenience and storage. It features two push-to-open drawers, a semi-open cubby, and an integrated charging station. Its sleek design and durable construction make it suitable for bedrooms, living rooms, or home offices.



Image: The ACCOHOHO 22-inch Nightstand, showcasing its two drawers and open storage cubby.

Your browser does not support the video tag.

Video: An overview of the ACCOHOHO 22-inch Nightstand, highlighting its features such as the charging station and push-to-open drawers.

Setup and Assembly

This nightstand requires assembly. Follow the comprehensive instructions provided in the packaging. Each component is labeled with serial numbers for easy identification. A pack of spare hardware is included.

Tools Required:

- Allen Key (included)
- Screwdriver (not included)

Assembly Steps:

1. Unpack all components and verify against the parts list in the instruction manual.
2. Follow the step-by-step diagrams and instructions to assemble the frame.
3. Install the drawer slides and push-latch mechanisms.
4. Assemble the drawers and insert them into the nightstand.
5. Connect the charging station unit according to the electrical safety guidelines.
6. Ensure all connections are secure and the nightstand is stable before use.



Image: Dimensional diagram of the nightstand, including width, depth, height, and load capacities for the tabletop, open storage, and drawers.

Operating Instructions

Using the Charging Station:

The integrated charging station on the tabletop provides convenient power access. It includes 2 AC outlets (125V/12A) and USB/Type-C ports (5V/2.1A). Simply plug your devices into the appropriate ports. The power cord is 4.9 feet long.



Image: A close-up view of the nightstand's charging station with a phone and tablet connected for charging.

Using the Push-to-Open Drawers:

The nightstand features two handle-free drawers with a push-to-open mechanism. To open a drawer, gently press the center of the drawer front. The drawer will spring open. To close, push the drawer back until it latches securely.



Image: The nightstand with both push-to-open drawers extended, revealing ample storage space for various items.



Push Latch

Effortless push-to-open functionality, designed for modern convenience, our nightstand feature a built-in push-open rebound mechanism. Simply press the drawer front, and it will gently spring open—no handles needed.

NOTE: If the drawer doesn't pop out when pressed, please adjust the Push Latch to the left.

Semi-Open Cubby for Storage

Easily access your essentials with the semi-open cubby, perfect for keeping books, remotes, or decorative items within arm's reach while maintaining a clean, organized look.



Image: A detailed view of the push latch mechanism for the drawers and the semi-open cubby for quick access storage.

Using the Semi-Open Cubby:

The semi-open cubby provides easily accessible storage for items like remotes, books, or decorative pieces, helping to keep your space organized.

Maintenance

To maintain the appearance and longevity of your ACCOHOHO nightstand, follow these guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the engineered wood finish.
- **Spills:** Promptly clean up any spills to prevent staining, especially on the water-resistant surfaces.

- **Dusting:** Regularly dust with a dry, soft cloth.
- **Drawer Mechanisms:** Periodically check the push-latch mechanisms and drawer glides for smooth operation. If a drawer does not pop out when pressed, adjust the push-latch mechanism as needed (refer to assembly instructions for details).
- **Stability:** Ensure the nightstand remains stable. Tighten any loose screws if necessary.

Troubleshooting

If you encounter issues with your nightstand, please refer to the following common solutions:

- **Drawer not opening/closing smoothly:**
  - Check if the push-latch mechanism is properly aligned. The instruction manual provides guidance on adjusting the push-latch.
  - Ensure no objects are obstructing the drawer slides.
  - Verify that the drawer slides are securely attached and not bent.
- **Nightstand feels wobbly:**
  - Re-tighten all assembly screws. Do not overtighten.
  - Ensure the nightstand is placed on a flat, level surface.
- **Charging station not working:**
  - Check if the main power cord is securely plugged into a functional wall outlet.
  - Ensure devices are properly connected to the USB/Type-C ports or AC outlets.
  - Test the wall outlet with another appliance to confirm it has power.

For further assistance, please contact ACCOHOHO customer support.

Specifications

Brand	ACCOHOHO
Model Number	LM088
Product Dimensions (D x W x H)	16" x 22" x 24"
Item Weight	44 Pounds
Frame Material	Engineered Wood
Color	Black
Number of Drawers	2
Special Features	Charging Station, Push-to-Open
Charging Station Output	2 AC Outlets (125V/12A), USB/Type-C (5V/2.1A)

Power Cord Length	4.9 Feet
Assembly Required	Yes

Warranty Information

For specific warranty details regarding your ACCOHOHO nightstand, please refer to the documentation included with your purchase or contact ACCOHOHO customer support directly. Warranty terms typically cover manufacturing defects under normal use.

Support

If you require further assistance, have questions about assembly, or need to report a missing part, please contact ACCOHOHO customer support. You can also visit the official ACCOHOHO store for more product information and support resources:

Visit the ACCOHOHO Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FB8WRN19

More documents and user manuals: **https://manuals.plus/**