

AOCHUAN Smart M3

AOCHUAN Smart M3 Face Tracking Tripod User Manual

Model: Smart M3

1. INTRODUCTION

The AOCHUAN Smart M3 is a versatile 3-in-1 device combining a selfie stick, desktop stand, and floor tripod, featuring advanced AI face tracking and remote control capabilities. Designed for content creators and everyday users, it offers hands-free video recording and photography without the need for a dedicated application. This manual provides comprehensive instructions for setting up, operating, and maintaining your Smart M3 tripod.

2. SAFETY INFORMATION

- Do not expose the device to extreme temperatures or direct sunlight for extended periods.
- Keep the device away from water and other liquids.
- Avoid dropping or subjecting the device to strong impacts.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.
- Ensure your smartphone is securely mounted in the holder before use.

3. PACKAGE CONTENTS

Verify that all items are included in your package:

- Smart M3 AI Face Tracking Tripod
- Remote Control (x1)
- USB-C Charging Cable (x1)
- Product Manual (x1)



Image: The package contents of the AOCHUAN Smart M3, showing the main tripod unit, a small remote control, a USB-C charging cable, and the instruction manual.

4. PRODUCT OVERVIEW

The AOCHUAN Smart M3 features an integrated design with several key components:

- **Phone Holder:** Securely holds smartphones from 1.8 to 3.8 inches in width.
- **AI Tracking Camera:** Located on the main unit, it detects and follows faces.
- **Power Button:** For turning the device on/off.
- **USB-C Charging Port:** For recharging the internal battery.
- **Remote Control Slot:** Stores the detachable Bluetooth remote.
- **Extendable Pole:** Made from aluminum alloy, extends up to 57 inches.
- **Tripod Legs:** Four-legged design with anti-slip rubber pads for enhanced stability.



Image: A comprehensive view of the AOCHUAN Smart M3, illustrating its compact form, extended selfie stick mode, and tripod configuration, alongside its detachable remote control.

Multi-Angle Shooting



Image: A detailed view highlighting the hidden phone holder mechanism, the silicone non-slip foot pads on the tripod base, and the integrated slot for the remote control.

5. SETUP

5.1 Unfolding the Tripod

1. Gently pull the bottom of the device to extend the tripod legs. Ensure they are fully spread for maximum stability.
2. Extend the telescopic pole to your desired height. The pole can reach up to 57 inches.

5.2 Attaching Your Smartphone

1. Open the phone holder by pulling the top clip upwards.
2. Carefully place your smartphone into the holder, ensuring it is centered and securely gripped. The holder accommodates devices from 1.8 to 3.8 inches wide.



AI Face Tracking

 | **OK gesture**
to start tracking

 | **Palm gesture**
to stop tracking



NO APP



Image: A smartphone is shown mounted horizontally in the adjustable phone holder of the AOCHUAN Smart M3 tripod, ready for use.

5.3 Powering On

Press and hold the power button on the main unit until the indicator light illuminates.

5.4 Remote Control Pairing

The remote control uses Bluetooth. To pair, ensure the remote is charged and the tripod is powered on. Activate Bluetooth on your smartphone and select the Smart M3 remote from the list of available devices. The remote is typically pre-paired or automatically connects upon activation.

Your browser does not support the video tag.

Video: An official product video demonstrating the setup, remote control functionality, and AI face tracking features of the AOCHUAN Smart M3 tripod.

6. OPERATING INSTRUCTIONS

6.1 AI Face Tracking

The Smart M3 features an integrated AI tracking camera that does not require an app. It automatically detects and follows faces.


- **To Start Tracking:** Make an "OK" gesture with your hand towards the AI tracking camera. The device will begin to rotate and follow your face.
- **To Stop Tracking:** Show your open palm to the AI tracking camera. The device will pause tracking.

57" Extenable Telescopic Pole

Let everyone be in the picture



Ours (Full screen)



Others (Half screen)

Image: A visual guide to using AI face tracking, showing a user making an 'OK' gesture to initiate tracking and a palm gesture to stop it, with the Smart M3 tripod in the foreground.

6.2 Remote Control Function

The detachable remote control allows you to operate your smartphone's camera from a distance of up to 10 meters (32 feet). Use it to trigger photos or start/stop video recording, ideal for group shots or solo content creation.

Remote Control

Embedded remote control to help you shoot from a distance



Image: A group of people posing for a photo, with the AOCHUAN Smart M3 tripod set up and the remote control visible, illustrating its use for distant photography.

6.3 Extendable Pole

The built-in aluminum alloy extension pole can be adjusted to a maximum height of 57 inches, providing flexibility for various shooting scenarios and wider fields of view.



Image: The AOCHUAN Smart M3 tripod extended to its full 57-inch height, demonstrating its capability to capture a broader scene or include more subjects in a shot.

6.4 Multi-Angle Shooting

The Smart M3 offers extensive adjustability for capturing unique perspectives:

- **360° Rotating Head:** Allows for panoramic shots and seamless tracking.
- **270° Tilt Adjustment:** Adjust the vertical angle of your smartphone.
- **360° Balanced Handle:** Provides additional rotational flexibility.

Three Usage Modes



Phone Holder



Selfie Stick



Tripod



Image: Visual representations of the multi-angle shooting features, detailing the 360-degree horizontal rotation and 270-degree vertical tilt of the phone holder on the Smart M3 tripod.

6.5 Usage Modes

The Smart M3 can be used in three primary modes:

- **Desktop Stand:** Compact mode for stable placement on flat surfaces.
- **Extended Selfie Mode:** Use the extended pole for wider selfie shots.
- **Floor Tripod Mode:** Fully extend the pole and legs for stable, elevated recording.



Image: A graphic depicting the three versatile usage modes of the Smart M3: as a compact phone holder for desktops, an extended selfie stick, and a full-height tripod.

7. MAINTENANCE

- Clean the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Store the tripod in a cool, dry place when not in use.
- Ensure the remote control is securely stored in its slot to prevent loss.

8. TROUBLESHOOTING

- **Device not powering on:** Ensure the device is fully charged using the provided USB-C cable.
- **AI Face Tracking not working:** Check for sufficient lighting. Ensure your face is clearly visible to the AI tracking camera. Avoid rapid movements that might cause the tracker to lose focus.
- **Remote Control not connecting:** Verify that the remote's battery is functional and that Bluetooth is enabled on your smartphone. Re-pair the remote if necessary.
- **Tripod instability:** Ensure the four legs are fully extended and placed on a flat, stable surface. Avoid using in strong winds.

9. SPECIFICATIONS

Feature	Specification
Product Dimensions	1.77 x 1.57 x 57 inches
Item Weight	1.08 pounds (0.49 Kilograms)
Batteries	1 Lithium Ion battery required (included)
Manufacturer	AOCHUAN
Brand	AOCHUAN
Color	Black
Compatible Devices	Smartphone
Material	Aluminum

Maximum Height	57 Inches
Tripod Head Type	Pan Heads
Number of Leg Sections	4
Folded Size	12.41 inches

10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided on the product packaging or visit the official AOCHUAN website. Keep your purchase receipt for warranty claims.

© 2025 AOCHUAN. All rights reserved.

Related Documents - Smart M3

 <p>MN-S620W Gimbal Selfie Stick Tripod</p> <p>EN JP DE IT ES FR</p>	<p><u>AOCHUAN S620W M1 Pro Gimbal Selfie Stick Tripod User Manual</u></p> <p>Comprehensive user manual for the AOCHUAN S620W M1 Pro Gimbal Selfie Stick Tripod, detailing product features, setup, modes, charging, warranty, and specifications for enhanced mobile content creation.</p>
 <p>Smart X</p>	<p><u>AOCHUAN Smart X Gimbal Stabilizer User Guide</u></p> <p>Comprehensive user guide for the AOCHUAN Smart X Gimbal Stabilizer, covering product features, setup, operation, app integration, and technical specifications. Learn how to unfold, fold, charge, and utilize the various modes and functions of your smartphone gimbal for professional-quality video and photography.</p>
 <p>Smart XE</p>	<p><u>AOCHUAN Smart XE Gimbal User Manual and Product Information</u></p> <p>Comprehensive guide to the AOCHUAN Smart XE smartphone gimbal, covering product features, setup, operation, charging, specifications, and warranty information. Learn how to unfold, fold, and operate the gimbal for stable video recording.</p>

 SMART S2	<p><u>AOCHUAN Smart S2 3-Axis Smartphone Gimbal Stabilizer User Manual</u></p> <p>Comprehensive guide to the AOCHUAN Smart S2 3-axis smartphone gimbal stabilizer, covering product features, operation, microphone instructions, charging, specifications, and warranty.</p>
 Smart XE <small>EN JP DE IT ES FR</small>	<p><u>AOCHUAN Smart XE Gimbal Stabilizer User Manual and Product Information</u></p> <p>Explore the features and specifications of the AOCHUAN Smart XE 3-Axis Gimbal Stabilizer for smartphones. This guide covers product details, operation, charging, and warranty terms.</p>
 Smart X PRO <small>EN JP DE IT ES FR RU</small>	<p><u>AOCHUAN Smart X Pro Gimbal Stabilizer User Manual</u></p> <p>Explore the features and operation of the AOCHUAN Smart X Pro, a 3-axis smartphone gimbal stabilizer. This guide covers product setup, app integration, battery management, and technical specifications.</p>