



[Manuals.plus](#) /

› [Flamaker](#) /

› Flamaker Acacia Wood Patio Rocking Chair Set (Model: porchchair123) Instruction Manual

Flamaker porchchair123

Flamaker Acacia Wood Patio Rocking Chair Set Instruction Manual

Model: porchchair123

INTRODUCTION

Welcome to your new Flamaker Acacia Wood Patio Rocking Chair Set. This manual provides detailed instructions for assembly, safe operation, and maintenance to ensure long-lasting enjoyment of your chairs. Crafted from premium acacia hardwood, these chairs offer durability and ergonomic comfort for both indoor and outdoor use.



Figure 1: Flamaker Acacia Wood Patio Rocking Chair Set

IMPORTANT SAFETY INFORMATION

- Do not exceed the maximum weight capacity of 300 lbs per chair.
- Store chairs indoors or cover them during extreme weather conditions (e.g., heavy rain, snow, strong winds) to prevent damage and prolong product life.
- Use caution when rocking to avoid sudden tipping. Ensure the chair is placed on a stable, level surface.
- Keep sharp objects away from the chair's surface to prevent scratches or damage.
- Regularly inspect all fasteners and connections to ensure they are secure. Tighten if necessary.

PACKAGE CONTENTS

Your Flamaker Acacia Wood Patio Rocking Chair Set includes the following components for two chairs:

- Chair Backrests (2)

- Chair Seats (2)
- Left Armrests (2)
- Right Armrests (2)
- Front Legs with Rockers (2)
- Rear Legs with Rockers (2)
- Crossbars/Support pieces (various, as per design)
- Hardware Pack (screws, bolts, Allen wrench)
- Instruction Manual (this document)

SETUP AND ASSEMBLY

The Flamaker Acacia Wood Patio Rocking Chair is designed for easy assembly, with approximately 80% of the chair pre-assembled. Follow these steps for quick setup:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent scratches. Verify all components listed in the "Package Contents" section are present.
2. **Initial Assembly:** Attach the armrests to the seat and backrest sections. *Important: Do not fully tighten any screws until all parts are loosely assembled.* This allows for proper alignment.
3. **Attach Rocker Base:** Connect the pre-assembled rocker bases (front and rear legs) to the main chair frame.
4. **Final Tightening:** Once all components are in place and aligned, gradually tighten all screws and bolts using the provided Allen wrench. Ensure all connections are secure.



Figure 2: Assembly Diagram for Flamaker Rocking Chair

OPERATING INSTRUCTIONS

Your Flamaker rocking chair is designed for comfortable and stable rocking.

- **Seating:** Sit centrally in the chair, ensuring your weight is evenly distributed.
- **Rocking Motion:** Gently push off with your feet to initiate a smooth rocking motion. The engineered swing-base provides a controlled and stable rock.
- **Foot Support:** Utilize the footboard support for added comfort and stability while rocking.
- **Armrests:** The wide armrests are designed for ultimate comfort and support.

Natural Acacia Wood
ERGONOMIC DESIGN



Breathable
Natural Comfort



Sticky & Sweaty
in Heat



Anti-overall
Gentle rocking



Easy Tipping



Elegant Real
Wood Grain



Artificial
Wood Print



Figure 3: Ergonomic Design Features



Figure 4: Enjoying the Rocking Chairs

CARE AND MAINTENANCE

To ensure the longevity and appearance of your Flamaker Acacia Wood Patio Rocking Chair, follow these care guidelines:

- **Cleaning:** Wipe down the chairs regularly with a soft, damp cloth to remove dust and dirt. For stubborn stains, use a mild soap solution and rinse thoroughly.
- **Weather Protection:** While the acacia wood is durable, it is recommended to store the chairs indoors or cover them during prolonged periods of extreme weather, such as heavy rain, snow, or intense sunlight, to prevent fading and wood degradation.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the wood finish.
- **Inspect Fasteners:** Periodically check all screws and bolts and tighten them if they have become loose.
- **Wood Treatment:** To maintain the wood's natural beauty and protect it from the elements, consider applying a suitable outdoor wood sealant or oil annually.

TROUBLESHOOTING

- **Squeaking Noise:** If the chair makes squeaking noises, check all assembly points. Loosen and re-tighten screws, or apply a small amount of silicone lubricant to the joints if necessary.
- **Instability/Wobbling:** Ensure the chair is placed on a flat, level surface. Verify all fasteners are securely tightened. If the issue persists, disassemble and reassemble the chair, ensuring all parts are correctly aligned before tightening.
- **Fading/Discoloration:** Exposure to direct sunlight over extended periods can cause wood to fade. Regular application of a UV-protective wood sealant can help mitigate this.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Flamaker
Color	White
Material	Acacia Wood
Product Dimensions (D x W x H)	34"D x 27.2"W x 44"H
Item Weight	40.12 Pounds
Maximum Weight Recommendation	300 Pounds
Indoor Outdoor Usage	Outdoor
Model Name	porchchair
Model Number	porchchair123
Required Assembly	Yes
Back Style	High Back
Arm Style	Flared
Seat Height	30.5 Inches
Seat Depth	20.3 inches
Seat Length	21.3 Inches

7 PARTS 3 STEPS 15 MINS

80%
Assembled

More Time for Rocking Moment

**EASY
INSTALLATION**

step 1

step 2

step 3

Figure 5: Product Dimensions

WARRANTY INFORMATION

No specific warranty duration or terms are provided in the product details. Please refer to the manufacturer's official website or contact Flamaker customer service for detailed warranty information.

CUSTOMER SUPPORT

For further assistance, questions, or to report any issues with your Flamaker Acacia Wood Patio Rocking Chair Set, please contact Flamaker customer service through their official website or the retailer where the product was purchased.

Visit the Flamaker Store: [Flamaker Official Store](#)

