

Lamshaw 18mm Silicone Smartwatch Bands

Lamshaw 18mm Silicone Smartwatch Bands Instruction Manual

Model: 18mm Silicone Smartwatch Bands

Brand: Lamshaw

INTRODUCTION

This instruction manual provides guidance for the proper installation, use, and maintenance of your Lamshaw 18mm Silicone Smartwatch Bands. These bands are designed for comfort and durability, suitable for various activities and daily wear.

COMPATIBILITY

These smartwatch bands are compatible with the following 1.27-inch smartwatches:

- FQQ DR06
- TOOBUR DR06
- YMZ DR03
- KIBFLE DR03

Before purchasing or installing, please measure the width of your smartwatch's original strap to ensure it requires an 18mm band width.

PACKAGE CONTENTS

Your package typically includes:

- Lamshaw 18mm Silicone Smartwatch Band(s)
- Quick Release Spring Pins (pre-installed or included separately)

SETUP AND INSTALLATION

Installing your Lamshaw smartwatch band is a quick and tool-free process thanks to the integrated quick-release spring bars.

Step 1: Remove Existing Band (if applicable)


Locate the quick-release lever on your current smartwatch band. Slide the lever inward to detach the band from the watch lug. Repeat this process for the other side of the band.

Step 2: Attach New Band

Identify the top and bottom sections of your new Lamshaw band. Each section has a quick-release spring bar.

1. Insert one end of the quick-release spring bar into the corresponding watch lug hole.
2. While holding the band, slide the quick-release lever inward. This retracts the other end of the spring bar.
3. Position the retracted end of the spring bar into the opposite watch lug hole.
4. Release the lever, ensuring both ends of the spring bar are securely seated in the watch lug holes.
5. Gently tug on the band to confirm it is securely fastened and does not detach.
6. Repeat this process for the other band section.

High Quality with Elegant Design



Stainless Steel Buckle



Reinforced Spring Pins

Image: Detailed view of the smartwatch band components, including the stainless steel buckle and reinforced quick-release spring pins, illustrating the attachment mechanism.

Note: Ensure the band is fully seated and locked into the watch lugs before wearing to prevent accidental detachment.

OPERATING AND USAGE

Once installed, adjust the band to a comfortable fit on your wrist. The silicone material is designed to be flexible and skin-friendly for extended wear.

Wearing the Smartwatch

Place the smartwatch on your wrist and thread the band through the stainless steel buckle. Secure the buckle pin into one of the adjustment holes to achieve a snug yet comfortable fit.

Tip: A proper fit ensures accurate heart rate monitoring (if applicable to your smartwatch) and prevents the watch from sliding around your wrist during activities.



Image: A person wearing a black Lamshaw smartwatch band while using a laptop, illustrating the band's suitability for daily activities.



Image: A person wearing a blue Lamshaw smartwatch band outdoors, highlighting its suitability for active lifestyles.

MAINTENANCE AND CARE

To ensure the longevity and hygiene of your silicone smartwatch bands, follow these care instructions:

- **Cleaning:** Hand wash the band with mild soap and warm water. Gently rub the surface to remove dirt and oils.
- **Drying:** Allow the band to air dry completely before reattaching it to your smartwatch or wearing it. Avoid using direct heat sources for drying.
- **Avoid Chemicals:** Do not use harsh chemicals, abrasive cleaners, or strong solvents, as these can damage the silicone material and cause discoloration.
- **Temperature:** Avoid exposing the band to high heat or direct prolonged sunlight, which can cause discoloration, material degradation, or loss of flexibility.

Regular cleaning helps prevent skin irritation and maintains the band's appearance and feel.

TROUBLESHOOTING

Band does not fit my watch.

Ensure your smartwatch requires an 18mm band. These bands are specifically designed for 1.27-inch smartwatches compatible with 18mm quick-release pins. Please verify your watch's lug width before purchasing.

Band feels loose or uncomfortable.

Adjust the buckle to a different hole for a more secure or comfortable fit. The band should be snug enough to stay in place but not so tight as to restrict circulation.

Band detaches unexpectedly.

Verify that the quick-release spring pins are fully engaged in the watch lugs. Gently tug on the band after installation to confirm it is securely locked. If the issue persists, inspect the spring pins for damage or ensure they are correctly installed.

SPECIFICATIONS

Feature	Detail
Material	Premium Soft Silicone
Band Width	18mm
Buckle Material	Stainless Steel
Compatibility	FQQ DR06, TOOBUR DR06, YMZ DR03, KIBFLE DR03 (1.27-inch smartwatches)
Fastening Mechanism	Quick Release Spring Pins

SUPPORT

For further assistance or inquiries regarding your Lamshaw smartwatch bands, please contact the manufacturer or your retailer through their official support channels.