

## LABIGO EM-323

# LABIGO Handheld Steam Cleaner

MODEL: EM-323

Brand: LABIGO

## Introduction

Thank you for choosing the LABIGO Handheld Steam Cleaner, Model EM-323. This multi-purpose pressurized natural cleaning steamer is designed to provide efficient and chemical-free cleaning for various surfaces in your home, car, and for clothes. Please read this manual thoroughly before operating the device to ensure safe and optimal performance.

## Important Safety Instructions

**WARNING:** When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and personal injury.

- Always ensure the steam cleaner is unplugged before filling or emptying the water tank.
- Do not open the water tank cap while the unit is pressurized or hot. Allow the unit to cool down completely before refilling.
- Keep hands and face away from the steam nozzle during operation. Steam is extremely hot and can cause severe burns.
- Do not direct steam at people, pets, or electrical appliances.
- Use only tap water. Do not add cleaning solutions, perfumes, or other chemicals to the water tank, as this can damage the unit and void the warranty.
- Ensure the power cord is not damaged and avoid kinking or stretching it.
- Always supervise children and individuals with reduced physical, sensory, or mental capabilities when the appliance is in use.
- This appliance is for household use only. Do not use outdoors.
- The unit features overheating protection. If the unit overheats, it will automatically shut off. Unplug and allow it to cool before resuming use.

# POWERFUL HIGH-TEMPERATURE STEAM CLEANER



**3-5 Mins**  
Fast Heating



**UP TO  
230°F (110°C)**



**Image Description:** A close-up of the LABIGO Handheld Steam Cleaner emitting powerful, high-temperature steam, illustrating its fast heating time of 3-5 minutes and steam temperature up to 230°F (110°C).

## Package Contents

Your LABIGO Handheld Steam Cleaner comes with a comprehensive set of accessories to tackle various cleaning tasks. Please ensure all items are present:

- LABIGO Handheld Steam Cleaner Unit
- Long Spray Nozzle
- Round Nylon Brush (for tiles, grout, etc.)
- Bent Nozzle (for hard-to-reach areas)
- Fabric/Clothing Steaming Accessory (with cleaning cloth)
- Window/Door Cleaning Accessory
- Scraper Tool (for tough, stuck-on grime)

- Flexible Extension Hose
- Measuring Cup
- Funnel
- Small Brushes (various sizes for crevices)
- Cleaning Cloths

# 13-IN-1 MULTIFUNCTIONAL ACCESSORIES FOR WHOLE CLEAN



**Image Description:** An overview of the LABIGO Handheld Steam Cleaner and its 13 multifunctional accessories, demonstrating its versatility for cleaning various surfaces like toilets, windows, furniture, kitchen areas, bathrooms, and tyres.

## Setup

1. **Prepare the Unit:** Ensure the steam cleaner is unplugged and cool.
2. **Fill Water Tank:** Unscrew the safety cap. Use the provided measuring cup and funnel to fill the water tank with up to 350mL of tap water. Do not overfill. Securely screw the safety cap back on.
3. **Attach Desired Accessory:** Select the appropriate nozzle or brush for your cleaning task. Attach it firmly to the main unit. For extended reach, connect the flexible extension hose first, then attach the desired accessory to the

hose.

4. **Power On:** Plug the steam cleaner into a grounded electrical outlet. The indicator light will illuminate, signaling that the unit is heating up.

Your browser does not support the video tag.

**Video Description:** This video demonstrates the unboxing of the LABIGO Handheld Steam Cleaner, showcasing its various attachments and how to connect them. It also illustrates the process of filling the water tank with tap water using the provided measuring cup and funnel.

## Operating Instructions

---

1. **Heating Time:** Allow the unit to heat for approximately 3-5 minutes. The indicator light will change or turn off once the optimal steam temperature is reached.
2. **Steam Release:** Press and hold the steam button to release steam. Direct the steam towards the surface you wish to clean.
3. **Continuous Cleaning:** The 350mL tank provides 8-12 minutes of continuous steam cleaning.
4. **Cleaning Surfaces:**
  - **Stovetops/Hard Surfaces:** Use the scraper tool or a small brush attachment to loosen and remove stuck-on food or grime.
  - **Fabric/Upholstery/Clothes:** Attach the fabric steaming accessory with a cleaning cloth. Hold the steamer a few inches away from the fabric and move it slowly to remove wrinkles or refresh the material.
  - **Grout/Crevices:** Use the round nylon brush or bent nozzle to target narrow spaces and stubborn dirt.
5. **After Use:** Release any remaining pressure by holding the steam button until no more steam is emitted. Unplug the unit and allow it to cool completely before storing.

**BEFORE** **After**

**EFFICIENT STEAM CLEANING**

Clean **99.9%** of Dirt & Grease

The image shows a woman in a kitchen wearing a light-colored shirt, a striped apron, and teal gloves. She is using a white handheld steam cleaner with a black nozzle to clean a stainless steel stovetop. The stovetop is covered in brown grease and dirt. The steam cleaner is emitting a large amount of steam. In the background, there is a kitchen sink with a chrome faucet. Two circular insets in the top left corner show the 'BEFORE' and 'After' results of the cleaning process. The 'BEFORE' inset shows the greasy stovetop, and the 'After' inset shows the clean stovetop. The text 'EFFICIENT STEAM CLEANING' is written in large blue letters, and 'Clean 99.9% of Dirt & Grease' is written below it in black and orange text.

**Image Description:** A user effectively cleaning a stovetop with the LABIGO Handheld Steam Cleaner, highlighting the "before" and "after" results of its efficient steam cleaning capabilities.

# Fabric & Clothing Steaming Tool



**Image Description:** A woman demonstrating the use of the LABIGO Handheld Steam Cleaner with the fabric attachment to steam wrinkles from a white t-shirt, illustrating its function as a fabric and clothing steaming tool.

## Maintenance

- **Empty Water Tank:** After each use, ensure the unit is cool and depressurized, then carefully empty any remaining water from the tank.
- **Clean Accessories:** Wash all removable attachments with warm, soapy water and rinse thoroughly. Allow them to air dry completely before storing.
- **Wipe Down Unit:** Wipe the exterior of the steam cleaner with a damp cloth. Do not immerse the unit in water.
- **Descaling (Monthly):** To prevent mineral buildup, especially in hard water areas, descale the unit monthly. Mix a solution of equal parts white vinegar and water. Fill the tank with this solution (do not exceed 350mL) and let it sit for 30 minutes. Then, operate the steamer until the tank is empty. Rinse the tank thoroughly with fresh water afterward.
- **Storage:** Store the steam cleaner and its accessories in a cool, dry place, away from direct sunlight and out of reach of children.

## Troubleshooting

---

Problem	Possible Cause	Solution
No steam or low steam output.	Water tank is empty or low. Unit not heated sufficiently. Mineral buildup.	Refill water tank. Allow 3-5 minutes for heating. Perform descaling procedure.
Water leaking from nozzle.	Accessory not properly attached. Unit not fully heated.	Ensure accessory is securely attached. Allow unit to fully heat before use.
Unit not turning on.	Not plugged in. Power outlet issue. Overheating protection activated.	Check power connection. Try a different outlet. Unplug and allow to cool for 30 minutes.

## Specifications

---

- **Brand:** LABIGO
- **Model Name:** EM-323
- **Tank Volume:** 350 Milliliters
- **Form Factor:** Handheld
- **Heat Time:** 3-5 Minutes
- **Continuous Steam Time:** 8-12 Minutes
- **Power Source:** Electric
- **Cord Length:** 9.8 feet
- **Surface Recommendation:** Floor, Sink, Counter Top, Upholstery, Window, Grout, Carpet

## Warranty and Support

---

For warranty information or technical support, please refer to the product packaging or contact LABIGO customer service directly. Keep your purchase receipt as proof of purchase.

