

## CUTEBEE CQB-CWGB404

# CUTEBEE Bach Strings Book Nook Miniature Kit Instruction Manual

Model: CQB-CWGB404

## 1. INTRODUCTION

Thank you for choosing the CUTEBEE Bach Strings Book Nook Miniature Kit. This DIY kit allows you to construct a detailed miniature musical instrument shop, designed to fit seamlessly into your bookshelf or serve as a standalone decorative piece. It features intricate laser-cut wooden components and LED lighting to bring the scene to life.



Overview of the CUTEBEE Bach Strings Book Nook Kit, highlighting key features like the dust cover, LED light, estimated assembly time, and piece count.

## 2. WHAT'S IN THE BOX

Your CUTEBEE Bach Strings Book Nook Miniature Kit includes the following components:

- Laser-cut wooden sheets with 285 pieces for assembly.

- LED lighting components.
- Dust cover.
- Illustrated instruction manual.



Image illustrating the main components included in the kit.

### 3. TOOLS REQUIRED (NOT INCLUDED)

---

To complete the assembly of your Book Nook, you will need the following items, which are not supplied in the kit:

- 2 x AAA batteries (for LED lighting).
- Craft glue (wood glue or quick-drying adhesive recommended).
- Small scissors or precision knife.
- Tweezers (recommended for handling small parts).

Please ensure you have these tools ready before beginning assembly.

### 4. ASSEMBLY INSTRUCTIONS

---


The assembly process typically takes 4-6 hours. Follow the detailed, illustrated instructions provided in your kit for a smooth building experience. The laser-cut pieces are designed for a precise fit.

1. **Preparation:** Carefully unpack all components. Identify the wooden sheets and the instruction manual. Ensure you have all necessary external tools (batteries, glue, scissors/knife, tweezers).
2. **Detaching Pieces:** Gently detach the laser-cut pieces from their wooden sheets. Use a precision knife or tweezers for smaller, more delicate parts to prevent breakage.
3. **Following the Manual:** Refer to the step-by-step illustrated instructions. Each step will guide you on which pieces to use and how to connect them. Pay close attention to the diagrams.
4. **Gluing:** Apply a small amount of craft glue to the designated connection points. Hold pieces firmly together until the glue sets. For a stronger bond, allow sufficient drying time between steps.
5. **Wiring the LED Lights:** Follow the specific instructions for installing the LED lighting system. Ensure all connections are secure and correctly oriented. Insert the AAA batteries into the battery compartment once the wiring is complete.
6. **Adding Details:** Once the main structure is complete, add the smaller decorative elements and miniature instruments as per the instructions.

7. **Final Touches:** Place the dust cover over the assembled book nook to protect the intricate details.



A view of the fully assembled Bach Strings Book Nook, showcasing its intricate details.



Detailed view of the interior, emphasizing the 'Arc Light Flow' and various miniature instruments.

## Two-tier Visualiser

From the point of view of space utilisation, the double-storey structure effectively increases the display area and enables more instruments to be displayed at the same time.



The 'Two-tier Visualiser' design, allowing for a comprehensive display of miniature instruments.



The intricate 'Arched Cabinets' providing display and storage for the miniature instruments.

## 5. OPERATING INSTRUCTIONS

---

Your CUTEBEE Bach Strings Book Nook features integrated LED lighting for enhanced display.

- **Powering On/Off:** The LED lights are controlled by a touch switch. Gently touch the designated area (as indicated in the assembly manual or on the product itself) to turn the lights on or off.
- **Battery Replacement:** When the lights dim or stop working, replace the 2 AAA batteries in the battery compartment. Ensure correct polarity (+/-).



Comparison of the Book Nook in daylight and illuminated at night, showcasing the LED lighting effect.

## 6. MAINTENANCE

To ensure the longevity and appearance of your Book Nook:

- **Dust Protection:** Always use the provided dust cover when the Book Nook is not being actively viewed or handled. This protects the delicate components from dust accumulation.
- **Cleaning:** Gently wipe the exterior and dust cover with a soft, dry cloth. For interior dusting, use a soft brush or compressed air to avoid damaging small parts. Do not use liquid cleaners.
- **Storage:** Store the Book Nook in a cool, dry place away from direct sunlight and extreme temperatures to prevent warping or fading of the wooden components.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
LED lights do not turn on.	<ol style="list-style-type: none"> <li>1. Batteries are dead or incorrectly inserted.</li> <li>2. Loose wiring connection.</li> </ol>	<ol style="list-style-type: none"> <li>1. Replace AAA batteries, ensuring correct polarity.</li> <li>2. Check all wiring connections as per the assembly manual.</li> </ol>
Pieces do not fit together.	<ol style="list-style-type: none"> <li>1. Incorrect piece selection.</li> <li>2. Excess glue or debris in connection points.</li> </ol>	<ol style="list-style-type: none"> <li>1. Double-check the instruction manual for the correct pieces.</li> <li>2. Carefully remove any obstructions from the connection points.</li> </ol>
Small parts break during assembly.	Excessive force used.	Handle delicate parts with care, use tweezers for precision. If a piece is broken, attempt to glue it back together.

If you encounter any issues not listed here or require further assistance, please contact CUTEBEE customer support.

## 8. SPECIFICATIONS

Feature	Detail
Model Number	CQB-CWGB404
Product Dimensions (L x W x H)	21 x 13 x 17 cm (8.27 x 5.12 x 6.69 inches)
Weight	620 grams
Material	Wood
Number of Pieces	285
Recommended Age	Adult (14 years and older)
Power Source (Lights)	2 x AAA Batteries (not included)
Assembly Time	Approx. 4-6 hours

## 9. PRODUCT VIDEO

---

Your browser does not support the video tag.

This video provides a visual overview of the CUTEBEE Bach Strings Book Nook, showcasing its intricate details, assembly process, and illuminated appearance.

## 10. WARRANTY AND SUPPORT

---

CUTEBEE products are designed for quality and enjoyment. If you have any questions, require replacement parts, or experience any issues with your kit, please contact CUTEBEE customer support through the retailer where you purchased the product. Please retain your proof of purchase for warranty claims.