

LIULINREST 10' x 30' Canopy Tent

LIULINREST 10' x 30' Canopy Tent Instruction Manual

Model: 10' x 30' Canopy Tent

1. SAFETY INFORMATION

Please read and understand all safety instructions before assembling and using the canopy tent. Failure to follow these instructions may result in injury or damage to the product.

- Do not use the tent in windy or rainy conditions.
- Always fix the ropes and ground nails securely when using the tent.
- Reinforce the base for added stability, especially in conditions with potential wind.
- Ensure the tent is properly anchored to prevent wind-induced movement.
- Keep all flame and heat sources away from the tent fabric.
- Do not hang heavy objects from the tent frame.

2. PRODUCT OVERVIEW

The LIULINREST 10' x 30' Canopy Tent is designed for outdoor events, providing shade and protection from light rain. It features a sturdy metal frame and removable sidewalls for versatile use.

2.1 Components

The canopy tent includes the following main components:

- Waterproof Fabric Cloth (Canopy Top)
- Steel Tubes (Frame Poles)
- Transparent Plastic Film (Window Sidewalls)
- Wind Ropes and Ground Nails (Anchoring Kit)
- Strengthened Connectors (Frame Joints)
- Sturdy Bases (Foot Plates)

LIULINREST PARTY TENT




Image: Detailed view of canopy tent components.

2.2 Removable Sidewalls

The tent comes with 5 removable sidewalls, allowing for flexible configurations:

- **Fully Enclosed:** All sidewalls attached for maximum privacy and weather protection.
- **Semi-Open:** Some sidewalls removed for partial openness and ventilation.
- **Fully Open:** All sidewalls removed for an open canopy design.

STURDY FRAME STRUCTURE



Reinforced steel pipe with elegant white paint coating.



Strengthened Connectors can be more convenient to assemble.



Transparent plastic film can better see the scenery and prevent rain.



Wind ropes with ground nails and sturdy bases add more stability.

3. SETUP INSTRUCTIONS


Assembly typically requires 3 people and takes approximately 30-40 minutes. Follow these steps for proper setup:

1. **Step 1: Assemble the Base Frame.** Lay out all frame poles and connectors. Connect the horizontal and vertical poles to form the rectangular base of the tent.
2. **Step 2: Attach Roof Poles.** Connect the roof support poles to the base frame using the appropriate connectors.
3. **Step 3: Secure the Canopy Top.** Drape the waterproof fabric cloth over the assembled frame. Ensure it is centered and evenly distributed.
4. **Step 4: Raise the Frame.** With assistance, carefully lift the frame to its full height.
5. **Step 5: Anchor the Tent.** Use the provided ground stakes and wind ropes to firmly anchor the tent to the ground. For additional stability, especially in windy conditions, consider using heavy-duty stabilizing weights.
6. **Step 6: Attach Sidewalls.** Secure the removable sidewalls to the frame using the attached fasteners.

Details



Transparent Plastic Film



waterproof Fabric Cloth



Steel Tubes



Wind Ropes and
Ground Nails



Strengthened Connectors



Sturdy Bases

3.1 Anchoring and Reinforcement

Proper anchoring is crucial for the stability of the canopy tent. Always use ground stakes and wind ropes. For enhanced stability, especially in areas prone to wind, consider additional weights or anchors.

5 Removable Sidewalls




Good Ventilation



Premium Vision



Multi Application



Fully Enclosed



Semi Open



Fully Open

Image: Double Reinforcement using ground stakes and ropes.

3.2 Assembly Video Guide

For a visual guide on assembling your LIULINREST Canopy Tent, please watch the video below:

Your browser does not support the video tag.

Video: Official LIULINREST Canopy Tent assembly guide. This video demonstrates the step-by-step process of setting up the tent frame and attaching the canopy.

4. OPERATING INSTRUCTIONS

Once assembled, the canopy tent is ready for use. Ensure all anchors are secure before leaving the tent unattended.

4.1 Sidewall Management

- **Attaching Sidewalls:** Use the hook-and-loop fasteners or ties provided to secure the sidewalls to the tent frame.
- **Removing Sidewalls:** Detach the fasteners to remove sidewalls as needed for ventilation or an open-air setup.
- **Window Panels:** The transparent plastic film windows allow light and visibility while providing protection.

4.2 Usage Environment

This canopy tent is suitable for various outdoor activities such as parties, events, birthdays, weddings, backyard gatherings, and picnics. It provides sunlight and light rain protection.



Suitable for Various Outdoor Activities



Outdoor
Lawn



Backyard
Gathering



Weeding
Party



Camping
Gathering



Image: Canopy tent suitable for various occasions.

5. MAINTENANCE

Regular maintenance will extend the life of your canopy tent.

- **Cleaning:** Clean the fabric with mild soap and water. Do not use harsh chemicals or abrasive cleaners. Allow the fabric to air dry completely before storage.
- **Frame Inspection:** Periodically check all frame poles and connectors for any signs of damage, bending, or corrosion. Replace damaged parts immediately.
- **Storage:** When not in use, disassemble the tent and store all components in a dry, cool place, away from direct sunlight and extreme temperatures. Ensure the fabric is completely dry to prevent mold and mildew.
- **Anchoring:** Regularly inspect ground stakes and ropes for wear and tear. Replace as needed to maintain secure anchoring.

6. TROUBLESHOOTING


Here are solutions to common issues you might encounter:

Problem	Possible Cause	Solution
Tent instability / collapses	Insufficient anchoring; strong winds; damaged frame poles/connectors.	Ensure all ground nails and ropes are securely fastened. Add extra weights if necessary. Do not use in strong winds. Inspect and replace damaged frame parts.
Water leakage	Heavy rain exceeding water resistance; fabric damage; improper canopy installation.	The tent is water repellent, not fully waterproof for heavy rain. Avoid use in heavy rain. Check canopy for tears and ensure it is taut and properly fitted.
Difficulty assembling frame	Incorrect pole/connector matching; insufficient manpower.	Refer to the assembly diagram and video. Ensure correct parts are used. Assembly is easier with 3 people.
Sidewalls not fitting properly	Incorrect orientation; frame not fully extended.	Ensure sidewalls are oriented correctly. Verify the frame is fully assembled and taut.

7. SPECIFICATIONS

Key specifications for the LIULINREST 10' x 30' Canopy Tent:

- **Brand:** LIULINREST
- **Size:** 10' x 30'
- **Color:** White
- **Frame Material:** Metal (Reinforced steel pipe with elegant white paint coating)
- **Water Resistance Level:** Water Repellent
- **Floor Area:** 300 square feet
- **Recommended Uses:** Camping, Outdoor Activities, Picnic, Social Gathering
- **Coverage:** Sunlight and light rain protection with removable sidewalls
- **Capacity:** Approximately 30 people
- **Assembly Time:** 30-40 minutes by 3 people
- **Weight:** 39 lbs
- **UPC:** 762849210025
- **ASIN:** B0FBG5YLT1



High Reliability
Stable & Sunshade



Multi Application
Party, Camping...

Image: Product Parameters.

8. WARRANTY AND SUPPORT

Specific warranty details are not provided in the product information. For warranty claims or technical support, please contact the seller or manufacturer directly through your purchase platform.

When contacting support, please have your product model number (10' x 30' Canopy Tent) and ASIN (B0FBG5YLT1) available for faster service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FBG5YLT1>

More documents and user manuals: <https://manuals.plus/>