

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Retevis](#) /

› [Retevis H777D Walkie Talkie User Manual](#)

Retevis H777D

Retevis H777D Walkie Talkie User Manual

Model: H777D

1. INTRODUCTION

The Retevis H777D is a handheld FRS two-way radio designed for reliable communication across various environments. Featuring an LCD display, USB-C charging, and a 1200 mAh battery, it offers extended use and clear operation. This manual provides detailed instructions for setting up, operating, and maintaining your H777D walkie talkie.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package. If any items are missing or damaged, please contact your retailer.

- H777D Walkie Talkie (x6)
- 1200mAh Battery (x6)
- Charge Base (x6)
- Type-C Cable (x6)
- Belt Clip & Strap (x6)
- Adapter (x3)
- User Manual (x1)

Package Includes



H777D walkie talkie *6



Battery *6



Base charger *6



Type-C cable *6



Belt clip *6



User manual *1



Adapter *3

Image: Contents of the Retevis H777D Walkie Talkie package, showing six radios, batteries, charging bases, USB-C cables, and belt clips.

3. PRODUCT OVERVIEW

The Retevis H777D features an intuitive design with an LCD screen for clear status updates and easily accessible controls.

3.1 Key Components

- **Antenna:** For transmitting and receiving signals.
- **Power/Volume Knob:** Turns the radio on/off and adjusts volume.
- **Channel Switch:** Selects the operating channel.
- **LED Indicator:** Shows transmission (red) or reception (green) status.
- **Speaker/Microphone Jack:** For connecting external audio accessories.
- **PTT Button (Push-to-Talk):** Press and hold to transmit.
- **Side Key 1:** Programmable function, default for Emergency Alarm.
- **Side Key 2:** Programmable function, default for Flashlight/VOX activation.

- **LCD Screen:** Displays channel, frequency, battery status, signal strength, and other settings.
- **Menu Button:** Accesses radio settings.
- **Up/Down Buttons:** Navigates menus and adjusts settings.
- **USB-C Port:** For direct charging.

Your browser does not support the video tag.

Video: A detailed overview of the Retevis H777D Walkie Talkie, highlighting its various components and their functions, including the LCD screen, buttons, and ports.

4. SETUP

4.1 Battery Installation and Charging

The H777D walkie talkie uses a 1200mAh Lithium-Ion battery. Ensure the battery is fully charged before first use.

1. Align the battery with the compartment on the back of the radio and slide it into place until it clicks.
2. To charge, place the radio in the charging base or connect a USB-C cable directly to the radio.
3. The LED indicator on the charging base or radio will show charging status (typically red for charging, green for fully charged).



Image: The Retevis H777D Walkie Talkie being charged via its dedicated charging base and directly via a USB-C cable, illustrating dual charging flexibility.

4.2 Power On/Off

Rotate the Power/Volume knob clockwise to turn the radio on. Rotate counter-clockwise until a click is heard to turn it off.

4.3 Quick Pairing Mode

To quickly pair multiple H777D radios:

1. Ensure all radios are on Channel 1.
2. During startup, long-press the Up button on each radio.
3. The radios will enter pairing mode and synchronize their settings.

Quick Pairing Mode

Sync multiple H777D radios instantly for seamless teamwork



Image: Three Retevis H777D walkie talkies demonstrating the quick pairing mode, with blue signal waves indicating connection between them.

Your browser does not support the video tag.

Video: Demonstrates the power on/off sequence and the one-key pairing process for the Retevis H777D walkie talkies.

5. OPERATION

5.1 Basic Communication

1. **Select Channel:** Rotate the Channel Switch to select one of the 16 available channels. Ensure all communicating parties are on the same channel.
2. **Adjust Volume:** Rotate the Power/Volume knob to adjust the listening volume.
3. **Transmit:** Press and hold the PTT button to speak. Speak clearly into the microphone. Release the PTT button to listen.

Effortless Operation

3 Simple Steps to Get Started



Image: A visual guide to the three simple steps for operating the Retevis H777D: turning on, adjusting the channel, and using the PTT button.

5.2 LCD Display

The upgraded LCD screen provides real-time information at a glance, including:

- Signal Strength
- Volume Level
- Current Channel and Frequency
- Battery Life Indicator
- VOX Status
- CTCSS/DCS Status

Upgraded to LCD Display



Image: The Retevis H777D's LCD display showing signal strength, volume, channel, and battery life, highlighting its clear and informative interface.

5.3 Advanced Features

• VOX (Voice Operated Exchange):

To enable hands-free communication, long-press Side Key 2. The radio will automatically transmit when it detects your voice. You can adjust VOX sensitivity (1-9 levels) through the menu to suit your environment.



One-key VOX

Long-press Side Key 2 to enable VOX. Right for hands-free kitchen or warehouse use.

Image: A user demonstrating the one-key VOX function on the Retevis H777D, allowing for hands-free communication.

- **Flashlight:**

For illumination, short-press Side Key 2. Short-press twice to activate emergency light mode. This is useful for navigating in low-light conditions.



One-key Illuminate

Short-press Side Key 2 to toggle the flashlight. Suitable for inventory checks or late-night shifts.

Image: The Retevis H777D walkie talkie's flashlight function being used in a dark environment, providing illumination.

- **Emergency Alarm:**

In emergency situations, long-press Side Key 1 to trigger an audible alarm. This alerts others to your location or distress.



One-key Alarm

Long-press Side Key 1 to activate the emergency alarm. Critical for restaurant back-of-house safety.

Image: A person activating the one-key alarm on the Retevis H777D walkie talkie, indicating an emergency situation.

- **Squelch Levels:**

The H777D offers 9 adjustable squelch levels (1-9) to filter out weak signals and background noise, ensuring clearer communication. Access this setting via the menu.



Image: A visual representation of the 1-9 squelch levels feature on the Retevis H777D, indicating noise reduction capabilities.

- **CTCSS/DCS Codes:**

With 50 CTCSS (Continuous Tone-Coded Squelch System) and 210 DCS (Digitally Coded Squelch) options, you can ensure private communication and reduce interference from other users on the same channel. Set these codes through the menu.



Image: A graphic illustrating the CTCSS/DCS feature of the Retevis H777D, symbolizing secure and private communication.

Your browser does not support the video tag.

Video: Demonstrates the functions of the side keys, including channel lock, emergency alarm, flashlight, VOX activation, and adjustment of VOX sensitivity and squelch levels.

6. MAINTENANCE

6.1 Battery Care

- Do not expose batteries to extreme temperatures.
- Charge batteries regularly, even if not in use, to maintain optimal performance.
- Dispose of old batteries according to local regulations.

6.2 Cleaning

- Wipe the radio with a soft, damp cloth.
- Do not use harsh chemicals or abrasive cleaners.
- Ensure the USB-C port cover is securely closed to prevent dust and moisture ingress.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Battery is low or not installed correctly.	Charge the battery or re-install it.
Cannot transmit or receive	Incorrect channel/CTCSS/DCS code, out of range, or low battery.	Verify channel and codes, move closer to other radios, charge battery.
Poor audio quality	Weak signal, high squelch level, or interference.	Adjust squelch level, move to a clearer area, check antenna connection.
VOX not working	VOX disabled or sensitivity too low.	Enable VOX (long-press Side Key 2) and increase sensitivity in menu.

8. SPECIFICATIONS

Feature	Detail
Model	H777D
Tuner Technology	FRS
Number of Channels	16
Frequency Range	462.55-462.725 MHz
Talking Range (Max)	3 Kilometers (approx. 300,000 sq.ft or 30 floors)
Battery Capacity	1200mAh Lithium Ion
Battery Average Life	11 Hours (continuous use), 87 Hours (standby)
Voltage	3.7 Volts (DC)
Special Features	LCD Screen, VOX, Emergency Alarm, Flashlight, USB-C Charging, Adjustable Squelch, CTCSS/DCS
Water Resistance Level	Not Water Resistant
Color	Black
Dimensions (Parcel)	29.6 x 25.3 x 15.8 cm
Weight (Parcel)	1.75 kg

9. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Retevis website. Keep your purchase receipt as proof of purchase.