

[Manuals.plus](#) /

› [POWMUS](#) /

› POWMUS Android 15 Tablet LS1111 User Manual

POWMUS LS1111

POWMUS Android 15 Tablet LS1111 User Manual

Model: LS1111 | Brand: POWMUS

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your POWMUS Android 15 Tablet LS1111. Please read it thoroughly before operating the device and retain it for future reference. The tablet features an 11-inch 2K display, an Octa-Core processor, 36GB RAM, 256GB ROM (expandable up to 2TB), and an 8000mAh battery, supporting 5G WiFi, Bluetooth 5.0, and GPS.



Image: Front view of the POWMUS Android 15 Tablet, showcasing its display.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 11-inch Android 15 Tablet
- Bluetooth Keyboard
- Mouse
- Touch Pen (Stylus)
- Tablet Case
- USB-C Cable
- OTG Cable
- Charger
- User Manual




Image: The POWMUS Android 15 Tablet displayed with its full set of accessories, including the Bluetooth keyboard, mouse, stylus, charging cable, and power adapter.

3. PRODUCT OVERVIEW

Familiarize yourself with the various components and ports of your tablet:




Image: Detailed diagram of the POWMUS Android 15 Tablet, highlighting key features such as the power button, volume

controls, reset button, speakers, front and rear cameras, flash light, Micro SD card slot, and Type-C charging port.

1. **Power ON/OFF:** Press and hold to power on or off. Short press to sleep/wake.
2. **Volume +/-:** Adjust the tablet's audio volume.
3. **Reset:** Small pinhole for factory reset (use a thin pin, only when necessary).
4. **Speakers:** Audio output.
5. **Rear Camera:** 13MP camera for photos and videos.
6. **Front Camera:** 8MP camera for video calls and selfies.
7. **Flash Light:** Provides illumination for the rear camera.
8. **Micro SD Slot:** Insert a Micro SD card for expandable storage (up to 2TB).
9. **Type-C Port:** For charging and data transfer.

4. SETUP

4.1 Initial Power On and Language Selection

1. **Charge the Tablet:** Before first use, connect the tablet to the charger using the provided USB-C cable and power adapter. Ensure the tablet is fully charged.
2. **Power On:** Press and hold the Power ON/OFF button (1) until the POWMUS logo appears on the screen.
3. **Language Selection:** Follow the on-screen prompts to select your preferred language and region.
4. **Wi-Fi Connection:** Connect to a Wi-Fi network to access the internet and complete the setup process.

4.2 Connecting Accessories

Your tablet comes with a Bluetooth keyboard, mouse, and stylus for enhanced productivity.

UNISOC T606

Octa-core Processor

The tablet adopts an Octa-core Unisoc T606 processor based on 12 nm fabrication to deliver enhanced graphics performance and fast processing speed for better multitasking. From work to play, Unisoc T606 multiplies your joy.



1.6GHz
Peak Frequency

A75 High Performance
A55 High Efficiency

12nm Process
Low Consumption

Unrivalled Speed

Optimise the Performance



Data transmission
34%

Power consumption
30%

Storage space
48%

Image: The POWMUS Android 15 Tablet set up with its Bluetooth keyboard and mouse, demonstrating a complete workstation configuration.

- **Bluetooth Keyboard/Mouse:**

- a. Turn on the keyboard/mouse.
- b. On your tablet, go to **Settings > Connected devices > Bluetooth**.
- c. Enable Bluetooth and scan for available devices.
- d. Select the keyboard/mouse from the list and follow pairing instructions.

- **Stylus:** The stylus is generally passive and does not require Bluetooth pairing. Simply use it directly on the screen.

5. OPERATING INSTRUCTIONS

5.1 Basic Navigation

- **Tap:** Select an item or activate a function.
- **Tap and Hold:** Access contextual menus or move icons.
- **Swipe:** Scroll through screens or lists.
- **Pinch:** Zoom in or out on images and web pages.

5.2 Connectivity

- **Wi-Fi:** Access Wi-Fi settings via **Settings > Network & internet > Wi-Fi**
- **Bluetooth:** Manage Bluetooth devices via **Settings > Connected devices > Bluetooth**.
- **GPS:** Enable or disable location services via **Settings > Location**.

5.3 Camera Usage


The tablet features a 13MP rear camera and an 8MP front camera.

- Open the Camera app from the home screen or app drawer.
- Tap the shutter button to take a photo.
- Switch between front and rear cameras using the camera icon.
- Select video mode to record videos.

5.4 Storage Management

Your tablet has 256GB of internal storage, expandable up to 2TB using a Micro SD card.

- To check storage usage, go to **Settings > Storage**.
- Insert a Micro SD card into the Micro SD slot (8) to expand storage.



Optimized Performance for Your Needs

This 11-inch tablet is built for performance, meeting your needs for studying, working, and entertainment

Image: Visual representation of the tablet's storage capabilities, highlighting 36GB RAM, 256GB internal storage, and the option to expand up to 2TB with a TF (Micro SD) card.

5.5 Special Features

- **Split-Screen Mode:** To use two apps simultaneously, open a recent app, tap its icon at the top, and select "Split screen." Choose a second app to open alongside it.
- **Face Unlock:** Set up face unlock for convenient and secure access via **Settings > Security & privacy > Face unlock**.
- **Eye Protection Mode:** Reduce blue light emission for comfortable reading by enabling Eye Protection Mode in Quick Settings or **Settings > Display**.

5.6 Tablet in Action

Watch this video to see the POWMUS Android 15 Tablet in various usage scenarios, including gaming and general navigation.

Your browser does not support the video tag.

Video: A demonstration of the POWMUS Android 15 Tablet's performance and features, including gaming and general user interface interaction.

6. MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid abrasive cleaners or solvents.
- **Battery Care:**
 - Avoid extreme temperatures.
 - Do not let the battery fully discharge frequently.
 - Use only the provided charger or a certified compatible charger.
- **Software Updates:** Regularly check for system updates via **Settings > System > System update** to ensure optimal performance and security.



Image: Illustration of the tablet's 8000mAh battery, detailing estimated usage durations for standby (500 hrs), music playback (35 hrs), streaming video (7 hrs), casual gaming (6 hrs), and web browsing (8 hrs).

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Tablet does not power on.	Low battery; System crash.	Charge the tablet for at least 30 minutes. Press and hold the power button for 10-15 seconds to force restart. If unresponsive, use the reset pinhole.
Touchscreen unresponsive.	Temporary software glitch; Screen protector interference.	Restart the tablet. Ensure the screen is clean and dry. If using a screen protector, ensure it is properly applied and not damaged.
Cannot connect to Wi-Fi.	Incorrect password; Router issue; Tablet Wi-Fi disabled.	Verify Wi-Fi password. Restart your router. Ensure Wi-Fi is enabled in tablet settings. Try connecting to a different network.
Bluetooth device not pairing.	Device not in pairing mode; Out of range; Interference.	Ensure the Bluetooth device is in pairing mode. Bring the device closer to the tablet. Turn off other Bluetooth devices nearby. Restart both devices.
Slow performance.	Too many apps running; Low storage space.	Close unused apps. Clear cache. Uninstall unnecessary apps. Check storage via Settings > Storage and free up space.

8. SPECIFICATIONS

Feature	Detail
Brand	POWMUS
Model Name	LS1111
Operating System	Android 15
Screen Size	11 Inches
Screen Resolution	2000 x 1200 Pixels (2K Display)
Processor	Octa-Core (Unisoc T606, up to 1.6GHz)
Graphics Coprocessor	ARM MaliTM-G57
RAM	36GB (12GB physical + 24GB virtual)
Internal Storage (ROM)	256GB
Expandable Storage	Up to 2TB (Micro SD)
Rear Camera Resolution	13 MP
Front Camera Resolution	8 MP
Battery Capacity	8000mAh
Average Battery Life	6 Hours (usage dependent)
Wireless Type	802.11ac, 802.11b, 802.11g, 802.11n (Dual-band 5G/2.4G WiFi)
Bluetooth	Bluetooth 5.0
Item Weight	1.98 pounds
Product Dimensions (LxWxH)	10.21 x 6.73 x 0.38 inches

9. WARRANTY AND SUPPORT

POWMUS products are designed for reliability and performance. For warranty information, please refer to the warranty card included in your package or visit the official POWMUS website. If you encounter any issues or require technical assistance, please contact POWMUS customer support through the contact details provided on the product packaging or the official website.

Please have your model number (LS1111) and purchase details ready when contacting support.