Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tiffcofio TF-014

TiFFCOFiO Digital Programmable Outlet Timer (Model TF-014)

User Manual

1. Introduction

Thank you for choosing the TiFFCOFiO Digital Programmable Outlet Timer. This device is designed to automate the power supply to your electrical appliances, helping you save energy and enhance convenience in your home or office. Please read this manual carefully before use to ensure proper operation and safety.

Safety Information

- For indoor use only.
- Do not exceed the maximum load rating of the timer.
- Ensure the timer is securely plugged into a grounded outlet.
- Keep away from water and high humidity environments.
- Do not disassemble or attempt to repair the device.

2. Product Overview

The TiFFCOFiO Digital Programmable Outlet Timer features a compact design with a clear LCD display and intuitive controls for easy programming. It allows you to set multiple ON/OFF schedules, use a countdown function, or manually control your devices.

Key Features

- **24-Hour Programmability:** Set precise ON/OFF times for daily repeating schedules.
- **Multiple Programs:** Up to 6 programmable ON/OFF settings.
- **Countdown Function:** Set a specific duration for your device to operate.
- **Manual Override:** Easily switch between ON, OFF, and AUTO modes.
- **Random Function (RND):** Randomly turn lights on/off to simulate occupancy.
- **Daylight Saving Time (DST):** Conveniently adjust for seasonal time changes.
- **Compact Design:** Minimizes space usage in your outlet.
- **ETL Listed:** Certified for safety and quality.

Components




Image: Front view of the digital timer showing the LCD display, control buttons (DAY, +, -, Reset, OK, RND, DST), and the mode dial (SET CLOCK, 1-6 PROG, COUNT DOWN, MANUAL, AUTO).



Image: Close-up of the digital timer's LCD screen, displaying current time, day, and ON/OFF times for the active program.

3. Setup

3.1 Setting Current Time and Day

1. Plug the timer into a standard 3-prong wall outlet.
2. Rotate the mode dial to the **SET CLOCK** position.
3. Press the **DAY** button repeatedly to set the current day of the week.
4. Use the **+** and **-** buttons to set the current hour and minute. Hold the buttons for faster adjustment.
5. Once the time and day are set, rotate the mode dial to **AUTO** to save settings and return to automatic operation.

3.2 Setting Daylight Saving Time (DST)

- In **AUTO** mode, press the **DST** button once to activate Daylight Saving Time (advance 1 hour). The DST indicator will appear on the screen.
- Press the **DST** button again to deactivate (revert 1 hour). The DST indicator will disappear.

4. Operating Instructions

4.1 Programming ON/OFF Cycles (P1-P6)

The timer allows for up to 6 distinct ON/OFF programs. Each program can be set for specific days of the week.

1. Rotate the mode dial to the **1-6 PROG** position. The display will show 'P1 ON'.
2. Press the **DAY** button to select the desired day(s) for Program 1 ON time. Options include individual days, weekdays, weekends, or all days.
3. Use the **+** and **-** buttons to set the ON hour and minute for Program 1.
4. Press the **OK** button to confirm and proceed to 'P1 OFF'.
5. Repeat steps 2-3 to set the OFF time for Program 1.
6. Press the **OK** button to confirm and move to 'P2 ON'. Repeat the process for up to 6 programs.
7. After setting all desired programs, rotate the mode dial to **AUTO** to activate the schedules.

4.2 Using Countdown Function

1. Rotate the mode dial to the **COUNT DOWN** position.
2. Use the **+** and **-** buttons to set the desired countdown duration (hours and minutes).
3. Press the **OK** button to start the countdown. The connected device will turn ON for the set duration and then turn OFF.

4.3 Manual ON/OFF Control

1. Rotate the mode dial to the **MANUAL** position.
2. Press the **OK** button to cycle through Manual ON, Manual OFF, and Auto modes.

4.4 Random Function (RND)

The Random function can be activated in **AUTO** mode to randomly turn your lights ON/OFF within a set time frame, providing a security deterrent when you are away.

1. Ensure the timer is in **AUTO** mode.
2. Press the **RND** button once to activate the Random function. The RND indicator will appear on the screen.
3. Press the **RND** button again to deactivate.



Image: The digital timer plugged into a wall outlet, controlling the lights of a Christmas tree, demonstrating its application for holiday decor.

5. Maintenance

- To clean the timer, unplug it from the wall outlet and wipe it with a dry, soft cloth.
- Do not use liquid cleaners or abrasive materials.
- Store the timer in a cool, dry place when not in use.

6. Troubleshooting

Issue	Possible Cause	Solution

Issue	Possible Cause	Solution
Device not turning ON/OFF at programmed times.	Timer not in AUTO mode. Incorrect program settings.	Ensure mode dial is set to AUTO. Review and correct program settings (P1-P6).
Display is blank or dim.	No power to the timer. Internal battery low.	Check wall outlet. Plug the timer into a live outlet for several hours to charge the internal battery.
Timer not responding to button presses.	Temporary software glitch.	Press the **Reset** button with a pointed object (e.g., a paperclip) to clear all settings and restart. Then re-program.
Connected device is not working.	Device malfunction. Timer overload.	Test the device directly in a wall outlet. Ensure the total wattage of the connected device(s) does not exceed the timer's maximum load.

7. Specifications

Feature	Detail
Brand	Tiffcofio
Model Number	TF-014
Color	White
Material	Plastic
Product Dimensions	2"D x 3"W x 3"H
Number of Settings	48 ON/OFF options (for 24-hour cycle) / Up to 6 programs
Certifications	ETL Listed
Unit Count	1.0 Count

8. Warranty and Support

TiFFCOFiO products are designed for reliability and performance. For any questions, technical assistance, or warranty claims, please refer to the contact information provided with your purchase or visit the official TiFFCOFiO website. Our professional and reliable after-sales service team is available to assist you.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FBKFK9TP

More documents and user manuals: **https://manuals.plus/**