

Asuwish Z-Fold-3-FG008

Asuwish Phone Case for Samsung Galaxy Z Fold 3 5G

INSTRUCTION MANUAL

Model: Z-Fold-3-FG008 | Brand: Asuwish

1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your Asuwish Phone Case for Samsung Galaxy Z Fold 3 5G. This product is designed to offer comprehensive protection and versatile functionality, including a wallet, detachable cover, and multiple carrying options.

2. Package Contents

Please verify that all items listed below are included in your package:

- 1 x Asuwish Phone Case (Blue)
- 1 x Tempered Glass Screen Protector
- 1 x Detachable Wrist Strap
- 1 x Detachable Crossbody Strap

3. Compatibility

This phone case is specifically designed for the **Samsung Galaxy Z Fold 3 / Samsung Galaxy Z Fold 3 5G**. It is **NOT** compatible with other devices, including the original Samsung Galaxy Fold or Samsung Galaxy Z Fold 2.

Compatible with **Samsung Z Fold 3 Only**



Image: Compatibility chart illustrating that the case is only for Samsung Z Fold 3.

4. Setup

4.1. Installing the Phone Case

1. Ensure your Samsung Galaxy Z Fold 3 is clean and free of dust.
2. Gently align your phone with the inner protective shell of the case.
3. Press the phone firmly into the shell until it is securely seated. Ensure all edges are properly covered.

4.2. Installing the Tempered Glass Screen Protector

1. Clean the phone screen thoroughly with the provided cleaning wipes (if included) to remove any dust, smudges, or fingerprints.
2. Peel off the protective film from the adhesive side of the tempered glass.
3. Carefully align the screen protector with the edges and cutouts of your phone screen.
4. Gently lower the screen protector onto the screen. It will adhere automatically.
5. Use a clean cloth or your finger to push out any air bubbles towards the edges.

4.3. Attaching the Straps

The case includes a detachable wrist strap and a detachable crossbody strap. Both can be attached to the small metal rings located on the top edge of the wallet case using their respective clasps.

5. Operating Instructions

5.1. Wallet Functionality

The case features an integrated wallet design with multiple compartments:

- **Card Slots:** 8 dedicated slots for ID, credit cards, or driver's license.
- **Cash Slot:** 1 larger slot for bills.
- **Zipper Purse:** 1 zippered compartment for coins or small items.

CASH & CARD SLOTS

- 9 card slots
- 1 cash slots
- 1 zipper purse
- Strong Magnetic



CARD SLOTS



Image: Detailed view of the wallet's card slots, cash slot, and zipper purse.

5.2. Detachable Back Cover and Magnetic Car Mount Support

The inner phone cover is detachable from the wallet portion. This allows you to use the slim cover independently. The back cover has a built-in metal disk, enabling it to be attached to a magnetic car phone holder. **Note:** Using the magnetic disk may interfere with wireless charging functionality.



Image: Illustration of the detachable wallet case and the slim inner cover.



Image: The detachable phone cover being used with a magnetic car mount.

5.3. Kickstand Holder Function

The wallet case can be folded to create a kickstand, allowing for hands-free viewing of content on your phone.



The zipper won't scratch the phone screen



Kickstand Holder Function



Convenient Carry & Free Your Hands



Neck or crossbody carry safely and easily

Image: The case configured as a kickstand for media viewing.

5.4. Using Wrist and Crossbody Straps

Attach the wrist strap for convenient carrying or the crossbody strap for hands-free use, allowing you to keep your phone secure and accessible.



Image: Examples of carrying the phone case using the wrist and crossbody straps.

6. Maintenance

6.1. Cleaning the Faux Leather Case

- Wipe the faux leather surface with a soft, damp cloth.
- For stubborn stains, use a mild soap solution and wipe gently.
- Avoid harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the material.
- Allow the case to air dry completely before reattaching your phone.

6.2. Cleaning the Screen Protector

- Use a microfiber cloth to gently wipe the screen protector and remove fingerprints or smudges.
- For deeper cleaning, a screen cleaner spray designed for electronics can be used sparingly on the cloth, not directly on the screen.

7. Troubleshooting

7.1. Wireless Charging Issues

If you experience issues with wireless charging, ensure the detachable back cover is removed from the wallet portion. The built-in metal disk for magnetic car mounts can interfere with wireless charging functionality.

7.2. Screen Protector Bubbles

If air bubbles appear after screen protector installation, gently press them towards the nearest edge using a soft cloth or a credit card wrapped in cloth. For persistent bubbles, carefully lift the nearest edge of the protector and reapply, ensuring no dust particles are trapped underneath.

8. Specifications

Feature	Detail
Brand	Asuwish
Compatible Phone Models	Samsung Galaxy Z Fold3
Color	Blue
Material	Faux Leather
Additional Features	Built-in Screen Protector, Detachable Wallet, Magnetic Car Mount Support, Kickstand
Form Factor	Flip
Model Number	Z-Fold-3-FG008-Blue
Number of Items	1 (case, screen protector, 2 straps)

9. Warranty and Support

This product comes with a **three months warranty** from the date of purchase. For warranty claims or technical support, please contact Asuwish customer service through your original point of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question