mloong 69x59in

Mloong 69x59in Large Baby Playpen Instruction Manual

Model: 69x59in | Brand: Mloong

Important Safety Information

Please read and understand all instructions before assembling and using the Mloong Large Baby Playpen. Keep this manual for future reference.

- **Adult Supervision Required:** Never leave a child unattended in the playpen. Constant adult supervision is necessary.
- **Proper Assembly:** Ensure all components are correctly assembled and securely fastened before placing a child inside. Failure to do so can result in injury.
- **No Climbing:** Do not allow children to climb on the playpen. This can cause the playpen to tip over or the child to fall out.
- **Hazard-Free Zone:** Keep the playpen away from potential hazards such as stoves, heaters, electrical outlets, windows, and cords.
- **Safe Materials:** This playpen is constructed with baby-safe, BPA-free, and non-toxic materials.
- **Stability Features:** The playpen includes suction cup feet, extra-thick tubes, and reinforced joint padding for enhanced stability and to prevent bumps.
- **Weight Limit:** Do not exceed the recommended weight limit for the playpen.



Image: The Mloong playpen provides a safe environment, keeping children away from common household hazards such as kitchen areas, preventing accidental falls, and protecting from electrical shock risks.

Package Contents

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Mesh Fabric Enclosure (with integrated zipper door and storage bag)
- Metal Support Pipes (various lengths for frame)
- T-Joint Connectors
- Corner Connectors
- Suction Cup Feet
- Pull Rings (2 units)
- Assembly Instructions Manual

Assembly Instructions (Setup)

Assembly is designed to be straightforward. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.
2. **Assemble Base Frame:** Connect the shortest metal pipes using the T-joint connectors to form the base perimeter. Ensure they click securely into place.
3. **Attach Vertical Pipes:** Insert the vertical metal pipes into the T-joints and corner connectors of the base frame.
4. **Install Mesh Fabric:** Slide the mesh fabric enclosure over the assembled frame. Ensure the zipper door is positioned as desired. The fabric should fit snugly around the pipes.
5. **Assemble Top Frame:** Connect the remaining metal pipes using the T-joint and corner connectors to form the top perimeter. Securely attach this top frame to the vertical pipes.
6. **Secure Joints:** Verify that all connections are firm and stable. The reinforced joint padding should be properly positioned.
7. **Attach Suction Cup Feet:** Press the suction cup feet firmly onto the bottom of the playpen frame to enhance stability on smooth surfaces.
8. **Install Pull Rings:** Attach the two pull rings to the top rail of the playpen as desired.



Image: The fully assembled Mloong Large Baby Playpen, showcasing its spacious design and overall structure. Note the indicated dimensions for reference.



Image: Detail of the playpen's 'Double Protection' features, including extra sponge padding at joint areas and thicker soft padding on the armrests for child safety and comfort.



Image: Demonstrating the playpen's robust construction with an extra-thick stainless steel pipe and an upgraded T-joint, contributing to a stronger and safer play environment.

Operating Instructions

The Mloong playpen is designed for ease of use and versatility.

- **Zipper Door Access:** The playpen features a convenient zipper door for easy entry and exit for both children and adults. Ensure the zipper is fully closed when the child is inside to maintain a secure enclosure.
- **Storage Bag:** Utilize the integrated storage bag on the side of the playpen to keep small toys, diapers, or other essentials within easy reach.
- **Pull Rings:** The included pull rings are designed to assist babies in standing and taking their first steps, promoting early development and strengthening arm muscles.
- **360° Mesh Visibility:** The full mesh design allows for clear visibility of your child from all angles, ensuring you can always keep an eye on them.



Image: The transparent mesh sides of the playpen allow for constant visual connection between parent and child, fostering interaction and peace of mind.




Image: The playpen's multi-functional design, featuring a convenient storage bag, an accessible zipper door, and pull rings to aid in a child's early development and mobility.




Image: The extra-large design of the playpen provides sufficient space for both children and adults to comfortably play together, promoting family bonding.

Maintenance and Care

Regular cleaning and inspection will ensure the longevity and safety of your playpen.

- **Cleaning:** The mesh fabric can be wiped clean with a damp cloth and mild soap. Allow to air dry completely. Do not use harsh chemicals or abrasive cleaners.
- **Frame Cleaning:** The metal and plastic frame components can be wiped with a damp cloth.
- **Regular Inspection:** Periodically check all pipes, connectors, and fabric for any signs of wear, damage, or loose parts. Ensure the zipper functions smoothly.
- **Storage:** If disassembling for storage, ensure all parts are clean and dry. Store in a cool, dry place away from direct sunlight.

Troubleshooting

If you encounter any issues with your Mloong playpen, refer to these common solutions:

- **Playpen is Unstable:** Ensure all pipes are fully inserted into their connectors and that the suction cup feet are firmly pressed onto a smooth, clean surface. Check for any bent or damaged pipes.
- **Difficulty Assembling:** Double-check that you are using the correct pipe lengths for each section (e.g., shorter pipes for the base, longer for sides). Refer to the assembly diagrams.
- **Zipper Not Functioning:** Ensure no fabric is caught in the zipper teeth. Apply a small amount of zipper lubricant if it is stiff.
- **Missing Parts:** If any parts were missing upon unboxing, please contact customer support immediately.

Specifications

Feature	Detail
Model	69x59in Large Baby Playpen

Feature	Detail
Dimensions (L x W x H)	69 x 59 x 27 inches (approximate, based on product images)
Floor Area	28 Square Feet
Material	Metal (frame), Plastic (connectors), Mesh Fabric
Color	Beige
Item Weight	8.3 Pounds
Age Range	Toddler
Foldable	No (unfoldable)




Image: Visual representation of the Mloong playpen's dimensions, highlighting its generous size for active toddlers.

Warranty and Support

Mloong is committed to providing high-quality products. While specific warranty details are not provided in this manual, we encourage you to retain your proof of purchase.

For any questions, concerns, or assistance with your Mloong Large Baby Playpen, please contact the retailer or manufacturer directly. Contact information can typically be found on the product packaging or the retailer's website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question