



Manuals.plus /

- › AirWire /
- › AirWire 10x10 FT Outdoor Storage Shed Instruction Manual

## AirWire AGJF1010BT-C02

# AirWire 10x10 FT Outdoor Storage Shed Instruction Manual

Model: AGJF1010BT-C02

Brand: AirWire

## 1. INTRODUCTION

---

This manual provides detailed instructions for the assembly, operation, and maintenance of your AirWire 10x10 FT Outdoor Storage Shed. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



*Image 1.1: Assembled AirWire 10x10 FT Outdoor Storage Shed with open doors.*

The AirWire 10x10 FT Outdoor Storage Shed is designed to provide secure and weather-resistant storage for your garden tools, equipment, and other outdoor items. It features an upgraded full-frame structure for enhanced stability and ease of installation.

## **2. SAFETY INFORMATION**

---

Please observe the following safety precautions during assembly and use:

- Assembly may require handling heavy components. It is recommended that 2-3 people assist with assembly.
- Always wear appropriate personal protective equipment, such as gloves and safety glasses, during assembly.
- Ensure the assembly area is clear of obstructions and hazards.
- Follow all provided safety guidelines in the detailed step-by-step manual included with your shed.
- Ensure doors are properly locked and unlocked to prevent accidents and unauthorized access.
- Do not climb on the shed roof.
- Secure the shed to the ground to prevent wind damage.

### 3. PACKAGE CONTENTS

---

Before beginning assembly, verify that all parts are present and undamaged. Each part of the outdoor shed is clearly labeled with a part number for easy identification.

#### Expected Items:

- Metal panels for walls and roof
- Frame components (alloy steel)
- Hardware kit (screws, nuts, bolts)
- Door components and locking mechanism
- Air vents
- Detailed step-by-step instruction manual
- Protective gloves (2 pairs)



*Image 3.1: Product dimensions and included accessories.*

### 4. SITE PREPARATION

---

Proper site preparation is crucial for the stability and longevity of your shed:

- Choose a level and firm surface for installation. An uneven surface can lead to difficulties in assembly and compromise the shed's structural integrity.
- Ensure adequate drainage around the shed to prevent water accumulation.
- Clear the area of any debris, rocks, or vegetation.
- Consider a foundation (e.g., concrete slab, treated timber frame) for added stability and moisture protection.

## 5. ASSEMBLY INSTRUCTIONS

---

The AirWire shed features an upgraded frame structure designed for improved installation ease. Refer to the detailed step-by-step manual provided in the packaging for specific instructions and diagrams.

### General Assembly Steps:

1. **Unpack and Identify Parts:** Lay out all components and match them with the part numbers in the manual.
2. **Assemble the Base Frame:** Construct the shed's base on your prepared site, ensuring it is square and level.
3. **Install Wall Panels:** Attach the wall panels to the base frame, following the sequence specified in the manual.
4. **Construct the Roof Frame:** Assemble the roof support beams and attach them to the top of the wall panels. The shed includes 3 sturdy beams for enhanced roof support.
5. **Attach Roof Panels:** Secure the roof panels, ensuring proper overlap for water runoff. The sloped roof design aids in efficient water drainage.
6. **Install Doors and Vents:** Mount the lockable doors and install the 2 air vents for improved air circulation.
7. **Final Checks:** Tighten all fasteners and ensure all components are securely in place.

# Product upgrade - increased

## from 65" to 80.3"

Higher heights for greater storage space.  
And spacious top space to give you a comfortable feeling.



Image 5.1: Key structural and functional details of the shed.

## 6. OPERATING INSTRUCTIONS

---

Operating your AirWire storage shed is straightforward:

- **Doors:** The shed is equipped with lockable doors for security. Use a padlock (not included) to secure your belongings. Ensure the doors close smoothly and align correctly.
- **Vents:** The shed features 2 integrated air vents to promote air circulation and reduce condensation inside. Ensure these vents are not obstructed.
- **Storage:** Utilize the spacious interior for organizing tools, lawn equipment, and other items. Consider shelving or hooks for efficient space management.

## 7. MAINTENANCE

---

Regular maintenance will help preserve the condition and extend the lifespan of your AirWire storage shed:

- **Cleaning:** The shed's superior-grade metal construction is easy to clean. Wipe down exterior and interior surfaces with a damp cloth and mild detergent as needed. Avoid abrasive cleaners.

- **Weather Protection:** The shed features waterproof and UV-resistant capabilities, providing reliable all-weather protection. Periodically inspect for any signs of wear or damage to maintain its protective qualities.
- **Fastener Checks:** Annually, check all screws and bolts to ensure they remain tight. Re-tighten if necessary to maintain structural integrity.
- **Door Alignment:** If doors become misaligned or difficult to open/close, inspect hinges and adjust as needed.
- **Ventilation:** Ensure the air vents remain clear of debris to allow for proper airflow.

## 8. TROUBLESHOOTING

---

If you encounter issues with your shed, consider the following common solutions:

- **Difficulty with Door Closure/Alignment:** Ensure the shed's base is perfectly level and square. Uneven ground can cause the frame to twist, affecting door operation. Check that all wall and roof panels are correctly installed and tightened.
- **Water Leakage:** Verify that all roof panels are properly overlapped and secured according to the manual. Ensure all fasteners are tight and any sealant (if used during assembly) is intact. Check for any damage to panels.
- **Missing or Damaged Parts:** If you find any parts missing or damaged upon unpacking, refer to the customer support section to request replacements.

For any issues not resolved by these steps, please contact AirWire customer support.

## 9. SPECIFICATIONS

---

Feature	Specification
Brand	AirWire
Model Number	AGJF1010BT-C02
Color	Gray
Material	Alloy Steel
Product Dimensions (D x W x H)	113.3"D x 113.3"W x 80.3"H (10x10 FT)
Water Resistance Level	Waterproof
Frame Material	Alloy Steel
Door Style	Double Hinged, Lockable
Assembly Required	Yes
Ventilation	2 Air Vents

## 10. CUSTOMER SUPPORT

---

AirWire is committed to providing high-quality products and excellent customer service. If you have any questions, concerns, or require assistance with your AirWire 10x10 FT Outdoor Storage Shed, please do not hesitate to contact our professional support team.

Please refer to the contact information provided in your product packaging or on the official AirWire website for the most current support channels.