

[Manuals.plus](#) /

› [SoarFlash](#) /

› SoarFlash Chenille Ottoman Instruction Manual

SoarFlash 1 Ottoman

SoarFlash Chenille Ottoman Instruction Manual

Model: 1 Ottoman Black

INTRODUCTION

Thank you for choosing the SoarFlash Chenille Ottoman. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image: The SoarFlash Chenille Ottoman in black, showcasing its plush design.

SAFETY INFORMATION

- Always assemble the ottoman on a soft, clean surface to prevent damage.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not stand or jump on the ottoman. It is designed for seating and footrest purposes only.
- Keep small parts away from children during assembly to avoid choking hazards.
- Avoid placing the ottoman near open flames or direct heat sources.
- Use caution when moving the ottoman to prevent injury or damage to the product or surroundings.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Ottoman Base (1)
- Ottoman Cushion (1)
- Legs (4)
- Assembly Hardware (screws, washers, Allen wrench)



Image: An illustration showing that multiple packages may arrive separately for modular furniture components, including the ottoman.

SETUP AND ASSEMBLY

Assembly of the SoarFlash Chenille Ottoman is straightforward and typically requires one person. Please follow these steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Attach Legs:** Locate the four legs and the corresponding attachment points on the underside of the ottoman base. Align each leg with the pre-drilled holes and secure them using the provided screws and Allen wrench. Ensure all legs are firmly attached.
3. **Place Cushion:** Position the ottoman cushion onto the ottoman base. The cushion is designed to fit snugly and provide optimal comfort.
4. **Final Check:** Gently lift and place the assembled ottoman in its desired location. Ensure it is stable and does not wobble. Re-tighten any loose connections if necessary.



Image: A detailed view highlighting the multi-layer cushion construction and non-slip feet for stability.

OPERATING INSTRUCTIONS

The SoarFlash Chenille Ottoman is designed for versatile use:

- **As a Footrest:** Place the ottoman in front of your sofa or chair to comfortably elevate your feet and legs.
- **Extra Seating:** The ottoman can serve as additional seating for guests, providing a comfortable and supportive surface.
- **Modular Component:** As part of the SoarFlash modular sectional series, this ottoman can be rearranged with other pieces to create various configurations, such as an L-shaped sofa or a chaise lounge.
- **Surface for Items:** With a tray, the ottoman can function as a temporary coffee table or side table for light items.



Image: The ottoman serving as both a comfortable footrest and a convenient surface for a coffee cup.



Image: An overview demonstrating different modular configurations possible with SoarFlash sectional components, including the ottoman.

MAINTENANCE

Proper care will extend the life and appearance of your chenille ottoman:

- **Regular Cleaning:** Vacuum the ottoman regularly using a soft brush attachment to remove dust and loose debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. Do not rub, as this can spread the stain. For stubborn stains, use a mild fabric cleaner specifically designed for chenille, testing on an inconspicuous area first.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the fabric to fade. Position your ottoman away from direct sun exposure or use curtains/blinds.
- **Fluff Cushions:** Periodically fluff and rotate the cushion to maintain its shape and even out wear.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Ottoman wobbles	Legs are not tightened evenly or fully.	Check and re-tighten all leg screws. Ensure the ottoman is on a flat surface.
Cushion appears flat or uneven	Normal settling of foam over time; uneven use.	Fluff and rotate the cushion regularly. Allow time for foam to fully expand after unpacking.
Fabric discoloration or fading	Exposure to direct sunlight or harsh chemicals.	Relocate the ottoman away from direct sunlight. Avoid using strong cleaning agents.

SPECIFICATIONS

- **Brand:** SoarFlash
- **Model:** 1 Ottoman
- **Color:** Black
- **Upholstery Fabric Type:** Chenille
- **Fill Material:** High Density Foam
- **Frame Material Type:** Wood
- **Product Dimensions (D x W x H):** 22.4"D x 35"W x 19"H
- **Seat Depth:** 25 inches
- **Item Firmness Description:** Medium to Firm
- **Assembly Required:** Yes



Image: Detailed dimensions of the ottoman.



Image: Visual representation of the ottoman's seat depth.



Image: Visual representation of the ottoman's seat height.



Image: Visual representation of the overall height of a modular sofa component, indicating compatibility.

PRODUCT FEATURES OVERVIEW

Comfortable Experience



Cushion Back ►

Experience unrivaled comfort with our sofa, featuring a full upholstered design.

◀◀ Throw Pillows

Add extra support, ensuring a luxurious lounging experience and indulge in ultimate relaxation.



Comfy Ottoman ►►►

Designed to alleviate leg pressure, it promotes long-lasting relaxation, perfect for unwinding after a busy day.

Image: Overview of comfort features including cushion design and throw pillows.

Ultra-comfortable Seats




Image: Icons illustrating the soft, durable, breathable, and comfortable nature of the chenille fabric.




Image: A cutaway view showing the internal construction of the cushion, featuring high-density foam and pocketed

springs.

PRODUCT VIDEOS

Your browser does not support the video tag.

Video: A short overview demonstrating the features and versatility of the SoarFlash modular furniture system.

Your browser does not support the video tag.

Video: A detailed demonstration of how to assemble and configure the modular sofa components.

Your browser does not support the video tag.

Video: A vertical format video showcasing the comfort and aesthetic appeal of the SoarFlash sectional.

WARRANTY

SoarFlash products are manufactured with quality and durability in mind. While specific warranty details are not provided in this manual, please refer to your purchase documentation or contact the seller directly for information regarding warranty coverage and terms.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or encounter any issues with your SoarFlash Chenille Ottoman, please do not hesitate to contact the seller through the platform where you made your purchase. Provide your order number and a detailed description of the issue for prompt support.

You can typically find seller contact information on your order details page.

© 2026 SoarFlash. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question