

[Manuals.plus](#) /

> [KCCKOM](#) /

> KCCKOM Kitchen Trolley Black (Model KCCKOM) Instruction Manual

## KCCKOM KCCKOM

# KCCKOM Kitchen Trolley Black (Model KCCKOM) Instruction Manual

Important information for assembly, operation, and maintenance.

## 1. INTRODUCTION

Welcome to your new KCCKOM Kitchen Trolley. This manual provides essential instructions for safe assembly, proper use, and maintenance of your kitchen storage unit. Please read this manual thoroughly before assembly and retain it for future reference.

## 2. SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product.

- **Wall Attachment:** To prevent tipping, this product **must** be used with the provided wall attachment device. Securely fasten the trolley to a wall according to the instructions.
- **Assembly:** Ensure all parts are correctly assembled and fasteners are tightened before use.
- **Weight Capacity:** Do not overload the shelves or drawers. Distribute weight evenly.
- **Movement:** When moving the trolley, ensure all items are secure to prevent them from falling. Lock the wheels when the trolley is stationary.
- **Children:** Keep children away from the assembly area. Do not allow children to climb on or play with the trolley.

## 3. PACKAGE CONTENTS

Verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Engineered Wood Panels (Top, Shelves, Drawer, Door, Side Panels)
- Steel Frame Components
- Drawer Slides and Handle
- Door Hinges and Handle
- 4 Castors (2 with brakes)

- Adjustable Feet (for stationary use)
- Towel Rack
- Wall Attachment Device
- Assembly Hardware (screws, bolts, cam locks, etc.)

## 4. SETUP AND ASSEMBLY

Assembly is required for this product. Follow these steps carefully.

1. **Prepare the Area:** Clear a spacious, clean, and flat area for assembly. Lay down a blanket or cardboard to protect the floor and product components.
2. **Assemble the Steel Frame:** Connect the vertical and horizontal steel frame components using the provided hardware. Ensure all connections are secure.
3. **Install Panels:** Attach the engineered wood panels (shelves, side panels, back panel if applicable) to the steel frame.
4. **Assemble Drawer:** Construct the drawer box and install the drawer slides. Attach the drawer handle.
5. **Install Drawer into Frame:** Carefully slide the assembled drawer into its designated slot within the frame.
6. **Assemble Door:** Attach hinges to the door and then secure the door to the frame. Install the door handle.
7. **Attach Towel Rack:** Secure the towel rack to the side of the trolley as indicated in the diagrams.
8. **Choose Base Option:**
  - **For Stationary Use:** Screw in the adjustable feet to the bottom of the frame. Adjust them to ensure stability on uneven surfaces.
  - **For Mobile Use:** Attach the 4 castors to the bottom of the frame. Ensure the 2 castors with brakes are positioned at the front for easy access.
9. **Wall Attachment:** Position the trolley in its desired location. Using the provided wall attachment device, secure the trolley to a sturdy wall stud to prevent accidental tipping. Refer to the specific instructions included with the wall attachment kit.



*Image: KCCKOM Kitchen Trolley configured with adjustable feet for stationary use. This configuration provides stability on uneven surfaces.*



*Image: KCCKOM Kitchen Trolley configured with wheels for mobility. Two of the wheels are lockable for secure placement.*

## 5. OPERATING INSTRUCTIONS

- **Storage:** Utilize the drawer, open shelf, and cabinet space for organizing kitchen essentials, food items, dishes, and utensils.
- **Mobility (if applicable):** To move the trolley, unlock the two braked wheels. Guide the trolley to the desired location and then lock the wheels to secure it.
- **Towel Rack:** Use the side-mounted rack to keep kitchen towels conveniently accessible.



*Image: The KCCOM Kitchen Trolley showcasing its storage capabilities with various items on the open shelf and top surface.*



*Image: The KCCOM Kitchen Trolley with its drawer and cabinet door open, revealing internal storage space suitable for cutlery and other kitchen items.*

## 6. MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the engineered wood or steel finish.
- **Spills:** Clean up spills immediately to prevent moisture damage to the engineered wood.
- **Fasteners:** Periodically check all screws and bolts to ensure they remain tight. Retighten as necessary.
- **Wheels (if applicable):** Keep castor wheels free of debris to ensure smooth movement.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Trolley is wobbly/unstable.	Uneven floor; loose fasteners; adjustable feet not properly set.	Adjust the feet to level the trolley. Check and tighten all assembly fasteners. Ensure wall attachment is secure.

Problem	Possible Cause	Solution
Wheels do not roll smoothly.	Debris in wheels; wheels locked.	Clear any debris from the castor wheels. Ensure brakes are disengaged.
Drawer/Door does not close properly.	Misaligned slides/hinges; obstruction.	Check for obstructions. Realign drawer slides or door hinges if necessary.

## 8. SPECIFICATIONS

- **Model:** KCCKOM
- **Color:** Black
- **Material:** Engineered wood, steel
- **Dimensions with Castors (L x W x H):** 22" x 16.9" x 35.2"
- **Wheels:** 4 castors, 2 with brakes
- **Assembly Required:** Yes
- **Item Weight:** Approximately 0.811 ounces (*Note: This weight may be a data entry error; please refer to actual product packaging for accurate weight.*)

## 9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or contact the retailer where the product was acquired.

**Manufacturer:** KCCKOM

**ASIN:** B0FBRJST47