

CITLLA L360

CITLLA Wireless Bluetooth Mouse (USB + BT1 + BT2) Instruction Manual

Model: L360 | Brand: CITLLA

1. INTRODUCTION

Thank you for choosing the CITLLA L360 Wireless Bluetooth Mouse. This manual provides detailed instructions for setting up, operating, and maintaining your new mouse. Please read it thoroughly to ensure optimal performance and a seamless user experience across multiple devices.

2. KEY FEATURES

- **Versatile Connectivity:** Supports 2.4G wireless USB receiver and dual Bluetooth (BT1 + BT2) connections, allowing users to choose their preferred method or connect to different devices simultaneously.
- **4-Way Scrolling:** Features a unique 4-way scrolling wheel for enhanced navigation, offering faster vertical scrolling and horizontal movement by tilting the wheel.
- **Adjustable DPI:** Four adjustable DPI settings (1000/1600/2400/3000) to customize cursor sensitivity for various tasks, from precise work to faster navigation.
- **Silent Operation:** Designed with silent buttons and scroll wheel to minimize noise, providing a quiet working environment.
- **Ergonomic Design:** Full-size mouse with rubber side grips for a comfortable, sweat-proof, and non-slip hold, suitable for extended use.
- **Extended Battery Life:** Powered by two AA batteries (included), offering an impressive battery life of up to 3 years and 4 months, thanks to an efficient power control system and auto-sleep function.
- **Wide Compatibility:** Compatible with a broad range of operating systems including Windows, iOS, MacOS, Android, Linux, and Chrome OS, and devices such as computers, laptops, all-in-one PCs, tablets, smartphones, iPads, and MacBooks.







Figure 1: Top view of the CITLLA L360 Wireless Bluetooth Mouse.

3. PACKAGE CONTENTS

- 1 x CITLLA L360 Wireless Bluetooth Mouse
- 1 x 2.4G USB Receiver (stored inside the mouse battery compartment)
- 2 x AA Batteries (pre-installed in the mouse)
- 1 x User Manual

4. SETUP AND INSTALLATION

4.1. Battery Installation

1. Gently slide and lift the top cover of the mouse from the rear to expose the battery compartment.
2. Remove the protective yellow tab from the pre-installed AA batteries.
3. If replacing batteries, insert two new AA batteries, ensuring correct polarity (+/-).
4. Replace the top cover, ensuring it snaps securely into place.

Power saving



Power Saving



Auto Sleep



Under daily use, the mouse can be used continuously for 40 months (Package contains two high-capacity batteries)

8 minutes: sleep mode(2.4G mode)



Work



Standby



Auto Sleep

Figure 2: Battery compartment and USB receiver storage.

4.2. Connecting via 2.4G USB Receiver

1. Open the battery compartment and carefully remove the 2.4G USB receiver.
2. Plug the USB receiver into an available USB port on your computer or laptop.
3. Turn on the mouse using the ON/OFF switch located on the bottom of the mouse.
4. Press the connection mode button (located below the scroll wheel) until the white indicator light illuminates, signifying 2.4G USB mode. The mouse should connect automatically.

4.3. Connecting via Bluetooth (BT1 / BT2)

1. Turn on the mouse using the ON/OFF switch on the bottom.
2. Press the connection mode button until the blue indicator light (for BT1) or green indicator light (for BT2) flashes. This indicates the mouse is in pairing mode.
3. On your device (computer, laptop, tablet, smartphone), go to Bluetooth settings.

4. Search for new devices and select "BT5.0 Mouse" or "CITLLA Mouse" from the list.
5. Once connected, the corresponding indicator light on the mouse will become solid.
6. To connect a second Bluetooth device, repeat steps 2-4, selecting the other Bluetooth channel (BT2) on the mouse.



Figure 3: Multi-device switching button and indicators.

5. OPERATING INSTRUCTIONS

5.1. Basic Mouse Functions

- **Left Click:** Standard selection and activation.
- **Right Click:** Accesses context menus.
- **Scroll Wheel:** Scrolls vertically.
- **4-Way Scrolling:** Tilt the scroll wheel left or right for horizontal scrolling.
- **Forward/Back Buttons:** Located on the left side of the mouse, these buttons allow for quick navigation forward or

backward in web browsers or file explorers.

Four-way navigation wheel

The mouse wheel unlocks the speed limit and can scroll at extremely high speeds



Figure 4: The 4-way navigation wheel provides versatile scrolling.

5.2. DPI Adjustment

The mouse features four adjustable DPI levels to suit your preference and task requirements:

- 1000 DPI
- 1600 DPI
- 2400 DPI
- 3000 DPI

To change the DPI, press the "DPI" button located below the scroll wheel. The indicator light will flash a certain number of times to indicate the current DPI setting:

- 1 flash: 1000 DPI
- 2 flashes: 1600 DPI

- 3 flashes: 2400 DPI
- 4 flashes: 3000 DPI



Figure 5: DPI button and silent click feature.

5.3. Multi-Device Switching

The mouse allows for quick switching between up to three connected devices (one via 2.4G USB, two via Bluetooth). Simply press the connection mode button (below the scroll wheel) to cycle through the connected devices. The mouse will automatically connect to the corresponding device if it has been previously paired.

Your browser does not support the video tag.

Video 1: Demonstrates the unboxing, features, and multi-device connectivity of the CITLLA L360 mouse.

6. POWER MANAGEMENT

- **Battery Life:** The mouse is designed for ultra-low power consumption, providing up to 40 months (3 years and 4 months) of battery life with the included AA batteries under daily use.

- **Auto Sleep:** To conserve power, the mouse will automatically enter sleep mode after 8 minutes of inactivity (in 2.4G mode). To wake it up, simply move the mouse or press any button.
- **Low Battery Indicator:** When the battery is low, the indicator light will flash, prompting you to replace the batteries.



Power saving



Power Saving



Auto Sleep



Under daily use, the mouse can be used continuously for 40 months (Package contains two high-capacity batteries)

8 minutes: sleep mode(2.4G mode)



Work



Standby



Auto Sleep

Figure 6: Power saving and auto-sleep features for extended battery life.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the mouse. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use for extended periods, turn off the mouse to conserve battery life. Store the USB receiver in its designated compartment inside the mouse.
- **Battery Replacement:** Replace batteries promptly when the low battery indicator flashes to ensure continuous operation.

8. TROUBLESHOOTING

Problem	Possible Solution
Mouse not responding.	Ensure the mouse is turned ON. Check battery levels and replace if necessary. Verify the USB receiver is securely plugged in (for 2.4G mode). Ensure Bluetooth is enabled on your device and the mouse is paired (for Bluetooth mode). Try switching to a different connection mode (2.4G, BT1, BT2).
Cursor movement is erratic or slow.	Clean the optical sensor on the bottom of the mouse. Ensure you are using the mouse on a suitable surface (non-reflective, non-transparent). Adjust the DPI setting to a higher value using the DPI button.
Cannot pair via Bluetooth.	Ensure the mouse is in Bluetooth pairing mode (flashing blue/green light). Delete previous Bluetooth connections for the mouse on your device and try pairing again. Restart your device and the mouse.

9. SPECIFICATIONS

Feature	Detail
Model Number	L360
Connectivity Technology	2.4G Wireless USB, Bluetooth (BT1, BT2)
Movement Detection Technology	Optical
DPI Settings	1000 / 1600 / 2400 / 3000
Mouse Dimensions (L x W x H)	4.6 x 2.6 x 1.6 inches (117 x 67 x 41 mm)
Item Weight	5.9 ounces
Power Source	2 x AA Batteries (included)
Battery Life	Up to 40 months (3 years and 4 months)
Compatibility	Windows, iOS, MacOS, Android, Linux, Chrome OS

10. WARRANTY AND SUPPORT

For warranty information, technical support, or customer service inquiries, please refer to the contact information provided on the product packaging or visit the official CITLLA website. Keep your purchase receipt for warranty claims.

11. SAFETY INFORMATION

- Do not expose the mouse to extreme temperatures or humidity.
- Avoid dropping or disassembling the device.
- Dispose of batteries according to local regulations.

- Keep out of reach of children.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Can I program the buttons on the CITLLA L360 mouse to control the volume on my laptop?

Based on the instruction manual for the CITLLA L360, the mouse does not come with proprietary software for button remapping or programming. The buttons have fixed default functions: Left/Right Click: Standard selection and context menus. Scroll...

[Read full answer](#)

Can I program the buttons on the CITLLA L360 mouse to control volume?

Based on the instruction manual for the CITLLA L360, the mouse does not include dedicated software for button remapping or programming. The buttons have fixed default functions: Left/Right Click: Standard selection and context menus. Scroll Wheel:...

[Read full answer](#)