

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [King Koil](#) /

> [King Koil Luxury Air Mattress with Built-in High-Speed Pump - User Manual](#)

King Koil Luxury Air Mattress

King Koil Luxury Air Mattress with Built-in High-Speed Pump - User Manual

Model: Luxury Air Mattress

Brand: King Koil

1. PRODUCT OVERVIEW

The King Koil Luxury Air Mattress is designed for superior comfort and convenience, featuring a built-in high-speed pump and a premium pillow top. Its coil-beam construction provides firm support for a restful night's sleep, making it ideal for overnight guests, camping, or temporary bedding solutions. This manual provides essential information for the safe and effective use of your air mattress.



Figure 1: King Koil Luxury Air Mattress in its fully inflated state, highlighting its comfortable pillow-top surface and elevated double-high profile, designed for guest comfort.

2. KEY FEATURES

- **Built-in High-Speed Pump:** Integrated 120V / 210W AC pump for quick and easy inflation and deflation in under 2 minutes.
- **Adjustable Comfort:** Separate inflate and deflate knobs allow for precise adjustment to your desired firmness.
- **Premium Pillow Top:** Soft flocking layer and built-in pillow for enhanced comfort and a luxurious feel.
- **Extra Spinal Support:** Coil-beam construction provides firm support for proper spinal alignment and good sleeping posture.
- **Durable & Waterproof:** Extra thick, durable, waterproof comfort quilt top with sueded surface to keep bedding in place.
- **Integrated Cord Storage:** Convenient compartment for storing the power cord after use.
- **Patch Kits Included:** All King Koil air mattresses include patch kits for accidental punctures or tears.

3. SETUP INSTRUCTIONS

1. **Unpack the Mattress:** Remove the air mattress from its storage bag and unroll it on a clean, flat surface, ensuring there are no sharp objects underneath.
2. **Locate the Pump:** Identify the built-in pump panel on the side of the mattress.
3. **Access Power Cord:** Open the small compartment on the pump panel to retrieve the power cord.
4. **Plug In:** Plug the power cord into a standard 120V AC electrical outlet.
5. **Prepare for Inflation:** Ensure the deflation valve is in the 'CLOSE' position. Turn the inflation valve to the 'OPEN' position.
6. **Inflate Mattress:** Flip the 'POWER' switch to 'ON'. The mattress will begin to inflate. Allow approximately 1-2 minutes for full inflation.
7. **Adjust Firmness:** Once fully inflated, you can adjust the firmness by briefly turning the inflation valve to 'OPEN' for more air, or the deflation valve to 'OPEN' for less air, then return to 'CLOSE'.
8. **Secure Valves & Store Cord:** Once desired firmness is achieved, ensure both inflation and deflation valves are in the 'CLOSE' position. Unplug the power cord and store it back in its compartment.

4. OPERATING INSTRUCTIONS

The King Koil air mattress features an intuitive built-in pump for hassle-free operation.

Inflation:

1. Plug the mattress into a 120V AC outlet.
2. Turn the inflation valve to 'OPEN'.
3. Flip the 'POWER' switch to 'ON'.
4. Allow the mattress to inflate to your desired firmness (approx. 1-2 minutes for full inflation).
5. Flip the 'POWER' switch to 'OFF' and turn the inflation valve to 'CLOSE'.

Deflation:

1. Plug the mattress into a 120V AC outlet.
2. Turn the deflation valve to 'OPEN'.
3. Flip the 'POWER' switch to 'ON'. The pump will actively remove air from the mattress.
4. Once the mattress is fully deflated, flip the 'POWER' switch to 'OFF' and turn the deflation valve to 'CLOSE'.
5. Unplug the power cord and store it in its compartment.

5. MAINTENANCE

- **Cleaning:** Clean the mattress surface with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners. Ensure the mattress is completely dry before storing.
- **Storage:** After deflation, fold or roll the mattress neatly. Store it in the provided storage bag in a cool, dry place away from direct sunlight and extreme temperatures. Avoid placing heavy objects on top of the stored mattress.
- **Patching:** In case of a small puncture, use the included patch kit. Clean the area around the puncture, apply the patch firmly, and allow sufficient time for it to cure before re-inflating.
- **Avoid Over-Inflation:** Do not over-inflate the mattress, as this can damage the seams and internal structure.

6. TROUBLESHOOTING

- **Mattress Not Inflating:**

- Check if the power cord is securely plugged into a working outlet.
- Ensure the 'POWER' switch is 'ON' and the inflation valve is in the 'OPEN' position.
- Verify that the deflation valve is in the 'CLOSE' position.

- **Mattress Losing Air:**

- Check that both inflation and deflation valves are securely in the 'CLOSE' position.
- Inspect the mattress surface for any punctures or leaks. Use soapy water to identify small leaks (bubbles will form).
- Ensure the mattress is not placed on sharp objects.

- **Pump Not Working:**

- Confirm the power cord is connected and the outlet is functional.
- Check for any obstructions in the pump's air intake or exhaust vents.

7. SPECIFICATIONS

Brand	King Koil
Model	Luxury Air Mattress
Inflated Dimensions	75" x 54" x 20" (Full Size)
Pump Type	Built-in 120V / 210W AC High-Speed Pump
Special Feature	Built-In Pump
Construction	Coil-Beam
Top Material	Extra thick durable waterproof comfort quilt top with sueded finish

8. WARRANTY AND SUPPORT

Your King Koil Luxury Air Mattress comes with a customer-friendly **1-year factory guarantee** provided by the manufacturer. Warranty details are included in the product packaging and with your airbed purchase.

For any support needs, questions, or to claim your warranty, please refer to the contact information provided in your product documentation or visit the official King Koil website.

King Koil is endorsed by the International Chiropractors Association to help promote proper spinal alignment and a healthier night's sleep.