**esbeecables LK-FBA-215**

# esbeecables USB-C Wired Earbuds User Manual

Model: LK-FBA-215

## INTRODUCTION

Thank you for choosing esbeecables USB-C Wired Earbuds. These earphones are designed to provide high-fidelity audio and clear communication for a wide range of USB-C enabled devices. Featuring a comfortable in-ear design, built-in microphone, and remote control, they are ideal for daily use, work, study, and sports.

Image: Two pairs of esbeecables USB-C wired earbuds, showcasing their design and connectivity.

## PACKAGE CONTENTS

- 2 x USB-C Wired Earbuds

## SETUP

The esbeecables USB-C Wired Earbuds are designed for simple plug-and-play operation. No drivers or additional software are required for most compatible devices.

1. **Identify the USB-C Port:** Locate the USB-C port on your device (smartphone, tablet, laptop, etc.). This port is typically oval-shaped and reversible.

2. **Connect the Earbuds:** Gently insert the USB-C connector of the earbuds into your device's USB-C port. Ensure it is fully

seated for a secure connection.

3. **Audio Output Selection:** Your device should automatically detect the earbuds and route audio through them. If not, navigate to your device's audio settings and select the connected earbuds as the output device.

4. **Adjust Volume:** Begin playing audio and adjust the volume using either your device's volume controls or the in-line remote control on the earbud cable.



Image: Simple plug-and-play connection of the USB-C earbuds to a mobile device.

## OPERATING INSTRUCTIONS

The earbuds feature an in-line remote control for convenient management of audio playback and calls.

# Remote Control
## Make your mobile phone use more convenient



◄)) Increase volume+

**Wake up Siri**

🎤 3S

**Music Control**

‖ X 1    ▶ X 2    ◄ X 3

**Call Control**

📞 X1    ➘ X1    📵 X1

◄) Decrease volume-

Image: Detailed diagram of the in-line remote control functions.

## Music Control:

- **Play/Pause:** Press the center button once.
- **Next Track:** Press the center button twice quickly.
- **Previous Track:** Press the center button three times quickly.
- **Volume Up:** Press the "+" button.
- **Volume Down:** Press the "-" button.

## Call Control:

- **Answer/End Call:** Press the center button once.
- **Reject Call:** Press and hold the center button.

## Voice Assistant:

- **Activate Voice Assistant (e.g., Siri):** Press and hold the center button for 3 seconds.

## MAINTENANCE AND CARE

Proper care will extend the lifespan of your earbuds and maintain optimal performance.

- **Cleaning:** Gently wipe the earbuds and cable with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earbuds in a clean, dry place, preferably in a small pouch or case to prevent tangling and damage.
- **Avoid Moisture:** Do not expose the earbuds to water, excessive humidity, or extreme temperatures.
- **Handle with Care:** Avoid pulling on the cable directly when disconnecting from your device. Always grasp the USB-C connector.

# Durable Headphone Cable

the premium TPE material of the headset
ensures a durable and flexible cable

Image: The durable TPE material of the headphone cable ensures longevity and flexibility.

## TROUBLESHOOTING

If you encounter issues with your earbuds, please refer to the following common solutions:

| Problem | Possible Cause | Solution |
|---------|----------------|----------|

| Problem | Possible Cause | Solution |
|---|---|---|
| No sound from earbuds. | Earbuds not fully plugged in. Device volume too low or muted. Incorrect audio output selected on device. Earbuds or device port damaged. | Ensure the USB-C connector is fully inserted. Increase device volume and check for mute. Check device audio settings and select the earbuds. Try earbuds with another device or another USB-C device with these earbuds to isolate the issue. |
| Microphone not working. | Microphone muted on device. Incorrect input device selected. Application permissions. | Check device microphone settings. Ensure the earbuds' microphone is selected as the input. Verify the application has microphone access. |
| Remote control not responding. | Incompatibility with device. Loose connection. | While widely compatible, some older or non-standard devices may have limited remote functionality. Ensure the USB-C connector is firmly plugged in. |

## SPECIFICATIONS

| Feature | Detail |
|---|---|
| Model Name | LK-FBA-215 |
| Connectivity Technology | Wired (USB-C) |
| Ear Placement | In Ear |
| Form Factor | In Ear |
| Color | White |
| Impedance | 32 Ohm |
| Audio Quality | Up to 24 bit/96 kHz (HiFi Stereo Sound) |
| Noise Control | Adaptive Noise Cancellation (Passive Noise Isolation) |
| Built-in Features | Microphone, In-line Remote Control (Volume+/-, Track Skip, Call Answer/End/Reject, Voice Assistant) |
| Cable Material | High-quality TPE wire with oxygen-free copper wire core |
| Weight | 0.634 ounces |

# 3D Stero Pure Tone

## Shocking 3D stereo, the real sound restores the real feeling.

Image: Illustration of the internal components contributing to 3D Stereo Pure Tone sound.

Image: Visual representation of the strong bass and 360-degree premium surround sound experience.

## COMPATIBILITY

These USB-C headphones are widely compatible with a variety of devices that feature a USB-C audio port. This includes, but is not limited to:

- **iPhone:** iPhone 15/15 Plus/15 Pro/15 Pro Max, iPhone 16/16 Plus/16 Pro/16 Pro Max
- **iPad:** iPad Pro 2020/2018/2022, iPad Air 4th/5th Gen, iPad Mini 6th Gen
- **Samsung Galaxy:** S24/S23/S22/S21/S21 Plus/S21 Ultra/S20 FE/S20/S20 Plus/S20 Ultra, Z Flip/Fold series, Note 20/Note 20 Ultra/Note 10/10 Plus, A53/A33, Galaxy Tab S8+ 5G
- **Google Pixel:** Pixel 8/7/6/5/4XL/4/3XL/3/2XL/2
- **OnePlus:** 11/10/9/Nord/8T/8 Pro/8/7T Pro/7T/7
- **Other Devices:** Compatible with MacBook/MacBook Pro, Huawei Mate/P series, Xiaomi Mi series, OPPO Find X/Reno series, and more devices without a 3.5mm audio jack.

# Compatible with Most USB-C Devices

## Compatible List(incomplete)

- ⭐ Samsung Galaxy S23 Ultra/S23/S23,S22 Ultra/S22+/S22, S21 Ultra/S21 FE/S21 5G,S20/S20 Ultra,Note 20,A53/A54 /A34,ZFold/Fip 5/4/3/2

- ⭐ iPhone16/16Plus/16Pro/16Pro Max iPhone15/15Plus/15Pro/15Pro Max

- ⭐ Huawei Mate 60/Mate 50/Mate 40 Pro/Mate 40 X2/P60/P50/ P40 Pro/P40/P30 Pro /P20 Pro/P20

- ⭐ 12.9'iPad Pro 6th/5th/4th/3rd gen,11'iPad Pro 4th/3rd/2nd GeriPad Air 5th/4th,iPad mini 6th

- ⭐ Xiaomi Mi 12/11/11Pro/10/10Pro/10T/9

- ⭐ OnePlus 10T/10 Pro/9/Nord/8T/8/7T/7/6T

- ⭐ Google Pixel 8 Pro 7a 76a 6 5 4 3 2 XL

- ⭐ Macbook Air/Macbook Pro

- ⭐ OPPO Find X5/X5 Pro/Find X2/X2 Pro

Image: The earbuds are compatible with a wide range of USB-C enabled devices.

## COMFORT AND DESIGN

The esbeecables earbuds are engineered for a comfortable and secure fit, minimizing discomfort even during extended use.

- **Ergonomic In-Ear Design:** Shaped to fit securely within the ear canal, providing both comfort and effective passive noise isolation.
- **Lightweight Construction:** Designed to be light, reducing ear fatigue.

# Comfortable Wearing Experience

Fits your ears better, not easy to fall off, perfect balance between quality and comfort

Ear Comfort

Tilt Wearing

Lighter Weight

Image: Features highlighting the comfortable wearing experience of the earbuds.

Image: Earbuds in use during various activities, demonstrating their versatility and comfortable fit.

## WARRANTY AND SUPPORT

esbeecables provides a comprehensive warranty and dedicated customer support for your product.

- **Warranty:** Your purchase is covered by a 48-month worry-free warranty.
- **Returns:** Enjoy a 60-day return policy without any specific reason required.
- **Customer Service:** For any problems or inquiries, please do not hesitate to contact our 24/7 friendly customer service. Refer to your purchase documentation or the seller's contact information for support channels.