

## CQH CQH-H01

# CQH Mini Body Camera Video Recorder (Model CQH-H01) User Manual

## 1. INTRODUCTION

---

This manual provides detailed instructions for the operation and maintenance of your CQH Mini Body Camera Video Recorder, Model CQH-H01. Please read this manual thoroughly before using the device to ensure proper functionality and to maximize its lifespan. This device is designed for portable video and audio recording in various environments.

## 2. PRODUCT OVERVIEW

---

### 2.1 Package Contents

- CQH Mini Body Camera (Model CQH-H01)
- USB Data Cable

### 2.2 Device Layout

Familiarize yourself with the various components and controls of your body camera:



## Recording While Charging and External TF card up to 128GB.

(Card not included)



**No WIFI, cannot connect to mobile phone**  
Read video data through computer and card reader

*Image 2.2.1: Front and side view of the CQH Mini Body Camera, highlighting key features and controls.*

- **Indicator Light:** Displays device status (e.g., charging, recording, standby).
- **Record/Save Key (Audio):** Initiates and saves audio-only recordings.
- **Record/Save Key (Video):** Initiates and saves video recordings.
- **Night Vision On/Key:** Activates or deactivates night vision mode.
- **Reset Hole:** Used to reset the device if it becomes unresponsive.
- **Power On/Off Key:** Turns the device on or off.
- **Back Magnet:** Allows for magnetic attachment to metal surfaces.
- **TF Card Slot:** For inserting a Micro SD card (up to 128GB, not included).
- **Microphone (MIC):** Captures audio during recordings.
- **Receiving Aperture:** Light sensor for automatic adjustments.
- **Rotatable Lens:** The camera lens can rotate 90 degrees for flexible viewing angles.

### 3. SETUP

#### 3.1 Inserting a Micro SD Card

A Micro SD card (TF card) is required for storing recordings. The device supports cards up to 128GB. The card is not included with the product.

1. Locate the TF Card slot on the side of the camera.
2. Gently insert the Micro SD card into the slot with the gold contacts facing down until it clicks into place.
3. To remove, push the card in slightly until it springs out.

## MORE USAGE SCENARIOS



Image 3.1.1: Illustration of Micro SD card insertion into the camera.

### 3.2 Charging the Device

Before first use, fully charge the camera. The device can record while charging.

1. Connect the provided USB data cable to the camera's charging port.
2. Connect the other end of the USB cable to a USB power source (e.g., computer USB port, USB wall adapter, power bank).
3. The indicator light will show the charging status. Refer to the indicator light section for specific light patterns.
4. A full charge typically takes approximately 2-3 hours.

## 4. OPERATING INSTRUCTIONS

## 4.1 Power On/Off

- **To Power On:** Press and hold the **Power On/Off Key** for a few seconds until the indicator light illuminates.
- **To Power Off:** Press and hold the **Power On/Off Key** for a few seconds until the indicator light turns off.

## 4.2 Video Recording

The camera records video in 1080P resolution.

1. Ensure the device is powered on and a Micro SD card is inserted.
2. Press the **Record/Save Key (Video)** once to start video recording. The indicator light will change to indicate recording is in progress.
3. To stop and save the video, press the **Record/Save Key (Video)** again. The indicator light will revert to standby mode.

## 4.3 Audio Recording

The camera can record audio independently.

1. Ensure the device is powered on and a Micro SD card is inserted.
2. Press the **Record/Save Key (Audio)** once to start audio recording. The indicator light will change to indicate audio recording is in progress.
3. To stop and save the audio file, press the **Record/Save Key (Audio)** again. The indicator light will revert to standby mode.

## 4.4 Night Vision

The camera features automatic night vision for low-light conditions.

- **To Activate/Deactivate:** Press the **Night Vision On/Key** to toggle night vision mode. The camera may automatically adjust based on ambient light.

## 4.5 Lens Rotation

The camera lens can be manually rotated 90 degrees to adjust the recording angle without repositioning the entire device.



Image 4.5.1: The camera's 90-degree rotatable lens allows for versatile mounting and recording angles.

## 4.6 Video Demonstration

Your browser does not support the video tag.

Video 4.6.1: A brief overview of the CQH Mini Body Camera's features and design.

## 5. VIEWING RECORDED FILES

The CQH Mini Body Camera does not have Wi-Fi or an app and cannot connect directly to a mobile phone. To view recorded files, you must transfer them to a computer.

1. **Method 1: Connect to Computer:** Power off the camera. Connect the camera to your computer using the provided USB data cable. The camera will appear as a removable disk. Open the disk to access your video and audio files.
2. **Method 2: Use a Card Reader:** Remove the Micro SD card from the camera. Insert the Micro SD card into a compatible card reader, then connect the card reader to your computer. Access the files from the card reader.

Recorded files are typically in MP4 format for video.

## 6. MAINTENANCE

---

- Keep the camera clean and free from dust and debris. Use a soft, dry cloth for cleaning.
- Avoid exposing the camera to extreme temperatures, direct sunlight, or high humidity.
- Do not attempt to disassemble or repair the device yourself, as this will void the warranty.
- Store the camera in a cool, dry place when not in use.
- Charge the battery regularly, even if not in use, to maintain battery health.

## 7. TROUBLESHOOTING

---

- **Device not turning on:** Ensure the battery is charged. If the issue persists, try resetting the device using a thin pin in the reset hole.
- **Cannot record:** Check if a Micro SD card is properly inserted and has sufficient free space. Ensure the battery is not critically low.
- **Files not playing on computer:** Ensure your computer has the necessary codecs to play MP4 files. Try a different media player.
- **Indicator light not responding:** Try resetting the device.
- **Video quality issues:** Ensure the lens is clean and free from smudges. Record in well-lit environments for optimal results.

## 8. SPECIFICATIONS

---

| Feature                  | Specification   |
|--------------------------|---|
| Model Name               | H01   |
| Video Capture Resolution | 1080p   |
| Video Capture Format     | MP4   |
| Lens Rotation            | 90 degrees  |
| Storage                  | Supports Micro SD card up to 128GB (not included)         |
| Connectivity             | Wired (USB for data transfer/charging), No WiFi, No APP   |
| Power Source             | Battery Powered (1 9V battery included)                   |
| Recording Time           | Up to 5 hours of video recording                          |
| Special Features         | Night Vision, Portable, Built-in Magnet, Back Clip Design |
| Dimensions (L x W x H)   | 0.79 x 1.02 x 3.27 inches                                 |
| Item Weight              | 2.08 ounces   |
| Material                 | Plastic   |

## 9. WARRANTY AND SUPPORT

---

For warranty information or technical support, please refer to the product packaging or contact CQH customer

service through the retailer where the product was purchased. Keep your purchase receipt as proof of purchase.