

Vu 55VIBE-DV

Vu Vibe Series 4K QLED Smart Google TV 55VIBE-DV User Manual

Model: 55VIBE-DV

Introduction	Safety	Setup	Operation	Maintenance & Support	Troubleshooting	Specifications	Warranty
------------------------------	------------------------	-----------------------	---------------------------	---	---------------------------------	--------------------------------	--------------------------

1. INTRODUCTION

This user manual provides comprehensive instructions for the installation, operation, and maintenance of your Vu Vibe Series 4K QLED Smart Google TV, model 55VIBE-DV. Please read this manual thoroughly before using your television and retain it for future reference. This television features a 139cm (55 inches) 4K QLED display, integrated soundbar, and Google TV operating system for an enhanced viewing experience.



Image 1.1: Front view of the Vu Vibe Series 4K QLED Smart Google TV.

2. IMPORTANT SAFETY INFORMATION

Always adhere to the following safety precautions to prevent electric shock, fire, or damage to the television:

- Do not expose the television to rain or moisture.
- Do not open the television casing; refer all servicing to qualified personnel.
- Ensure proper ventilation around the television.
- Avoid placing the television near heat sources or in direct sunlight.
- Use only the power cord supplied with the television.
- Keep batteries out of reach of children.

3. SETUP GUIDE

3.1. What's in the Box

Before proceeding with the setup, verify that all components are present in the packaging:

- TV Unit (1 U)
- Remote Control (1 U)
- Power Cord (1 U)
- Welcome Kit Guide (1 U)
- Table Mount Stand (1 U)
- AAA Batteries (2 U)




Image 3.1: Contents included in the product packaging.

3.2. Stand Installation (Table Mount)

To install the table mount stand:

1. Carefully place the TV screen-down on a soft, flat surface to prevent scratches.

2. Align the stand legs with the screw holes on the bottom of the TV.
3. Secure the legs using the provided screws.

Note: A table mount stand is provided free of cost during installation by the Vu service team. Wall mount installation is chargeable. Customers can choose between a table top stand or a wall mount bracket during the service visit.



Image 3.2: The Vu Vibe Series TV securely placed on its table mount stand.

3.3. Connecting Peripherals

Your Vu Vibe Series TV offers various connectivity options:

- **HDMI Ports:** Connect set-top boxes, Blu-ray players, gaming consoles (HDMI 2.1 for gaming).
- **USB Ports:** Connect hard drives and other USB devices.
- **Wi-Fi:** Connect to 2.4/5GHz networks for internet access.
- **Bluetooth 5.3:** Connect headphones or other Bluetooth audio devices.

- **Ethernet (LAN):** For a wired internet connection.
- **Optical Audio Out:** For connecting to external audio systems.




Image 3.3: Detailed view of the TV's rear connectivity ports.

3.4. Initial Power On and Google TV Setup

After connecting the power cord, press the power button on the remote. Follow the on-screen instructions to complete the initial Google TV setup, including network connection, Google account login, and channel scanning.

4. OPERATING YOUR TV

4.1. Remote Control Functions

The ActiVoice Remote Control provides intuitive navigation and quick access to features:

- **Voice Assistant:** Use voice commands for search and control.

- **Hotkeys:** Dedicated buttons for Netflix, YouTube, Picture, Sound, Cricket, and Cinema modes.
- **IR and Bluetooth:** The remote operates via both infrared and Bluetooth technologies.



Image 4.1: The ActiVoice Remote Control for the Vu Vibe Series TV.

4.2. Smart TV Features (Google TV)

Your TV runs on the Google TV OS, offering a personalized experience:

- **Google App Search:** Easily find content across various streaming services.
- **Built-in Chromecast:** Cast content directly from your smartphone or tablet.
- **Pre-installed Apps:** Access popular streaming platforms like Netflix, YouTube, Prime Video, Disney+ Hotstar, and more.

What's in the box

- LED TV x 1
- Remote Control x 1
- AC Power Cord x 1
- AAA Batteries x 2
- Welcome Kit x 1



Wall Mount and Stand Options

(Wall mount is chargeable and stand option is free - Provided during installation)

43" – 75"

Fixed Wall Mount Bracket Only

Note: No stand is provided inside the box; The Vu service team will provide table top stand free of cost during installation. Customer can choose between a table top stand or wall mount bracket.

Image 4.2: The Google TV interface displaying available streaming applications.

4.3. Picture and Sound Settings

Customize your viewing and listening experience:

- **Display:** Enjoy 4K QLED with Dolby Vision, HDR10, and HLG support. Features include Filmmaker Mode, Cricket Mode, Cinema Mode, AI Picture Smart Scene & Upscale, and MEMC for smooth motion.
- **Sound:** The integrated 88-Watt soundbar with Dolby Atmos delivers powerful audio. Utilize Dialogue Clarity, Deep Bass, Audio Only Mode, and Auto Volume Control.



INTEGRATED
SOUNDBAR



MUSIC
ECOSYSTEM



DOLBY
ATMOS



VOICE CLARITY
SOUNDBAR

Image 4.3: Key audio features of the Vu Vibe Series TV, including the integrated soundbar and Dolby Atmos.

5. MAINTENANCE

To ensure the longevity and optimal performance of your television:

- **Cleaning the Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner. Avoid harsh chemicals.
- **Cleaning the Casing:** Use a soft, dry cloth to wipe the TV casing.
- **Ventilation:** Ensure the ventilation openings are not blocked to prevent overheating.
- **Power Cord:** Regularly check the power cord for any damage.

6. TROUBLESHOOTING

Refer to the following table for common issues and their solutions:

Problem	Possible Cause	Solution
No picture, no sound	Power cord disconnected; no power to outlet.	Ensure power cord is securely connected and outlet has power.
No sound, but picture is present	Volume muted or too low; incorrect audio output setting.	Increase volume; check audio settings and external audio connections.
Remote control not working	Batteries depleted; obstruction between remote and TV.	Replace batteries; remove any obstructions; ensure remote is paired via Bluetooth if applicable.
Poor picture quality	Weak signal; incorrect picture settings.	Check antenna/cable connection; adjust picture settings (brightness, contrast, etc.).
Smart features not working	No internet connection.	Check Wi-Fi or Ethernet connection; restart router.

7. TECHNICAL SPECIFICATIONS

Detailed specifications for the Vu Vibe Series 4K QLED Smart Google TV 55VIBE-DV:

Feature	Description
Brand	Vu
Model	55VIBE-DV
Screen Size	55 Inches (139cm)
Display Technology	QLED
Resolution	4K (3840x2160 Pixels)
Refresh Rate	60 Hz
Viewing Angle	178 Degrees
Brightness	400 Nits Peaking Brightness
Operating System	Google TV
Processor	1.5GHz VuOn™ Processor
RAM	2 GB
Storage	16 GB
Sound Output	88 Watts (Integrated Soundbar)
Audio Technology	Dolby Atmos, Dolby Digital Plus
HDMI Ports	3 (HDMI 2.1, HDMI CEC & eARC/ARC)
USB Ports	2
Wireless Connectivity	2.4/5GHz Wi-Fi, Bluetooth 5.3

Feature	Description
Dimensions (LxWxH)	27.4 x 123.4 x 76.8 cm
Item Weight	12.3 kg
Power Source	AC (230 Volts, 120 Watts)
Included Components	TV Unit, Remote Control, Power Cord, Welcome Kit Guide, Table Mount Stand, AAA Batteries



- **IR** and **Bluetooth** Remote
- Remote with **Voice Assistant**
- **Wi-Fi**, **Picture** and **Sound** Hotkeys
- **Cricket** and **Cinema** Mode Hotkeys

Image 7.1: Physical dimensions and weight of the Vu Vibe Series TV.

8. WARRANTY AND SUPPORT

Your Vu Vibe Series TV comes with the following warranty:

- **Television Set:** 1-year manufacturer warranty from the date of purchase.

- **Remote Control:** 6-month warranty.

Warranty claims can be processed using your Amazon e-invoice. For customer support, you can contact Vu Technologies Pvt. Ltd. at:

- **Phone:** +91 022-45417000
- **WhatsApp:** +91 9867740000
- **Email:** support@vutvs.com

The user guide and manual are also available on the brand's website under the repair & customer support section.

© 2025 Vu Technologies Pvt. Ltd. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I play set-top box sound through an amplifier using the Vu 55VIBE-DV TV?

To play sound from your set-top box through an amplifier using your Vu 55VIBE-DV TV, you will need to utilize the TV's audio output capabilities. The Vu 55VIBE-DV TV is equipped with an 'Optical...

[Read full answer](#)

Why can I not access data on my external hard disk with the upgraded Vu Vibe Series 4K QLED TV when it works on older Vu TV models?

This issue often occurs because newer Google TV-based models, like the Vu Vibe Series 4K QLED (55VIBE-DV), have stricter requirements for file systems and drive health than older "basic" versions of Vu TVs. If...

[Read full answer](#)