

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SUSTEAS](#) /

› [SUSTEAS 10-in-1 Nut Milk Maker Machine User Manual - Model B0FBWCD385](#)

## SUSTEAS B0FBWCD385

# SUSTEAS 10-in-1 Nut Milk Maker Machine User Manual

Model: B0FBWCD385

## INTRODUCTION

---

Thank you for choosing the SUSTEAS 10-in-1 Nut Milk Maker Machine. This versatile appliance is designed to simplify the preparation of various homemade beverages and foods, including nut milks, soy milk, juices, milkshakes, porridges, and baby food. Please read this manual thoroughly before first use to ensure safe operation, optimal performance, and proper maintenance of your machine.



Image: The SUSTEAS 10-in-1 Nut Milk Maker Machine, showcasing its sleek design and the variety of drinks it can produce, including nut milk, juice, and a strawberry milkshake.

## PRODUCT FEATURES

- **10-in-1 Versatility:** This machine offers ten functions, including Hot Beverage Mode (nut milk, porridge, baby food, soup, keep warm at 131°F) and Cold Beverage Mode (juice, milkshake, smoothie).
- **No Soaking, No Filtering:** Equipped with a powerful motor and 8 sharp stainless steel blades, it efficiently processes nuts and beans. For hot drinks, it heats then blends, ensuring a smooth, grain-free texture without the need for pre-soaking or external filtering.
- **12-Hour Delay Start & Smart Self-Cleaning:** Plan your beverages with a 1-12 hour delay timer. The 2-hour automatic keep-warm function maintains temperature, adjustable from 1-10 hours. A one-touch self-cleaning cycle heats water for thorough, residue-free cleaning.
- **Elegant Design & Complete Accessories:** The beige design complements any kitchen. It includes a measuring cup, cleaning brush, user manual, and power cable.
- **Capacity:** The machine has a 34oz (Cold Max) capacity. For hot beverages and self-cleaning, do not exceed 22oz (Hot Max) to prevent spills.



# 340Z Large Capacity

Enough for the Whole Family



Nuts milk



Porridge



Baby food



Soup



Juice



Milk shake



Smoothie



Keep warm  
131°F



Dry



Clean

Image: Visual representation of the 10 functions available on the SUSTEAS Nut Milk Maker, including various milk types, porridges, and juices.

## WHAT'S INCLUDED

Upon unpacking, please ensure all the following components are present:

- SUSTEAS Nut Milk Maker Machine (Main Unit)
- Lid
- Measuring Cup
- Cleaning Brush
- Power Cable
- User Manual (This document)



Image: All accessories included with the SUSTEAS Nut Milk Maker, such as the measuring cup, cleaning brush, and power cable.

## IMPORTANT SAFETY INSTRUCTIONS

To prevent personal injury or property damage, please adhere to the following safety precautions:

- Always ensure the machine is placed on a stable, flat, and dry surface.
- Do not immerse the main unit (motor base) in water or other liquids.
- Keep out of reach of children. Close supervision is necessary when the appliance is used near children.
- Unplug the machine from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Always ensure the lid is securely in place before operating.
- Do not exceed the maximum fill lines indicated for hot (22oz) and cold (34oz) beverages to prevent overflow.
- Use only manufacturer-recommended attachments.
- Exercise caution when handling hot liquids and steam.

## SETUP AND FIRST USE

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, wash the pitcher, lid, and measuring cup with warm, soapy water. Rinse thoroughly and dry. Wipe the main unit with a damp cloth.
3. **Placement:** Place the machine on a stable, dry, and level surface.
4. **Connect Power:** Plug the power cable into a standard electrical outlet.
5. **Initial Cleaning Cycle:** For optimal hygiene, it is recommended to run a self-cleaning cycle with water before preparing any food or drink. Add water up to the "Hot Max" line (approx. 22oz), secure the lid, and select the "Clean" function.

## OPERATING INSTRUCTIONS

## General Operation

1. Add desired ingredients to the pitcher. Ensure ingredients and liquid do not exceed the indicated MAX fill lines (22oz for hot, 34oz for cold).
2. Securely place the lid on the pitcher. The machine will not operate if the lid is not properly closed.
3. Press the **Menu** button to cycle through the available functions.
4. Once the desired function is selected, press the **ON/OFF** button to start the program.
5. The machine will automatically complete the selected program and may beep to indicate completion.



Image: Close-up of the control panel, highlighting the 'Preset', 'Menu', and 'ON/OFF' buttons, along with the various program options like 'Nuts milk', 'Porridge', 'Juice', and 'Clean'.

## Hot Beverage Mode (e.g., Nut Milk, Soy Milk, Porridge, Soup, Baby Food)

- Add ingredients (e.g., nuts, beans, grains) and water up to the "Hot Max" line (approx. 22oz).
- Select the appropriate program (e.g., "Nuts milk", "Porridge").
- The machine will heat the ingredients, then blend them to a smooth consistency. No pre-soaking or filtering is required for most recipes.

## Cold Beverage Mode (e.g., Juice, Milkshake, Smoothie)

- Add fruits, vegetables, ice, and liquids up to the "Cold Max" line (approx. 34oz).
- Select the desired program (e.g., "Juice", "Milkshake", "Smoothie").
- The machine will blend ingredients to your desired consistency.

## 12-Hour Delay Start Function

1. Add ingredients and water to the pitcher.
2. Press the **Preset** button. Use the **Menu** button to adjust the delay time in 10-minute increments (1-12 hours).
3. Press **Preset** again to confirm the delay time.
4. Select your desired program using the **Menu** button.
5. Press the **ON/OFF** button to activate the delay start. The machine will begin processing after the set delay time.




Image: A visual guide to setting the 12-hour delay start, demonstrating how to prepare ingredients the night before for a fresh morning beverage.

## Automatic Keep-Warm Function

- After a hot beverage program finishes, the machine automatically enters a 2-hour keep-warm mode at 131°F.
- The keep-warm duration can be adjusted from 1 to 10 hours to suit your needs.



Image: The machine maintaining a beverage at 131°F, illustrating the automatic keep-warm function.

## CLEANING AND MAINTENANCE

### Smart Self-Cleaning Cycle

1. After use, remove any large food residues from the pitcher.
2. Add water up to the "Hot Max" line (approx. 22oz).
3. Secure the lid and select the "Clean" function from the menu.
4. Press the **ON/OFF** button to start the self-cleaning cycle. The machine will heat the water and agitate to clean the interior.
5. Once the cycle is complete, carefully empty the water and rinse the pitcher.

# Self-Cleaning

Our self-cleaning mode **heats water** first, ensuring a deeper clean than other methods.

## NOTE:

Add 14–27 oz of water.  
Do not exceed 27 oz to prevent spills



Image: The self-cleaning function in progress, with heated water circulating inside the pitcher for thorough cleaning.

## Manual Cleaning

- For stubborn residues, use the provided cleaning brush and warm, soapy water to scrub the interior of the pitcher and blades.
- The lid and measuring cup are dishwasher safe (top rack only) or can be hand-washed.
- Never immerse the main unit (motor base) in water. Wipe it clean with a damp cloth.
- Ensure all parts are completely dry before reassembling or storing.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Machine does not turn on.	Not plugged in; power outlet issue; lid not properly secured.	Check power connection; try a different outlet; ensure lid is firmly closed.

Problem	Possible Cause	Solution
Ingredients are not blending smoothly.	Too many ingredients; not enough liquid; ingredients too large.	Reduce ingredient quantity; add more liquid; cut ingredients into smaller pieces.
Overflow during operation.	Exceeded MAX fill line.	Always adhere to the "Hot Max" (22oz) and "Cold Max" (34oz) fill lines.
Unusual noise or odor.	Foreign object in pitcher; motor overheating.	Immediately turn off and unplug. Check for obstructions. Allow motor to cool if overheated. If problem persists, contact support.

## SPECIFICATIONS

---

**Brand:** SUSTEAS

**Model:** B0FBWCD385

**Color:** Beige

**Capacity:** 34oz (Cold Max), 22oz (Hot Max)

**Product Dimensions:** 7.48"D x 7.48"W x 15.16"H

**Item Weight:** 5.66 pounds

**Power Source:** AC

**Voltage:** 120V

**Controls Type:** Touch Control Panel

**Blade Material:** Stainless Steel

**Container Material:** Glass

**Special Features:** Adjustable Time, Auto Shut Off, Automatic Cleaning, Keep Warm Setting, Touch Control Panel

**Material Type Free:** BPA Free

## Sleek Milky White Aesthetic, Perfect for Modern Kitchen Styling



Image: Diagram illustrating the dimensions (height, width, depth) of the SUSTEAS Nut Milk Maker.

### WARRANTY AND SUPPORT

The SUSTEAS Nut Milk Maker Machine is backed by a **1-Year Assurance** for worry-free purchasing. Should you have any questions, concerns, or require technical assistance, please do not hesitate to contact our dedicated support team. Refer to the contact information provided on the product packaging or the official SUSTEAS website for assistance.

For more information and product registration, visit the official [SUSTEAS Store](#).

Related Documents - B0FBWCD385



[SUSTEAS SL-107A Electric Grill Instruction Manual](#)

Comprehensive instruction manual for the SUSTEAS SL-107A Electric Grill, covering safety precautions, operating components, handling, usage tips, cleaning, and product specifications.



[Susteas Electric Steamer Instruction Manual](#)

This instruction manual provides detailed information on the safe operation, application, cleaning, and maintenance of the Susteas Electric Steamer. It includes technical specifications, product structure diagrams, operation panel guidance, and fault analysis.



[SUSTEAS Vegetable Grater Instruction Manual](#)

Comprehensive guide for the SUSTEAS Vegetable Grater, covering product parts, installation, blade changing, materials, and environmental disposal information.