

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [UGREEN](#) /

› [UGREEN Finder 2 Item Tracker User Manual Model 75119P](#)

UGREEN 75119P

UGREEN Finder 2 Item Tracker User Manual

Model: 75119P

1. INTRODUCTION

The UGREEN Finder 2 is a compact item tracker designed to help you locate your valuable belongings quickly and efficiently. Utilizing wireless technology, it connects to your smartphone, allowing you to pinpoint the location of attached items within its operational range. This manual provides detailed instructions for setting up, operating, and maintaining your UGREEN Finder 2.

2. PACKAGE CONTENTS

Please check the package for the following items:

- UGREEN Finder 2 Item Tracker
- USB Charging Cable
- User Manual (this document)



Image 2.1: Contents of the UGREEN Finder 2 package. The image displays four UGREEN Finder 2 item trackers, each with a dark grey finish and a circular button, along with two USB charging cables (one USB-A to USB-C and one USB-C to USB-C).

3. SETUP

3.1 Charging the Device

The UGREEN Finder 2 comes with a built-in rechargeable Lithium Polymer battery. Before first use, it is recommended to fully charge the device.

1. Connect the provided USB charging cable to the charging port on the UGREEN Finder 2.
2. Connect the other end of the USB cable to a standard USB power adapter (not included) or a computer's USB port.
3. The indicator light on the device will show charging status (e.g., red for charging, green for fully charged).
4. Once fully charged, disconnect the cable.

3.2 Pairing with Your Smartphone

To use the UGREEN Finder 2, you need to download the official UGREEN app on your smartphone.

1. Download the **UGREEN App** from your smartphone's app store (iOS App Store or Google Play Store).
2. Open the UGREEN App and follow the on-screen instructions to create an account or log in.
3. Ensure your smartphone's Bluetooth is enabled.
4. In the app, select the option to add a new device.
5. Press and hold the circular button on the UGREEN Finder 2 until it enters pairing mode (e.g., an indicator light flashes).
6. Select the UGREEN Finder 2 from the list of available devices in the app to complete the pairing process.
7. You may be prompted to name your Finder 2 (e.g., "Keys," "Wallet").

4. OPERATING INSTRUCTIONS

4.1 Locating an Item

Once paired, you can use the UGREEN App to locate your item.

1. Open the UGREEN App on your smartphone.
2. Select the specific UGREEN Finder 2 you wish to locate from your list of devices.
3. Tap the "Ring" or "Find" button within the app.
4. The UGREEN Finder 2 will emit an audible sound, helping you to locate your item.

4.2 Using the Finder 2 Button

The circular button on the UGREEN Finder 2 may have additional functions, such as:

- **Silence Alarm:** Press the button once to stop the ringing sound when locating.
- **Reverse Find (if supported):** Double-press the button to make your paired smartphone ring (even on silent mode), helping you find your phone. Refer to the app for specific feature availability.

5. MAINTENANCE

5.1 Cleaning

To clean your UGREEN Finder 2, gently wipe it with a soft, dry, lint-free cloth. Avoid using abrasive cleaners, solvents, or aerosol sprays, as these may damage the device.

5.2 Battery Care

The UGREEN Finder 2 uses a built-in rechargeable Lithium Polymer battery. To prolong battery life:

- Avoid exposing the device to extreme temperatures.
- Charge the device regularly, especially if it has not been used for an extended period.
- Do not attempt to replace the battery yourself, as this may damage the device and void the warranty.

6. TROUBLESHOOTING

If you encounter issues with your UGREEN Finder 2, please refer to the following common solutions:

- **Device not connecting/pairing:**

- Ensure the UGREEN Finder 2 is charged.
- Make sure Bluetooth is enabled on your smartphone.
- Restart your smartphone and the UGREEN Finder 2 (if applicable, by pressing and holding the button for a few seconds).
- Ensure the device is within the Bluetooth range of your smartphone.

- **Device not ringing:**
 - Check the volume settings within the UGREEN app.
 - Ensure the device is charged.
 - Verify that the device is still connected to your smartphone via the app.

- **Short battery life:**
 - Ensure the device is fully charged before use.
 - Avoid extreme temperatures.
 - Frequent use of the ringing feature may consume more battery.

For further assistance, please contact UGREEN customer support.

7. SPECIFICATIONS

- **Model Number:** 75119P
- **Connectivity:** Wireless (Bluetooth)
- **Battery:** 1 Lithium Polymer battery (included, rechargeable)
- **Item Weight:** 3.53 ounces
- **Package Dimensions:** 5.31 x 5.31 x 0.67 inches
- **Manufacturer:** Ugreen Group Limited
- **Date First Available:** June 16, 2025

8. WARRANTY AND SUPPORT

UGREEN products are designed with quality and reliability in mind. For warranty information and customer support, please refer to the warranty card included with your product or visit the official UGREEN website. You can also contact UGREEN customer service directly for technical assistance or inquiries regarding your UGREEN Finder 2.