

PAXA Ctbuds03

PAXA Ctbuds03 2-in-1 Wireless Earbuds User Manual

Brand: PAXA | Model: Ctbuds03

INTRODUCTION

The PAXA Ctbuds03 offers a versatile 2-in-1 design, combining clip-on open-ear headphones with traditional wireless in-ear earbuds. This allows users to seamlessly switch between different listening experiences to suit various scenarios, from active outdoor use to focused indoor work. Featuring advanced Bluetooth 6.0 technology, these earbuds provide stable connectivity, high-fidelity sound, and an impressive 140-hour ultra-long playtime with the charging case. Designed for comfort and durability, they are IPX5 water-resistant, making them suitable for sports and daily use.



Image: PAXA Ct buds03 2-in-1 Wireless Earbuds in C-Purple, showcasing both the clip-on and in-ear styles, along with the unique rotating charging case.

WHAT'S IN THE BOX

- Clip on Earbuds x2
- In Ear Earbuds x2
- Charging Case x1
- User Manual x1
- Type-C Charging Cable x1

PAXA-Ctbuds

 Answer/End call Double click either earbud	 Reject Call Press and hold either earbud for 2 seconds
 Voice Assistant Hold both earbud for 2 seconds	 Play/Pause Double click either earbud
 Previous Song Triple-click the left (L) earbud	 Next song Triple-click the left (R) earbud
 Volume + Click the right (R) earbud	 Volume - Click the left (L) earbud




Image: A visual representation of all items included in the PAXA Ctbuds03 product package.

SETUP


Initial Charging

Before first use, ensure the charging case and earbuds are fully charged. The first full charge requires 6-8 hours to activate the battery. Subsequent full charges typically take about 2.5 hours.

- Connect the provided Type-C charging cable to the charging port on the case and a compatible USB power source.
- During charging, the red light on the earbud case will flash.
- Once fully charged, the red light will become steady.

140H Ultra Battery Life

Anytime to keep going, no need to wait for charging, just switch in a second



Fast Charging

⚡ 10Mins Fast Charging= ▶ 3Hrs Playtime

Image: The PAXA Ct buds03 charging case being charged via a USB-C cable, illustrating the fast charging capability.

Bluetooth Pairing

The PAXA Ct buds03 utilizes Bluetooth 6.0 for ultra-stable and low-latency connections.

1. Ensure the earbuds are in the charging case and the case has sufficient charge.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, laptop), go to Bluetooth settings and turn Bluetooth on.
4. Search for available devices. You should see "PAXA Ct buds" or a similar name.
5. Select the earbuds to connect. Once connected, you will hear an audible confirmation.

Latest Bluetooth 6.0 Chip

Faster and more stable pairing, clearer vocals, and richer bass



PAXA Ct buds

Feature

Others

LC3 encoding, near lossless (CD level)



Sound



Normal

Less than 50 ms



Latency



150-200ms

30-50 meters



Connection distance



10-30 meters

Smart avoidance of Wi-Fi



Interference resistance



Prone to Wi-Fi interference

8-10H of battery life



Power



5-8H of battery life

Image: A technical comparison highlighting the benefits of the Bluetooth 6.0 chip in PAXA Ct buds, including lower latency and wider connection distance.

OPERATING INSTRUCTIONS


Switching Earbud Styles

The PAXA Ct buds03 comes with two distinct earbud styles: clip-on open-ear and traditional in-ear. You can easily switch between them based on your activity and environment.

- **Clip-on Open-Ear:** Ideal for outdoor activities where situational awareness is crucial. They allow you to hear your surroundings while enjoying audio.
- **In-Ear:** Perfect for quiet environments like studying or working, providing privacy and minimizing sound leakage.

PAXA 2 in 1 Clip On Open Ear Earbuds

No more dead batteries or scene-hopping compromises.
Never choose between – own two pairs!



Ergonomically Designed
for all day Wearing Comfort



Image: A visual demonstration of the PAXA 2-in-1 earbuds, showing how to switch between the clip-on and in-ear designs for different uses.

Switching Scene Need Anytime, Anywhere

Double stable and comfortable fit to the ears, enjoying the perfect balance between audio clarity and situational awareness



Image: Examples of different scenarios where the PAXA Ct buds03 can be used, including sports, work, and commuting.

Touch Controls

The earbuds feature intuitive touch controls for managing audio playback and calls.

Action	Control
Answer/End Call	Double click either earbud
Reject Call	Press and hold either earbud for 2 seconds
Voice Assistant	Hold both earbuds for 2 seconds
Play/Pause	Double click either earbud
Previous Song	Triple-click the left (L) earbud
Next Song	Triple-click the right (R) earbud

Action	Control
Volume +	Click the right (R) earbud
Volume -	Click the left (L) earbud

Total **140H**
Ultra Playtime

12_H
Single Charge

140_H
with Charging Case

100_{days}
standby time




Image: A detailed diagram illustrating the touch control functions for the PAXA Ct buds03 earbuds.

MAINTENANCE

Water Resistance (IPX5)

The PAXA Ct buds03 earbuds are IPX5 water-resistant, meaning they are protected against low-pressure water jets from any direction. This makes them suitable for workouts and light rain. However, they are not designed for submersion in water or heavy water exposure.

- Do not immerse the earbuds or charging case in water.
- Avoid exposing them to saltwater or other corrosive liquids.
- If they get wet, wipe them dry with a clean, soft cloth before placing them back in the charging case or using them.

IPX5 Water Resistant

Designed for sports and fitness enthusiasts, built to withstand heavy sweat and rain without missing a beat



Image: A person wearing PAXA Ctbuds03 earbuds in light rain, demonstrating their IPX5 water resistance.

Cleaning and Storage

- Regularly clean the earbuds and charging contacts with a dry, soft, lint-free cloth.
- Avoid using abrasive materials, alcohol, or chemical cleaners.
- Store the earbuds in their charging case when not in use to protect them and ensure they are charged for next use.
- Keep the device away from extreme temperatures and direct sunlight.

TROUBLESHOOTING

No Sound or Disconnection

- Ensure the earbuds are charged.
- Check if Bluetooth is enabled on your device and the earbuds are connected.
- Try placing the earbuds back in the case, closing it, and then reopening to re-establish the connection.

- If issues persist, try unpairing the earbuds from your device's Bluetooth settings and then re-pairing them.
- Ensure the earbuds are within the Bluetooth range (up to 10 meters).

Charging Issues

- Verify the charging cable is securely connected to both the case and the power source.
- Ensure the charging contacts on both the earbuds and the case are clean and free of debris.
- Try using a different USB port or power adapter.
- Remember the initial activation charge requires 6-8 hours.

Unresponsive Touch Controls

- Ensure your fingers are clean and dry when using touch controls.
- Try restarting the earbuds by placing them in the case and taking them out again.

SPECIFICATIONS

Feature	Detail
Model Name	Ctbuds03
Connectivity Technology	Wireless
Wireless Communication Technology	Bluetooth
Bluetooth Version	6.0
Bluetooth Range	10 Meters
Ear Placement	Open Ear (with In-Ear option)
Form Factor	Over Ear / In Ear
Noise Control	Active Noise Cancellation (Hybrid Noise Reduction)
Battery Life (Earbuds)	4 Hours (single charge)
Total Playtime (with Charging Case)	Up to 140 Hours
Charging Time	2.5 Hours (earbuds + case)
Water Resistance Level	IPX5
Control Method	Touch
Audio Driver Type	Dynamic Driver (13mm)
Frequency Range	20 Hz - 20,000 Hz
Impedance	1 Ohm
Material	Metal, Plastic, Silicone
Item Weight	5 Ounces
Product Dimensions	3.05 x 0.98 x 2.78 inches

13mm Drivers Deliver Rich, Powerful Sound!

Precision-tuned 13mm drivers with enhanced frequency, experience thumping bass, crystal-clear vocals, and vibrant details in every beat



13mm
Driver

Image: An exploded view diagram illustrating the 13mm dynamic drivers responsible for the rich sound quality of the earbuds.

OFFICIAL PRODUCT VIDEO

Watch the official product video for a visual guide on the features and usage of the PAXA 2-in-1 Clip on Open Ear Headphones Wireless Earbuds.

Your browser does not support the video tag.

Video: A demonstration of the PAXA 2-in-1 Clip on Open Ear Headphones, showcasing their design, functionality, and how to switch between the two earbud styles. (Duration: 0:35)

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the product packaging or contact PAXA customer service directly. You may also visit the official PAXA store on Amazon for frequently asked questions and additional

resources.

Visit the PAXA Store on Amazon

© 2025 PAXA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question