

[Manuals.plus](#) /

> [VOWNER](#) /

> VOWNER Kitchen Hutch Storage Cabinet Microwave Shelf (Model SR-01) Instruction Manual

VOWNER SR-01

VOWNER Kitchen Hutch Storage Cabinet Microwave Shelf (Model SR-01) - Instruction Manual

Comprehensive guide for assembly, usage, and maintenance.

1. INTRODUCTION

Thank you for choosing the VOWNER Kitchen Hutch Storage Cabinet Microwave Shelf, Model SR-01. This freestanding pantry unit is designed to provide versatile storage and organization for your kitchen, dining room, or living room. Featuring four glass doors, two drawers, and multiple shelves, it offers both functional storage and display space. This manual provides detailed instructions for safe assembly, proper usage, and effective maintenance to ensure the longevity and optimal performance of your cabinet.

2. SAFETY INFORMATION

Please read and understand all safety warnings and instructions before assembling and using this product. Failure to follow these instructions may result in injury or damage to the product.

- **Keep Children Away:** Keep children and pets away during assembly. Small parts can be a choking hazard.
- **Two-Person Assembly:** Assembly is recommended with two adults to prevent injury and ensure proper handling of large components.
- **Anti-Tip Device:** Always install the anti-tip device provided to prevent the cabinet from tipping over, especially in households with children. Secure it to a wall stud.
- **Weight Limits:** Do not exceed the recommended weight limits for shelves and drawers. Distribute weight evenly.
- **Stable Surface:** Place the cabinet on a flat, level, and stable surface.
- **Handle Glass with Care:** The cabinet features tempered glass doors. Handle them carefully to avoid breakage.
- **Regular Checks:** Periodically check all connections and hardware to ensure they remain tight and secure.

3. PACKAGE CONTENTS

Before beginning assembly, ensure all parts are present and undamaged. Refer to the included parts list in your packaging. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Cabinet Panels (various sizes)
- Glass Doors (4 units)

- Drawers (2 units)
- Adjustable Shelves
- Hardware Pack (screws, dowels, cam locks, hinges, handles, anti-tip kit)
- Assembly Tools (e.g., Allen wrench, screwdriver - may not be included, check packaging)

4. ASSEMBLY INSTRUCTIONS

Follow the step-by-step instructions provided in the separate assembly manual included with your product. Ensure you have adequate space and the necessary tools before starting. It is highly recommended to have two people for assembly.

Key Assembly Steps:

1. **Unpack and Identify:** Carefully unpack all components and identify each part using the provided labels and diagrams.
2. **Base Assembly:** Assemble the base frame and attach the legs.
3. **Lower Cabinet Construction:** Build the lower cabinet section, including the microwave shelf area and drawer compartments.
4. **Drawer Assembly:** Assemble the two drawers and install their slides.
5. **Upper Hutch Construction:** Assemble the upper hutch section with its various compartments.
6. **Attach Hutch to Base:** Securely attach the upper hutch to the lower cabinet.
7. **Install Doors and Shelves:** Attach the glass doors using the hinges and insert the adjustable shelves into desired positions.
8. **Final Touches:** Install handles, and most importantly, secure the anti-tip device to a wall stud.




Figure 4.1: Detailed dimensions and internal layout of the VOWNER Kitchen Hutch Storage Cabinet. This image illustrates the various compartments, including the microwave shelf, drawers, and upper hutch sections with their respective measurements.




Figure 4.2: The VOWNER Kitchen Hutch Storage Cabinet fully assembled, showcasing its design and storage capabilities in a kitchen environment.

5. OPERATING INSTRUCTIONS (USAGE)

This cabinet is designed for organized storage and display. Follow these guidelines for optimal use:

- **Adjustable Shelves:** The cabinet features adjustable shelves. To adjust, remove items, lift the shelf, reposition the shelf pins to the desired height, and then place the shelf back on the pins. Ensure all four pins are securely in place before loading the shelf.
- **Drawer Usage:** Open and close drawers smoothly. Avoid slamming them to prevent damage to the slides and contents.
- **Glass Doors:** Open and close glass doors gently. Do not hang heavy items on the doors.
- **Microwave Shelf:** The designated shelf is suitable for most standard microwaves. Ensure adequate ventilation around the appliance.
- **Weight Distribution:** Distribute weight evenly across shelves and within drawers. Place heavier items on lower shelves to maintain stability.



Figure 5.1: Interior view of the cabinet demonstrating storage capacity for various kitchen items, including the microwave compartment and drawers.



Figure 5.2: A close-up view highlighting the adjustable shelf feature, allowing customization of storage space.

6. MAINTENANCE AND CARE

Proper care will help maintain the appearance and functionality of your VOWNER cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or solvents, as these can damage the finish. For glass doors, use a standard glass cleaner.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood.
- **Hardware Check:** Periodically inspect all screws, bolts, and other hardware. Tighten any loose connections to ensure stability and safety.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration.
- **Humidity Control:** Maintain a stable humidity level in the room to prevent warping or cracking of wood components.

7. TROUBLESHOOTING

If you encounter issues with your VOWNER cabinet, refer to the following common solutions:

Problem	Possible Cause	Solution
Cabinet is wobbly or unstable.	Loose hardware; uneven floor; anti-tip device not installed.	Ensure all screws and bolts are tightened. Adjust the adjustable feet (if applicable) to level the cabinet. Install the anti-tip device securely to a wall stud.
Drawers do not slide smoothly.	Improperly installed drawer slides; obstruction in the track.	Check that drawer slides are correctly aligned and installed according to the assembly instructions. Remove any debris from the tracks.
Doors are misaligned or do not close properly.	Hinges are loose or improperly adjusted.	Adjust the hinges using a screwdriver. Most hinges allow for minor adjustments in multiple directions. Refer to the hinge manufacturer's instructions if available.
Missing parts during assembly.	Packaging error.	Do not proceed with assembly. Contact VOWNER customer support immediately with your purchase details and the specific missing part number.

8. SPECIFICATIONS

- **Brand:** VOWNER
- **Model Name:** SR-01
- **Color:** White
- **Product Dimensions:** 15.7"D x 47.3"W x 72.5"H
- **Material:** Engineered Wood
- **Special Feature:** Adjustable Feet
- **Mounting Type:** Floor Mount
- **Room Type:** Kitchen, Dining Room, Living Room
- **Door Style:** Glass
- **Included Components:** Shelves
- **Finish Type:** Painted
- **Base Type:** Legs
- **Installation Type:** Freestanding
- **Assembly Required:** Yes
- **Number of Levels:** 8
- **Item Weight:** 113 pounds

9. WARRANTY AND SUPPORT

VOWNER products are manufactured with quality and customer satisfaction in mind. For specific warranty details, please refer to the warranty card included with your purchase or visit the official VOWNER website. If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact VOWNER customer support directly. Have your purchase receipt and model number (SR-01) ready when contacting support.

VOWNER Customer Support: Refer to your purchase documentation or the VOWNER brand store on Amazon for contact information.

You can visit the VOWNER Store for more information: [VOWNER Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FBWH6MKC>

More documents and user manuals: <https://manuals.plus/>