Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CXQ JW2409051-US642

CXQ Mini Fridge Cabinet with Storage Shelves and Microwave Space Instruction Manual

Model: JW2409051-US642

Introduction

This manual provides essential information for the safe and efficient use of your CXQ Mini Fridge Cabinet. Please read these instructions carefully before assembly and operation, and retain them for future reference.

Important Safety Information

Your safety and the safety of others are very important. Please read and follow all safety messages provided in this manual.

- Always assemble the cabinet according to the provided instructions.
- Do not overload the shelves or the mini fridge compartment.
- Be cautious of pinch points when using the cabinet.
- Always unplug the mini fridge from the power source before attempting to move the cabinet or perform any maintenance.
- Ensure the cabinet is placed on a stable, level surface to prevent tipping.
- Keep small children and pets away from the cabinet during assembly and use.

Package Contents

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact CXQ customer support.

- Cabinet panels (various sizes)
- Shelves (3 total, including adjustable)
- Drawer components
- Hardware pack (screws, dowels, cam locks, etc.)
- Assembly instructions (separate document, usually included in packaging)



Image: Dimensions and details of the CXQ Mini Fridge Cabinet. This diagram illustrates the overall dimensions and key features, including quality parts, space-saving design, and durable construction.

Setup and Assembly

Assembly is required for this product. Detailed assembly instructions are provided by the manufacturer within the product packaging. Please follow these instructions carefully to ensure proper and safe assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Verify all parts are present against the parts list in the included assembly guide.
2. **Assemble Frame:** Follow the step-by-step diagrams to connect the main cabinet panels using the provided hardware. Ensure all connections are secure.
3. **Install Shelves:** Insert the shelves into the designated slots. The upper shelves are adjustable; select the desired height before securing.
4. **Assemble Drawer:** Construct the drawer according to the instructions and install it into its designated slot.
5. **Position Cabinet:** Once fully assembled, carefully move the cabinet to its desired location. Ensure it is on a stable,

level surface.

6. **Insert Appliances:** Place your mini fridge into the bottom compartment and your microwave onto the designated countertop space.



Image: Fully assembled CXQ Mini Fridge Cabinet in a room setting, showcasing its functionality with a mini fridge and microwave in place.



Image: Detailed view of the CXQ Mini Fridge Cabinet's features, highlighting the upper adjustable shelf space, the position over a mini fridge, the countertop for a microwave, and the large drawer storage.



Image: Close-up illustrating the adjustable shelf heights within the CXQ Mini Fridge Cabinet, showing measurements of 10.4", 11.7", and 13" for flexible storage.

Operating Instructions

The CXQ Mini Fridge Cabinet is designed to organize your kitchen or living space efficiently. It functions as a storage unit for various items and provides dedicated spaces for a mini fridge and a microwave.

- **Storage Shelves:** Utilize the upper shelves for storing kitchen essentials, pantry items, books, or decorative objects. The adjustable shelf allows for customization based on item height.
- **Microwave Space:** Place your microwave oven on the designated countertop. Ensure the microwave's ventilation is not obstructed.
- **Mini Fridge Compartment:** Insert your mini fridge into the lower compartment. Ensure there is adequate clearance for the fridge door to open and for proper air circulation around the appliance.
- **Drawer:** Use the pull-out drawer for storing smaller items, utensils, or accessories.

Maintenance

Regular maintenance will help preserve the appearance and longevity of your cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the melamine laminate finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the wood.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary.
- **Avoid Overloading:** Do not exceed the weight capacity of the shelves or the drawer to prevent structural damage.

Troubleshooting

If you encounter any issues with your CXQ Mini Fridge Cabinet, consider the following common solutions:

- **Cabinet Wobbles:** Ensure the cabinet is placed on a level surface. Check that all assembly hardware is securely tightened.
- **Drawer Sticks:** Verify that the drawer slides are correctly installed and free of obstructions. Ensure the drawer is not overloaded.
- **Scratches/Damage:** For minor scratches, furniture repair kits or markers designed for engineered wood can be used. For significant damage, contact customer support.

Specifications

Brand	CXQ
Model Number	JW2409051-US642
Color	White
Product Dimensions (D x W x H)	22.05"D x 23.62"W x 76.77"H
Item Weight	62.8 Pounds
Material	Engineered Wood
Number of Shelves	3 (including adjustable)
Mounting Type	Floor Mount (Freestanding)
Assembly Required	Yes
UPC	769016753910, 717710186633

Warranty Information

Specific warranty details for the CXQ Mini Fridge Cabinet are typically provided with the product packaging or can be obtained by contacting the manufacturer directly. Please refer to the documentation included with your purchase for comprehensive warranty terms and conditions.

Customer Support

For any questions, assistance with assembly, or to report missing/damaged parts, please contact CXQ customer support. Refer to the contact information provided in your product packaging or visit the official CXQ website.

Online Store: CXQ Store on Amazon

© 2025 CXQ. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FBWQDKYZ

More documents and user manuals: **https://manuals.plus/**