

[Manuals.plus](#) /

› [Dell](#) /

› Dell 14 Plus 2-in-1 Touch Laptop (Model DB04250) User Manual

Dell DB04250

Dell 14 Plus 2-in-1 Touch Laptop User Manual

Model: DB04250

1. INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Dell 14 Plus 2-in-1 Touch Laptop. This device is designed for versatility, offering multiple modes of use and integrating advanced AI capabilities for enhanced productivity and creativity.



Dell 14 Plus 2-in-1 Laptop

Dell 14 Plus 2-in-1 convertible tablet laptop featuring a touchscreen with with Copilot+ AI and Intel Arc graphics.

The Dell 14 Plus 2-in-1 Laptop in its standard laptop configuration, showcasing its display and design.

2. WHAT'S IN THE BOX

Verify that all components are present in the packaging:

- Dell 14 Plus 2-in-1 Touch Laptop
- Power Adapter
- User Manual (this document)
- Integrated Webcam

3. SETUP

3.1 Initial Power-On

1. Connect the power adapter to the laptop's charging port and then to a power outlet.

2. Open the laptop lid. The system may power on automatically, or you may need to press the power button located on the side.
3. Follow the on-screen instructions to complete the Windows 11 Home operating system setup, including language selection, network connection, and user account creation.

3.2 Fingerprint Reader Setup

For enhanced security, set up the integrated fingerprint reader:

1. Navigate to Windows Settings > Accounts > Sign-in options.
2. Locate 'Fingerprint Recognition (Windows Hello)' and follow the prompts to register your fingerprints.

4. OPERATING INSTRUCTIONS

4.1 2-in-1 Modes

The Dell 14 Plus offers four versatile modes:

- **Laptop Mode:** Standard computing experience with keyboard and touchpad.
- **Tent Mode:** Ideal for presentations or watching media in confined spaces.
- **Stand Mode:** Perfect for touch-based interaction and media consumption.
- **Tablet Mode:** Fully folded back for a tablet experience, utilizing the touchscreen.



One seamless experience in four modes

Effortlessly switch between four modes, including a full 360, with all the essentials included.

The laptop easily transitions between various modes for different uses.

4.2 Touchscreen Usage

Interact with your laptop using intuitive touch gestures:

- **Tap:** Select items or open applications.
- **Swipe:** Scroll through content or navigate.
- **Pinch-to-Zoom:** Enlarge or reduce content size.

4.3 Keyboard and Fingerprint Reader

The backlit keyboard provides comfortable typing in various lighting conditions. The integrated fingerprint reader allows for quick and secure login.



Secure and reliable


Crafted with high quality materials and designed for durability, all Dell Plus laptops undergo rigorous military-grade testing to ensure exceptional reliability as you put it through the rigors of everyday use.

A detailed view of the backlit keyboard, designed for comfortable use.

4.4 AI-Enabled Features

Leverage the Intel Core Ultra 5 processor and Copilot+ AI for enhanced functionality:

- **Recall:** Quickly find content you've previously viewed on your laptop using natural language prompts.




CPU

Fast Response: Ideal for real time multi-tasking and AI workload such as noise cancellation and instant transcription.

The Recall feature helps users quickly locate previously accessed information.

- **Live Captions:** Instantly translate and display captions for audio content in real-time.




Live captions

Instantly translate* your video calls or movies from any app or video platform into English subtitles, in real time.

**From 44 languages into English.*

Live Captions provide real-time translation and subtitles for various media.

- **Cocreator:** Generate custom images and enhance creative projects using AI.




Cocreator

Help bring your creative aspirations to life with custom images through Cocreator*.

**Cocreator is optimized for English text prompts.
Requires Microsoft account.*

Cocreator assists in generating unique images for creative tasks.

- **Windows Studio Effects:** Enhance video calls with features like background blur, eye contact correction, and automatic framing.



Windows studio effects


No need for extra lights or soundproof rooms—new Windows studio effects help you look and sound your best.

Windows Studio Effects improve video call quality and user presentation.

4.5 Ports and Connectivity

The laptop features various ports for connecting peripherals and external displays:

- Thunderbolt™ 4 (40 Gbps) with DisplayPort™ 2.1 and Power Delivery
- USB 3.2 Gen 2 (10 Gbps) Type-C® port with DisplayPort™ 1.4 and Power Delivery
- HDMI 2.1
- USB 3.2 Gen 1 Type-A (5 Gbps)
- Headset Jack



Overview of the laptop's connectivity ports.

5. MAINTENANCE

5.1 Cleaning Your Laptop

- Use a soft, lint-free cloth slightly dampened with water or a screen cleaner to clean the display.
- For the keyboard and chassis, use a soft cloth. Avoid harsh chemicals.
- Ensure the laptop is powered off and unplugged before cleaning.

5.2 Battery Care

- Avoid extreme temperatures.
- Do not leave the laptop constantly plugged in at 100% charge for extended periods.
- Periodically discharge the battery to around 20% before recharging.

5.3 Software Updates

Regularly check for and install operating system and driver updates to ensure optimal performance and security. Access updates via Windows Settings > Windows Update.

6. TROUBLESHOOTING

This section addresses common issues you might encounter.

6.1 Laptop Does Not Power On

- Ensure the power adapter is securely connected to both the laptop and a working power outlet.
- Check if the power outlet is functional by plugging in another device.
- Try holding the power button for 15-20 seconds to perform a hard reset.

6.2 Display Issues

- If the screen is blank, try pressing the 'Fn' key along with the display toggle key (often F8 or F10) to cycle through display outputs.
- Ensure display drivers are up to date via Windows Update or Dell's support website.

6.3 Connectivity Problems (Wi-Fi/Bluetooth)

- Verify that Wi-Fi or Bluetooth is enabled in Windows Settings.
- Restart your router/modem for Wi-Fi issues.
- Update network drivers from Dell's support website.

7. SPECIFICATIONS

Key technical specifications for the Dell 14 Plus 2-in-1 Touch Laptop (Model DB04250):

Processor	Intel Core Ultra 5 226V (8 cores, up to 4.5 GHz)
RAM	16 GB LPDDR5X, 8533 MT/s (onboard)
Storage	512 GB M.2 PCIe NVMe SSD
Graphics	Intel Arc Graphics (Integrated)
Display	14" FHD+ (1920 x 1200) Touch WVA, 300 nits, ComfortView Plus
Operating System	Windows 11 Home
Keyboard	Backlit Keyboard
Security	Fingerprint Reader
Ports	1x Thunderbolt™ 4, 1x USB 3.2 Gen 2 Type-C®, 1x HDMI 2.1, 1x USB 3.2 Gen 1 Type-A, 1x Headset Jack
Wireless Connectivity	Wi-Fi, Bluetooth
Battery	64 Watt Hours Lithium Ion
Dimensions (L x W x Thickness)	22.6 x 31.4 x 1.6 cm (approx.)

Weight	1.61 Kg (approx.)
--------	-------------------



The slim profile of the Dell 14 Plus 2-in-1 Laptop.

8. WARRANTY INFORMATION

This Dell 14 Plus 2-in-1 Touch Laptop comes with a **1-Year Limited Hardware Warranty**. For detailed terms and conditions, please refer to the warranty documentation included with your product or visit the official Dell support website.

9. SUPPORT

For technical assistance, driver downloads, or further support, please contact Dell customer service or visit the official Dell support website:

- **Manufacturer:** DELL, Dell International Service India Private Limited

- Website: www.dell.com/support

© 2026 Dell Inc. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question