



Manuals.plus /

› Papablic /

› Papablic NutriWarm Swirlable Bottle Warmer Instruction Manual

Papablic NutriWarm Swirlable Bottle Warmer

Papablic NutriWarm Swirlable Bottle Warmer Instruction Manual

Model: NutriWarm Swirlable Bottle Warmer

INTRODUCTION

The Papablic NutriWarm Swirlable Bottle Warmer is designed to gently and efficiently warm breast milk and formula, preserving essential nutrients. Its advanced technology ensures even heating without hot spots, providing a safe and convenient feeding solution for your baby.



3:45

NUTRI
QUICK
KEEP



GLASS
PLASTIC
SILICONE



2-4 OZ
5-6 OZ
7-8 OZ



Papablic

Image: The Papablic NutriWarm Swirlable Bottle Warmer, a compact white and black device with a digital display, warming a baby bottle.

IMPORTANT SAFETY INFORMATION

- Always check milk temperature before feeding your baby to prevent scalding.
- Do not overheat breast milk, as temperatures above 104°F (40°C) may destroy essential nutrients.
- Keep the appliance out of reach of children.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Unplug the warmer when not in use and before cleaning.
- Do not immerse the appliance in water or other liquids.



Image: A diagram illustrating the components of breast milk and a warning about hot spots destroying essential nutrients.

COMPONENTS

The Papablic NutriWarm Swirlable Bottle Warmer includes the following components:

- Main Bottle Warmer Unit
- Bottle Basket/Holder
- Measuring Cup
- EasyClean Descaling Powder (for maintenance)

Still Concerned About Hot-spots in Breastmilk?

Hot-spots in breastmilk can destroy essential nutrients.




Image: The Papablic NutriWarm Bottle Warmer with a baby bottle inserted into its removable basket.

SETUP

1. Place the bottle warmer on a flat, stable surface.
2. Ensure the power cord is securely plugged into a suitable electrical outlet.
3. Clean the bottle warmer and its accessories before first use according to the "Maintenance" section.

4. Insert the bottle basket into the warming chamber.

OPERATING INSTRUCTIONS

The Papablic NutriWarm offers multiple warming modes and functions. Refer to the included warming time chart for precise settings based on milk type, volume, and bottle material.

General Operation Steps:

1. Pour the appropriate amount of water into the warming chamber using the measuring cup. The water level should be sufficient to cover the milk in the bottle.
2. Place the bottle containing milk or food into the bottle basket, then lower the basket into the warming chamber.
3. Press the power button to turn on the device.
4. Select the desired warming mode (Nutri, Quick, Keep) and adjust settings for bottle material (Glass, Plastic, Silicone) and milk volume (2-4 oz, 5-6 oz, 7-8 oz) using the touch controls.
5. Press the start button to begin the warming cycle.
6. The device will beep and display a completion indicator when warming is finished. Carefully remove the bottle using the basket handle.
7. Always test the milk temperature on your wrist before feeding your baby.

Specific Warming Modes:

- **Nutri Warming (for Breast Milk):** This mode uses a gentle water-bath and swirl heating to preserve essential nutrients. Select "NUTRI" mode.
- **Quick Warming (for Formula Milk):** This mode provides faster warming for formula. Select "QUICK" mode.
- **Keep Warm:** Maintains the desired temperature for a set period. Select "KEEP" mode and adjust the temperature as needed.
- **Thawing:** Gently thaws frozen breast milk or baby food. Select "KEEP" mode and set the desired temperature for thawing.
- **Food Warming:** Warms baby food jars. Select "KEEP" mode and set the desired temperature.
- **Sterilizing:** Sterilizes bottles and small accessories. Select "KEEP" mode and set the temperature to 212°F (100°C).
- **Swirl Only Mode:** To activate the swirl function without heating, hold the "NUTRI" button for 4 seconds. This helps mix milk evenly.

Memory Function:

The warmer remembers your last settings, allowing for one-step repeat operation for convenience.

Bottle Compatibility:

The Papablic NutriWarm is compatible with most baby bottle brands and food jars, including glass, plastic, and silicone bottles.

Compatible with Most Baby Bottle Brands and baby food jars



Silicone Bottles



Glass Bottles



Plastic Bottles



Breastmilk Bags



Baby Food Jars



Image: The bottle warmer demonstrating compatibility with silicone, glass, plastic bottles, breastmilk bags, and baby food jars.

Your browser does not support the video tag.

Video: A demonstration of how to use the Papablic NutriWarm Swirlable Bottle Warmer, showcasing its various functions and ease of operation.

MAINTENANCE

Cleaning:

- Unplug the appliance and allow it to cool completely before cleaning.
- Wipe the exterior of the warmer with a damp cloth. Do not use abrasive cleaners.
- The bottle basket can be washed with warm soapy water and rinsed thoroughly.
- Do not immerse the main unit in water.

Descaling:

Mineral deposits (limescale) can build up in the warming chamber over time, affecting performance. Descale regularly to ensure optimal function.

1. Mix one packet of EasyClean Descaling Powder with 3.4 fl oz (100ml) of water.
2. Pour the solution into the warming chamber.
3. Let it stand for 30 minutes.
4. Empty the solution and rinse the chamber thoroughly with clean water.
5. Repeat if necessary until all limescale is removed.

TROUBLESHOOTING

- **Warmer not turning on:** Ensure the power cord is securely plugged into a working outlet.
- **Milk not warming:** Check that the correct amount of water has been added to the warming chamber and that the selected settings (mode, material, volume) are appropriate for your needs.
- **Uneven warming or hot spots:** Ensure the swirl function is active (if applicable for the mode) and that the bottle is properly seated in the basket. Regular descaling can also prevent this.
- **Long warming time:** Verify that the correct milk volume and temperature (cold vs. room temperature) settings are selected. Descaling may also improve efficiency.

SPECIFICATIONS

- **Brand:** Papablic
- **Model:** NutriWarm Swirlable Bottle Warmer
- **Package Dimensions:** 8.39 x 6.58 x 6.46 inches
- **Weight:** 2.48 Pounds
- **Manufacturer:** Papablic
- **ASIN:** B0FBWY7B6

WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about protection plans, please refer to the official Papablic website or contact customer service directly. Protection plans are available for purchase to extend coverage beyond the standard warranty period.

Visit the official Papablic Store: [Papablic Store](#)

