

[Manuals.plus](#) /

› [Ouaken](#) /

› Ouaken Activated Carbon Filter for CY02C Electric Composter Instruction Manual

Ouaken CY02C-Filter

Ouaken Activated Carbon Filter for CY02C Electric Composter Instruction Manual

Model: CY02C-Filter

INTRODUCTION

This manual provides essential information for the proper installation, replacement, and maintenance of your Ouaken Activated Carbon Filter, designed specifically for the Ouaken CY02C Electric Composter. This original replacement carbon filter is crucial for maintaining an odor-free composting experience.



A close-up view of the Ouaken Activated Carbon Filter, designed for the CY02C Electric Composter.

COMPATIBILITY

This activated carbon filter is an original replacement part specifically manufactured for the **Ouaken CY02C Electric Composter**. Ensure you are using the correct filter model for optimal performance and odor control.

INSTALLATION

1. Ensure your Ouaken CY02C Electric Composter is powered off and unplugged before beginning installation.
2. Locate the filter compartment on your composter. This is typically found on the top or side of the unit.
3. Carefully open the filter compartment cover.
4. Remove any old or used carbon filters from the compartment. Dispose of used filters responsibly according to local regulations.
5. Install the new activated carbon filter cartridge by simply placing it into the designated installation compartment. Ensure it fits snugly.
6. Close the filter compartment cover securely.
7. Plug in and power on your composter.

Visual Guide: Filter Installation

Your browser does not support the video tag.

Video demonstrating the installation of activated carbon filters into the Ouaken Electric Composter, highlighting the ease of placement.

Your browser does not support the video tag.

Demonstration of replacing the biodegradable carbon filter in a kitchen composter, showing the removal and insertion of the filter cartridge.

FILTER REPLACEMENT

The activated carbon filter has a limited lifespan. Your Ouaken CY02C Electric Composter will provide a warning notification when the filter reaches the end of its lifespan, typically after approximately 1000 hours of operation.

However, if the machine frequently processes very moist food, it can cause the filter to become less effective sooner than 1000 hours, even if the machine hasn't yet prompted a replacement. If you notice persistent odors before the notification, it may be time to replace the filter.

Follow the installation steps above to replace your old filter with a new one.

MAINTENANCE TIPS

- To prolong the life of your carbon filter, try to avoid processing excessively moist food waste in your composter.
- Always ensure the filter compartment is securely closed after installation or replacement to maintain optimal air filtration.
- Keep spare filters on hand to ensure continuous odor control and efficient composter operation.

SPECIFICATIONS

Feature	Detail
Product Dimensions	3.22 x 5.7 x 8.2 inches
Item Weight	1.65 pounds
Material	Plastic (Filter Housing)
Compatibility	Ouaken CY02C Electric Composter

WARRANTY & SUPPORT

For any issues, questions, or support regarding your Ouaken Activated Carbon Filter or CY02C Electric Composter, please feel free to contact us. Our customer service team is ready to assist you.

Please refer to your original composter manual or the Ouaken website for detailed warranty information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

The ferment mode on my Ouaken CY02C Electric Composter will no longer turn on; what is the root cause?

Based on the documentation for the Ouaken CY02C Electric Composter, there are several potential reasons why the ferment mode may fail to activate even after a power reset:Filter Life Notification: The device tracks filter...

[Read full answer](#)