Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Mutaomay MTPW05

Mutaomay 3600 PSI 2.3 GPM Gas Pressure Washer MTPW05 User Manual

Model: MTPW05

1. Introduction

Thank you for choosing the Mutaomay 3600 PSI 2.3 GPM Gas Pressure Washer, Model MTPW05. This manual provides essential information for the safe operation, assembly, maintenance, and troubleshooting of your pressure washer. Please read this manual thoroughly before operating the unit and keep it for future reference.

2. Safety Information

WARNING: Failure to follow these safety instructions could result in serious injury or death.

- Always wear appropriate personal protective equipment, including eye protection, hearing protection, and sturdy footwear.
- Never point the spray gun at people, pets, or electrical devices. The high-pressure spray can cause severe injury.
- Operate the pressure washer in a well-ventilated area to avoid carbon monoxide poisoning from engine exhaust.
- Ensure all connections are secure before starting the unit to prevent leaks and accidental disconnections.
- Do not operate the pressure washer if any parts are damaged or missing.
- Keep children and bystanders away from the operating area.
- Before performing any maintenance or cleaning, always turn off the engine, allow it to cool, and disconnect the spark plug wire.
- Use only approved fuels and detergents. Store fuel in approved containers in a safe location.

3. Package Contents

Verify that all items are present in the package:

- Mutaomay Gas Pressure Washer Unit (with 212CC OHV Engine, Fuel Tank, Soap Tank, Hose Reel, and Wheels)

- High-Pressure Spray Gun
- 30 ft High-Pressure Hose
- 5 Quick-Connect Nozzles (0°, 15°, 25°, 40°, Soap)
- Cleaning Needle
- Oil Funnel



Figure 3.1: Included Accessories

4. Product Overview and Components

Familiarize yourself with the main components of your Mutaomay Gas Pressure Washer:

- **Engine:** 212cc 7 HP 4-stroke OHV gas engine for powerful performance.
- **Pump:** Durable Axial Cam Aluminum Pump designed for extended lifespan.
- **Fuel Tank:** 0.925-gallon (3.5L) capacity for longer operation.

- **Soap Tank:** Integrated 0.8-gallon (3L) tank for continuous detergent application.
- **Hose Reel:** Built-in for convenient storage and tangle-free management of the high-pressure hose.
- **Wheels:** 10-inch flat-free tires for easy mobility across various terrains.
- **Spray Gun:** Ergonomic design for comfortable use.
- **Quick-Connect Nozzles:** Five interchangeable nozzles for different spray patterns and cleaning tasks.



Figure 4.1: Product Details and Labeled Components



Figure 4.2: Engine and Pump Details

5. Setup Instructions

Follow these steps to set up your pressure washer before first use:

1. **Assemble the Handle:** Attach the handle to the main unit using the provided hardware. Ensure it is securely fastened.
2. **Add Engine Oil:** Remove the oil fill cap/dipstick and add the recommended engine oil (not included) to the proper level. Do not overfill.
3. **Add Fuel:** Fill the 0.925-gallon (3.5L) fuel tank with fresh, unleaded gasoline. Do not use E85 or E15 fuel. Ensure the fuel cap is securely tightened.
4. **Connect Water Supply:** Connect a garden hose (minimum 5/8 inch diameter) to the water inlet on the pump. Ensure the water supply is turned on fully before starting the engine.

5. **Connect High-Pressure Hose:** Connect one end of the 30 ft high-pressure hose to the pump's high-pressure outlet and the other end to the spray gun. Tighten all connections firmly.
6. **Select Nozzle:** Choose the appropriate quick-connect nozzle for your cleaning task and insert it into the spray gun wand until it clicks into place.



Figure 5.1: Hose Reel for Easy Storage

6. Operating Instructions

Follow these steps for safe and effective operation of your pressure washer:

6.1 Starting the Engine

1. Ensure the water supply is fully open and there are no kinks in the garden hose.
2. Pull the choke lever to the 'CHOKE' position (if the engine is cold).

3. Turn the engine switch to the 'ON' position.
4. Pull the recoil starter handle firmly until the engine starts.
5. Once the engine starts, gradually move the choke lever to the 'RUN' position.

6.2 Using Quick-Connect Nozzles

The pressure washer includes 5 quick-connect nozzles for various cleaning applications:

- **0° (Red):** Pin-point jet for intense cleaning of stubborn stains on concrete or metal. Use with extreme caution.
- **15° (Yellow):** Narrow spray for aggressive cleaning of hard surfaces like brick or siding.
- **25° (Green):** Medium spray for general cleaning of wood decks, fences, or vehicles.
- **40° (White):** Wide spray for gentle cleaning of delicate surfaces like windows or painted surfaces.
- **Soap (Black):** Low-pressure spray for applying detergent.



Figure 6.1: Quick-Connect Nozzle Guide

6.3 Applying Detergent

To apply detergent, ensure the black soap nozzle is installed. Fill the 0.8-gallon (3L) onboard soap tank with pressure washer safe detergent. The pressure washer will automatically draw detergent when the soap nozzle is in use. After applying detergent, switch to a high-pressure nozzle (e.g., 25° or 40°) to rinse the surface thoroughly.

6.4 Cleaning Applications

This pressure washer is suitable for a variety of cleaning tasks:

- **Driveways and Concrete:** Use 0° or 15° nozzles for tough stains.
- **Fences and Decks:** Use 25° or 40° nozzles, maintaining a safe distance to avoid damage.
- **Cars and RVs:** Use the soap nozzle for detergent application, then rinse with 25° or 40° nozzles.
- **Siding and Equipment:** Adjust nozzle and distance based on surface material.



Figure 6.2: Versatile Cleaning Applications



Figure 6.3: Cleaning a Car Wheel



Figure 6.4: Cleaning Concrete Cracks



Figure 6.5: Cleaning Wall Brick



Figure 6.6: Cleaning Fences



Figure 6.7: Vehicle Washing

7. Maintenance

Regular maintenance ensures optimal performance and extends the life of your pressure washer.

7.1 Engine Maintenance

- **Oil Change:** Change engine oil after the first 5 hours of use, then every 50 hours or annually.
- **Air Filter:** Check and clean the air filter every 25 hours or more often in dusty conditions. Replace if damaged.
- **Spark Plug:** Inspect and clean the spark plug annually or every 100 hours. Replace if necessary.

7.2 Pump Maintenance

- **Winterization:** Before storing in freezing temperatures, drain all water from the pump and hoses. Use a pump protector/antifreeze solution to prevent damage.
- **Inlet Filter:** Regularly check and clean the water inlet filter to prevent debris from entering the pump.

7.3 Hose and Nozzle Care

- Always drain water from the high-pressure hose after use and store it neatly on the hose reel.
- Clean clogged nozzles using the provided cleaning needle.

8. Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Engine will not start	No fuel; Engine switch OFF; Choke not set; Low oil level; Spark plug issue	Add fuel; Turn switch ON; Adjust choke; Add oil; Check/replace spark plug
Low pressure	Insufficient water supply; Clogged nozzle; Air in pump; Worn pump seals	Ensure full water flow; Clean nozzle; Purge air from pump; Contact service
Engine stalls during operation	Low fuel; Overheating; Clogged air filter	Refuel; Allow to cool; Clean air filter
Water leaks	Loose connections; Damaged O-rings/seals	Tighten connections; Replace O-rings/seals

9. Specifications

- **Model:** MTPW05
- **Brand:** Mutaomay
- **Maximum Pressure:** 3600 PSI
- **Maximum Flow Rate:** 2.3 GPM
- **Engine Type:** 212cc 7 HP 4-Stroke OHV Gas Engine
- **Fuel Tank Capacity:** 0.925 Gallons (3.5 Liters)
- **Soap Tank Capacity:** 0.8 Gallons (3 Liters)
- **High-Pressure Hose Length:** 30 Feet
- **Wand Length:** 16 Inches
- **Tires:** 10-inch Flat-Free
- **Item Weight:** 77 Pounds
- **Product Dimensions (L x W x H):**28.9" x 23.6" x 34.2"

10. Warranty and Support

This Mutaomay pressure washer, Model MTPW05, comes with a**2-Year Manufacturer Warranty**. For warranty claims, technical assistance, or replacement parts, please contact Mutaomay customer support. Keep your purchase receipt as proof of purchase.
For further assistance, please visit the Mutaomay store on Amazon:Mutaomay Store

© 2026 Mutaomay. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FBWYS8LJ

More documents and user manuals: **https://manuals.plus/**