

## VINEGO XF43

# VINEGO XF43 Retro Handheld Game Console User Manual

Model: XF43

## INTRODUCTION

---

This manual provides essential instructions for the setup, operation, maintenance, and troubleshooting of your VINEGO XF43 Retro Handheld Game Console. Please read this guide thoroughly to ensure optimal performance and longevity of your device.

## WHAT'S IN THE BOX

---

Upon unboxing, please verify that all the following items are included:

- 1 × XF43 Console
- 1 × TF Card (64G/128G)
- 1 × Type-C Data Cable
- 1 × User Manual
- 1 × Certificate of Conformity



Image: The VINEGO XF43 console in white, accompanied by its accessories including a 128GB TF card, USB-C cable, screen protector kit, and a protective carrying case.

## PRODUCT OVERVIEW: CONTROLS AND PORTS

---

Familiarize yourself with the layout of the XF43 console to enhance your gaming experience.

# Product Parameters



Image: A detailed diagram labeling all buttons and ports on the VINEGO XF43 console. Key features include dual 3D joysticks, directional cross key, A/B/X/Y game keys, Select/Start keys, Right/Left Shoulder Buttons (RB/LB), Right/Left Triggers (RT/LT), HDMI interface, HOST interface, Power On/Off button, TF Card Slot, DC/OTG Interface, and Headphone Jack.

- **Left Joystick:** For directional control in games.
- **Cross Key:** Traditional directional input.
- **Select Key:** Used for menu selections or in-game functions.
- **Start Key:** Used to begin games or pause.
- **Right Joystick:** For camera control or secondary directional input.
- **Game Keys (A, B, X, Y):** Primary action buttons.
- **Right Shoulder Button (RB):** Top right shoulder button.
- **Left Shoulder Button (LB):** Top left shoulder button.
- **Right Trigger (RT):** Bottom right trigger button.
- **Left Trigger (LT):** Bottom left trigger button.
- **HDMI Interface:** Connect to an external display.
- **HOST Interface:** For connecting external devices.
- **Power On/Off:** Slide switch to power the device.
- **TF Card Slot:** Insert the microSD card containing games and system files.

- **DC/OTG Interface:** For charging and On-The-Go (OTG) functions.
- **Headphone Jack:** Connect 3.5mm headphones for private audio.

## SETUP INSTRUCTIONS

---

### 1. Charging the Device

Before first use, fully charge the console. Connect the provided Type-C data cable to the DC/OTG interface on the console and the other end to a compatible USB power adapter (5V/2A recommended, not included).



Image: The VINEGO XF43 console connected via a USB Type-C cable for charging, highlighting its 3000mAh battery and 4-6 hours of gaming time.

### 3. Inserting the TF Card

Locate the TF Card Slot on the console. Gently insert the pre-loaded TF card into the slot until it clicks into place. Ensure the card is inserted correctly to avoid damage.

### 4. Powering On/Off

- **To Power On:** Slide the Power On/Off switch to the 'ON' position. The device will boot up.
- **To Power Off:** Slide the Power On/Off switch to the 'OFF' position. It is recommended to save your

game progress before powering off.

## OPERATING INSTRUCTIONS

---

### 1. Navigating the Interface

The XF43 runs on an open-source Linux system. Use the joysticks or cross key to navigate through menus and select options with the A button.

### 2. Playing Games

The console comes pre-loaded with a vast library of games supporting over 30 emulators. To play a game:

1. From the main menu, select the desired emulator or game category.
2. Browse the list of available games.
3. Select a game and press the A button to launch it.



Image: The VINEGO XF43 console displaying a game selection screen, indicating support for over 30 console formats and a large library of pre-installed games.

### 3. Saving and Loading Game Progress

Most emulators allow for in-game saving and loading, as well as 'save states'. Refer to the specific

emulator's menu (often accessed by pressing a combination of buttons like SELECT + START or a dedicated menu button) for these options.

#### 4. Connecting to an External Display (HDMI Out)

The XF43 supports HDMI 1.4 FHD output. Connect an HDMI cable (not included) from the console's HDMI interface to your TV or monitor. The display should automatically switch or require manual selection of the HDMI input on your external display.



Image: The VINEGO XF43 console being used in various entertainment modes, including connecting to a television for a larger screen gaming experience.

#### 5. Customizing Controls

Within each emulator, you may have options to remap buttons to your preference. Access the emulator's settings menu to configure controls.

#### 6. Adding More Games/Emulators

The Linux system allows for the installation of new emulators and compatible games. This typically involves transferring files to the TF card via a computer. Consult online communities or specific emulator documentation for detailed instructions on adding content.

Your browser does not support the video tag.

Video: An overview of the VINEGO XF43 Retro Handheld Game Console, showcasing its various color options, included accessories, and demonstrating gameplay across different emulators. The video highlights the console's design and functionality.

## MAINTENANCE

---

### 1. Cleaning the Device

Use a soft, dry, lint-free cloth to clean the console's exterior. For the screen, use a screen-specific cleaning solution and a microfiber cloth. Avoid abrasive materials or harsh chemicals.

### 2. Battery Care

- Avoid fully discharging the battery frequently.
- Store the device in a cool, dry place when not in use for extended periods.
- Charge the device periodically if stored for a long time to prevent deep discharge.

### 3. TF Card Management

Regularly back up the contents of your TF card to a computer to prevent data loss. Avoid removing the TF card while the device is powered on or actively accessing data.

## TROUBLESHOOTING

---

If you encounter issues with your XF43 console, refer to the following common solutions:

- **Device not powering on:** Ensure the battery is charged. Connect the charger and try again.
- **Games not loading or crashing:** Verify the TF card is properly inserted. Some games or emulators may require specific configurations or updates.
- **Screen issues (no display, flickering):** Try restarting the device. If connected to an external display, ensure the HDMI cable is secure and the TV input is correct.
- **Controls unresponsive:** Restart the device. Check if any buttons are stuck.

For persistent issues, please contact VINEGO customer support.

## SPECIFICATIONS

---

The following table details the technical specifications of the VINEGO XF43 Retro Handheld Game Console:

Feature	Detail
Model	XF43
Screen Size	4.3 Inches IPS (480x272 resolution) with OCA full lamination
Processor	RK3128 Cortex-A7 1.3GHz
GPU	Mali-400 MP2
RAM	4GB DDR3
Operating System	Open-Source Linux (Linux Ark OS 2.0)
Storage	128GB TF Card (expandable up to 256GB)

Feature	Detail
Battery	3000mAh Lithium-Ion
Battery Life	4-6 hours (continuous gameplay)
Charging Port	USB Type-C (5V/2A)
Video Output	HDMI 1.4 FHD
Dimensions	7.3 x 3.1 x 0.6 inches (15cm x 7.7cm x 2.1cm)
Weight	14.4 ounces
Material	Plastic

LCD	4.3Inch IPS 480*272 OCA Full Lamination
CPU	RK3128 Cortex-A7 1.3GHz
DDR3	4GB
ROM	EMMC 4GB
GPU	Mali-400 MP2
HD Output	Support HD Out 1.4 FHD
TF Card	Maximum 256GB
Charger	Maximum 5V&2A

Image: A visual representation of the VINEGO XF43's key specifications, including LCD, CPU, DDR3, ROM, GPU, HD Output, TF Card capacity, and Charger details.

## WARRANTY AND SUPPORT

### Warranty Information

The VINEGO XF43 Retro Handheld Game Console comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package or contact VINEGO customer support for specific terms and conditions.

### **Customer Support**

For technical assistance, troubleshooting, or warranty claims, please contact VINEGO customer support through their official website or the contact information provided in your product packaging.