



Manuals.plus /

- › Christopher Knight Home /
- › Christopher Knight Home Guma 48" Round Dining Table Instruction Manual

Christopher Knight Home Guma 325317

Christopher Knight Home Guma 48" Round Dining Table

Model: Guma 325317

1. INTRODUCTION

Thank you for purchasing the Christopher Knight Home Guma 48" Round Dining Table. This manual provides essential information for the safe assembly, proper use, and maintenance of your new dining table. Please read these instructions carefully before beginning assembly and retain them for future reference.

This round dining table is designed to comfortably seat four people, making it suitable for kitchens, dining rooms, or smaller living spaces. Its durable construction and classic pedestal base offer both stability and a touch of elegance to your home.

2. SAFETY INFORMATION

WARNING: Failure to follow these safety instructions could result in injury or damage to the product.

- Always follow the included assembly instructions to ensure safe and proper installation.
- Keep hands and fingers away from pinch points during assembly.
- Do not exceed the weight limit of 77.16 pounds for the tabletop to maintain stability.
- Ensure all connections are securely tightened before use. Periodically check and re-tighten hardware as needed.
- This table is intended for indoor use only.

3. PARTS LIST

Before assembly, verify that all parts are present and undamaged. Refer to the separate Assembly Guide included in your package for a detailed list of components and hardware.

Typical components include:

- Tabletop
- Pedestal Base Components
- Assembly Hardware (screws, bolts, washers, etc.)
- Assembly Guide

4. SETUP AND ASSEMBLY

Assembly of the Guma dining table is designed to be straightforward. Please follow the step-by-step instructions provided in the separate Assembly Guide. Ensure you have the recommended tools before starting.

Recommended Tools:

- Hammer
- Screwdriver

Assembly Steps:

1. Unpack all components and lay them out on a soft, clean surface to prevent scratches.
2. Identify all parts and hardware using the included Assembly Guide.
3. Attach the pedestal base components together as instructed. Ensure all connections are firm.
4. Securely attach the assembled pedestal base to the tabletop.
5. Once assembled, carefully move the table to its desired location.



Image: Close-up of the pedestal base connection, illustrating a key assembly point.

5. OPERATING AND USAGE

The Guma dining table is designed for everyday dining and casual gatherings. Its 48-inch diameter comfortably accommodates up to four individuals.

Key Usage Points:

- **Seating Capacity:** Designed for 4 people.
- **Placement:** Suitable for dining rooms, kitchens, or living room dining areas.
- **Stability:** The pedestal base provides excellent balance. Avoid placing excessive weight on one side.



Image: The Guma dining table in a typical home environment, showcasing its use for dining.

6. MAINTENANCE

Proper care will help maintain the appearance and longevity of your dining table.

Cleaning Instructions:

- Wipe the surface with a damp cloth.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- Promptly clean up spills to prevent staining.

General Care:

- Avoid direct sunlight and extreme temperature changes.
- Use coasters or placemats to protect the tabletop from heat and moisture.
- Periodically check and tighten all hardware to ensure stability.

7. TROUBLESHOOTING

If you encounter any issues with your dining table, please refer to the following common solutions:

Common Issues:

- **Wobbling Table:** Ensure all bolts and screws are securely tightened. Check that the table is on a level surface. Adjust floor glides if present.
- **Scratches/Dents:** Minor surface imperfections can sometimes be addressed with furniture repair kits

or touch-up pens matching the wood finish. For significant damage, contact customer support.

- **Missing Parts:** If any parts were missing upon delivery, please contact Christopher Knight Home customer service immediately.

8. SPECIFICATIONS

Detailed specifications for the Christopher Knight Home Guma 48" Round Dining Table:

Feature	Detail
Brand	Christopher Knight Home
Model Name	Guma
Model Number	325317
Product Dimensions	48"D x 48"W x 30.25"H
Item Weight	77.2 Pounds
Frame Material	Engineered Wood
Top Material Type	Engineered Wood
Color	Natural
Shape	Round
Base Type	Pedestal
Seating Capacity	4
Required Assembly	Yes
Indoor Outdoor Usage	Indoor



Image: Dimensional drawing of the table, indicating its 48-inch diameter and 30.25-inch height.

9. WARRANTY AND SUPPORT

Christopher Knight Home stands behind the quality of its products. For specific warranty information, please refer to the documentation included with your purchase or visit the official Christopher Knight Home website.

If you require assistance with assembly, have questions about your product, or need to report missing/damaged parts, please contact Christopher Knight Home customer support. Have your model number (Guma 325317) and purchase information ready when contacting support.