

Ltinist BX29

Ltinist Wireless Earbuds BX29 User Manual

Model: BX29 | Brand: Ltinist

1. INTRODUCTION

Thank you for choosing Ltinist Wireless Earbuds BX29. These earbuds are designed to provide a superior audio experience with advanced features such as Bluetooth 5.4 connectivity, ENC noise cancellation for clear calls, and IPX8 waterproofing, making them ideal for sports and daily use. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

1.1 What's in the Box

- Wireless Earbuds (L/R) x 2
- USB-C Charging Cable x 1
- Portable Charging Case x 1
- User Manual x 1
- Ear Tips (S/M/L) x 3 pairs (Medium pre-installed)

Born for Sports



Image: Components included in the product packaging.



Image: Ltinist BX29 Wireless Earbuds and their charging case.

2. SAFETY INFORMATION

Please read all safety warnings before using this product to ensure safe and proper operation.

- **Hearing Protection:** Avoid listening at high volume levels for extended periods to prevent hearing damage.
- **Driving Safety:** Do not use earbuds while driving or cycling where the inability to hear ambient sounds could pose a danger.
- **Choking Hazard:** Keep earbuds and small parts away from children and pets to prevent accidental ingestion.
- **Temperature:** Do not expose the product to extreme temperatures (below 0°C or above 45°C).
- **Cleaning:** Use a soft, dry cloth for cleaning. Do not use harsh chemicals or abrasive materials.
- **Disassembly:** Do not attempt to disassemble or modify the earbuds or charging case. This will void the warranty and may cause damage.

3. GETTING STARTED

3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case, ensuring they are correctly seated.
2. Connect the USB-C charging cable to the charging port on the case and the other end to a USB power adapter (not included) or a computer's USB port.
3. The LED display on the charging case will indicate the charging status. A full charge is indicated when the display shows 100%.

A single charge provides approximately 15 hours of playtime for the earbuds, and the charging case provides an additional 4 charges, totaling up to 75 hours of playtime.

75 HOURS LONG PLAYTIME



15 Hrs
Single Charge




75 Hrs
With Charging Case



Type-C
Fast Charging

Image: Battery life indicators for the earbuds and charging case.



Hi-Fi Stereo Sound

The wireless headphones feature 14.2mm dynamic Drivers that provide clear, full, balanced sound.

Image: Visual representation of battery status and total playtime.

3.2 Powering On/Off

- **Power On:** Open the charging case, and the earbuds will automatically power on. Alternatively, press and hold the touch control area on each earbud for 2 seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid, and they will automatically power off. Alternatively, press and hold the touch control area on each earbud for 5 seconds.

3.3 Bluetooth Pairing

The earbuds utilize advanced Bluetooth 5.4 technology for a stable and fast connection.

1. Ensure the earbuds are charged and powered on.
2. Open the charging case. The earbuds will enter pairing mode, indicated by a flashing light on the earbuds.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "BX29" from the list of found devices to connect.
5. Once connected, the earbud lights will stop flashing, and you will hear a confirmation tone.

After the initial pairing, the earbuds will automatically connect to the last paired device when removed from the charging case, provided Bluetooth is enabled on your device.

One-Step Auto Pairing

New Bluetooth 5.3 Technology

- 1 Activate Bluetooth Setting, search & click "BX29" to connect
- 2 After the first connection, open the charging box for automatic pairing.





Image: One-step auto pairing guide for the earbuds.

What's in the box?

Choose the right ear muffs to be comfortable.

1. Charging Case
2. Packing Box
3. Earbuds
4. USB-C
5. User Manual
6. L M S



The pre-installed ear tips on the earbuds are size M

Image: Benefits of advanced Bluetooth 5.4 technology.

4. OPERATING INSTRUCTIONS

4.1 Touch Controls

The Ltinist BX29 earbuds feature smart touch controls for easy management of music and calls. The touch control area is located on the upper part of each earbud's surface.

Function	Action
Play/Pause Music	Single tap L/R earbud
Volume Up	Single tap Right earbud
Volume Down	Single tap Left earbud
Next Track	Hold Right earbud for 2 seconds
Previous Track	Hold Left earbud for 2 seconds
Answer/End Call	Single tap L/R earbud
Reject Call	Hold L/R earbud for 2 seconds
Activate Voice Assistant	Double tap L/R earbud

ENC Noise Reduction Give you a Crystal-clear Calls

With ENC Noise Cancellation and the enhanced microphones can effectively block out 85% of back ground noise and make your voice 3 times clearer

Noise

Voice



Image: Detailed guide to touch control gestures.

4.2 Sound Quality

The earbuds are equipped with 14.2mm vibrating diaphragm speaker drivers, delivering pure balanced audio with deep bass for an immersive music experience.



HI-FI STEREO SOUND

14.2 MM Speaker provides powerful stereo sound, give you an immersive experience.

14.2mm Drives Bass+

ENC NOISE CANCELING

Enjoy high-definition and noise-free call quality

40dB
Noise reduced to

Image: Internal structure highlighting the 14.2mm speaker driver for superior sound.

4.3 Call Functionality (ENC Noise Cancelling)

With ENC (Environmental Noise Cancellation) technology, these earbuds effectively reduce background noise, providing a stable and clearer calling environment for face-to-face communication quality.




Image: Explanation of ENC noise reduction for calls.

5. CARE AND MAINTENANCE

5.1 Cleaning

Regular cleaning helps maintain the performance and longevity of your earbuds.

- Wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them with mild soap and water if necessary, then dry thoroughly before reattaching.
- Gently clean the charging contacts on both the earbuds and the case with a dry cotton swab.

5.2 Storage

When not in use, store the earbuds in their charging case to protect them from dust and damage.

5.3 Water Resistance (IPX8)

The Ltinist BX29 earbuds are rated IPX8 waterproof, meaning they are protected against continuous immersion in water beyond 1 meter. This makes them suitable for workouts, running, and use in rainy conditions. However, they are not designed for swimming or showering.

- Ensure the earbuds are dry before placing them back into the charging case to prevent damage to the charging contacts.
- Do not expose the charging case to water, as it is not waterproof.

IPX8 WATERPROOF



Rain Day



Sweat Resistance



Splash proof



Image: IPX8 waterproof features of the earbuds.

MADE FOR MOVEMENT



Image: Ergonomic design with flexible earhooks and interchangeable ear tips.

6. TROUBLESHOOTING

If you encounter issues with your Ltinist BX29 earbuds, please refer to the following common solutions:

Problem	Possible Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget "BX29" from your device's Bluetooth list and re-pair.
No sound from one earbud	Place both earbuds back into the charging case, close the lid, then take them out again. Check device's audio output settings.

Problem	Possible Solution
Earbuds not charging	Ensure earbuds are correctly seated in the case. Check the USB-C cable and power adapter. Clean charging contacts.
Poor sound quality	Ensure earbuds are fully inserted and ear tips provide a good seal. Try different sized ear tips. Clean ear tips and earbud grilles.
Connection drops frequently	Ensure no obstacles between earbuds and device. Move closer to your device. Avoid strong electromagnetic interference.

7. SPECIFICATIONS

Feature	Detail
Model Name	BX29
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.4
Audio Driver Size	14.2 Millimeters
Playtime (Single Charge)	Up to 15 Hours
Total Playtime (with Case)	Up to 75 Hours
Charging Port	USB-C
Water Resistance Rating	IPX8
Noise Cancellation	ENC (Environmental Noise Cancellation) for calls
Ear Placement	In Ear (with Earhooks)
Compatible Devices	Telephones, Tablets, Computers
Item Weight	4.6 ounces

8. WARRANTY AND SUPPORT

Ltinist provides comprehensive customer support for its products.

- **Warranty:** This product comes with a 2-year warranty from the date of purchase, covering manufacturing defects.
- **Returns:** You may be eligible for a return or replacement within 30 days of purchase, subject to the retailer's policy.
- **Customer Service:** For any inquiries, technical assistance, or warranty claims, please contact Ltinist customer service. Refer to the contact information provided in your product packaging or visit the official Ltinist website.



Image: Customer support and warranty information.

© 2025 Ltinist. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question