

Pinmoco L501681C

Pinmoco Upgraded Cross-Legged Office Chair

MODEL: L501681C

Introduction	Setup	Operation	Maintenance	Troubleshooting	Specifications	Support
<div>1. Introduction</div> <p>This manual provides instructions for the assembly, operation, and maintenance of your Pinmoco Upgraded Cross-Legged Office Chair, Model L501681C. This ergonomic chair is designed to support various sitting postures, including cross-legged, to promote comfort and circulation during extended periods of use. It features adjustable components to suit individual preferences and is constructed with durable materials for long-lasting performance.</p>						



Figure 1: Pinmoco Upgraded Cross-Legged Office Chair in use.

2. Setup and Assembly

The Pinmoco Cross-Legged Office Chair is designed for straightforward assembly. Please ensure all components are present before beginning. Refer to the included assembly diagram for detailed steps. If any parts are missing or damaged, please contact customer support.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Verify against the parts list in your packaging.
2. **Attach Casters to Base:** Insert the five casters into the holes at the end of each leg of the chair base until they click securely into place.
3. **Install Gas Lift:** Place the gas lift cylinder into the center hole of the chair base.
4. **Assemble Seat and Backrest:** Attach the backrest to the seat mechanism using the provided screws. Ensure all screws are tightened securely.
5. **Attach Footrest:** Secure the footrest to its designated support structure, then attach this assembly to the main seat mechanism.

6. **Connect Seat to Gas Lift:** Carefully place the assembled seat onto the gas lift cylinder, ensuring it is centered and stable.

Product Size



UNIT: INCH

Figure 2: Product dimensions for assembly and space planning.

3. Operation and Adjustments

Your Pinmoco chair offers several adjustments to optimize your comfort and posture.

- **Height Adjustment:** Use the lever located under the seat on the right side to adjust the chair's height. Lift the lever while seated to lower, or lift the lever while standing to raise the chair.
- **Backrest Adjustment:** The backrest features a 2-level adjustable height mechanism. Loosen the knob or lever at the back of the chair, adjust the backrest to your desired height, and then tighten to secure. This allows for personalized lumbar support.
- **360-Degree Swivel:** Both the upper cushion and the footstool are designed to rotate 360 degrees, providing flexibility for various sitting positions and easy movement around your workspace.
- **Footstool Usage:** The extra-wide footstool is designed to support your legs, knees, and ankles when sitting cross-legged or in other alternative postures. Its height can be adjusted relative to the main seat from 0 to 4.7

inches, offering greater freedom to find a comfortable position.

**Designed to align with perfectly
your body's natural posture**



Figure 3: Backrest adjustment and 360-degree rotation features.



Figure 4: Example of a meditation posture supported by the chair.



Extra width, Extra thickness



Figure 5: Detail of the extra-wide and thick seat and footrest for enhanced comfort.

4. Maintenance and Care

Proper care will extend the life and appearance of your Pinmoco office chair.


- **Cleaning:** The chair is upholstered with PU leather, which is easy to clean and waterproof. For general cleaning, wipe the surface with a soft, damp cloth. For tougher spots, use a mild soap solution and wipe dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Caster Care:** Periodically check the casters for accumulated dust or hair and clean them to ensure smooth rolling.
- **Hardware Check:** Every few months, inspect all screws and bolts to ensure they are tight. Re-tighten if necessary to maintain stability and safety.



Luxury Faux PU Leather



Easy to Clean



Waterproof

Figure 6: The chair's PU leather is designed for easy cleaning and water resistance.

5. Troubleshooting

If you encounter any issues with your chair, please refer to the following common solutions:

- **Chair Squeaks:** Check all bolts and screws and tighten them. Applying a small amount of silicone lubricant to moving parts (e.g., gas lift, tilt mechanism) may also help.
- **Difficulty Adjusting Height:** Ensure the height adjustment lever is fully engaged or disengaged. If the gas lift is unresponsive, it may require replacement.
- **Casters Not Rolling Smoothly:** Remove any debris (hair, lint) from the caster wheels. If casters are damaged, they may need to be replaced.
- **Missing Parts or Bent Components:** If you discover missing parts or a bent bar during assembly or use, please contact Pinmoco Direct customer service for assistance.

6. Specifications

Feature	Detail
Brand	Pinmoco
Model Name	L501681C
Color	Black
Product Dimensions	15"D x 20"W x 38.6"H
Size	Curved Shape
Back Style	Cross Back
Unit Count	1.0 Count
Maximum Weight Recommendation	385 Pounds
Pattern	Solid
Age Range (Description)	Adult
Included Components	Basic Components of Chair
Shape	L-Shaped
Arm Style	Armless
Indoor/Outdoor Usage	Indoor
Seat Depth	15 inches
Fill Material	Memory Foam
Leg Style	Wheels
Item Weight	29.1 pounds
Date First Available	February 18, 2022

7. Warranty and Support

Pinmoco is committed to providing quality products and customer satisfaction. While specific warranty details are not provided in this manual, Pinmoco offers support services for its products.

If you encounter any issues such as missing parts, bent components, or require assistance with assembly or operation, please contact Pinmoco Direct customer service. They are available to provide parts replacement or upgrade services as needed.

For further assistance, please visit the [Pinmoco Store on Amazon](#) or refer to your purchase documentation for contact information.

8. Product Videos

No official product videos from the seller are available for embedding in this manual.



