

OnePlus OPK2413

OnePlus Pad 3 Smart Keyboard User Manual

Model: OPK2413

1. SETUP

1.1 Unboxing

Carefully remove the OnePlus Pad 3 Smart Keyboard from its packaging. The box contains the keyboard unit and a user guide with safety and warranty information.



Figure 1: OnePlus Pad 3 Smart Keyboard in its retail packaging.



Figure 2: The keyboard unit after removal from the box.

1.2 Attaching the Keyboard

Align your OnePlus Pad 3 tablet with the magnetic connector on the keyboard. The tablet will snap securely into place, establishing a physical and power connection via the Pogo pin connector.



Figure 3: OnePlus Pad 3 tablet attached to the Smart Keyboard, ready for use.

1.3 Initial Connection and Firmware Update

Upon first attachment, the keyboard will automatically connect to your OnePlus Pad 3. A firmware update may be prompted; ensure you complete this update for optimal performance. If the on-screen keyboard appears when the physical keyboard is attached, navigate to **Settings > Additional settings > Keyboard & input method > Physical keyboards > OnePlus Magnetic Keyboard** and disable the 'Use on-screen keyboard' option.

2. OPERATION

2.1 Keyboard Layout and Touchpad

The Smart Keyboard features a full six-row layout with tactile keys for a comfortable typing experience. It includes a large precision touchpad (8640mm²) that supports multi-gesture input for enhanced navigation.

2.2 Angle Adjustment

The keyboard allows for five levels of angle adjustment, ranging from 110° to 160°, providing flexibility for various viewing and typing preferences.



Figure 4: The keyboard offers multiple viewing angles for user comfort.

2.3 Special Features

- **Dedicated AI Key:** Access integrated AI features with a dedicated key.
- **NFC Support:** Utilize one-touch NFC for fast file transfers and seamless screen projection from your phone to the tablet.

3. MAINTENANCE

3.1 Cleaning

To clean the keyboard, gently wipe the surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials that could damage the finish or electronic components. Ensure no liquid enters the keys or touchpad.

3.2 Storage

When not in use, fold the keyboard to protect both the tablet screen and the keyboard keys. Store the device in a cool, dry place away from direct sunlight and extreme temperatures.

4. TROUBLESHOOTING

4.1 Keyboard Not Responding

- **Check Connection:** Ensure the tablet is securely attached to the magnetic connector on the keyboard.
- **Restart Tablet:** A simple restart of your OnePlus Pad 3 can resolve minor connectivity issues.
- **Firmware Update:** Verify that the keyboard's firmware is up to date via the tablet's settings.
- **On-Screen Keyboard:** Confirm that the 'Use on-screen keyboard' option is disabled in **Settings > Additional settings > Keyboard & input method > Physical keyboards**.

4.2 Touchpad Issues

- **Clean Touchpad:** Ensure the touchpad surface is clean and free of debris.
- **Software Glitch:** Restarting the tablet can often resolve unresponsive touchpad behavior.

5. SPECIFICATIONS

Feature	Detail
Brand	OnePlus
Model Number	OPK2413
Item Weight	1.47 pounds
Product Dimensions	11.4 x 8.2 x 0.3 inches
Color	Blue
Power Source	Battery Powered (charged via Pogo pin connector from tablet)
Compatible Devices	OnePlus Pad 3
Connectivity Technology	Bluetooth (for pairing, physical connection for power/data)
Keyboard Description	Mechanical
Material	Plastic
Included Components	USB-C to USB-C Cable (for tablet charging, not keyboard directly)

6. WARRANTY AND SUPPORT

For detailed warranty information and technical support, please refer to the user guide included in the product packaging or visit the official OnePlus support website. Keep your proof of purchase for warranty claims.