



Manuals.plus /

› YITAHOME /

› YITAHOME Outdoor Dog Kennel User Manual

YITAHOME MAYIHQqrZ

YITAHOME Outdoor Dog Kennel User Manual

Model: MAYIHQqrZ | Size: 7.5'x7.5'

INTRODUCTION

Thank you for choosing the YITAHOME Outdoor Dog Kennel. This heavy-duty galvanized steel enclosure provides a secure and spacious environment for your pets, featuring a protective roof and convenient rotating feeder bowls. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your kennel.



Figure 1: Overview of the YITAHOME Outdoor Dog Kennel (7.5'x7.5' model).

This image displays the complete YITAHOME Outdoor Dog Kennel, showcasing its spacious interior and sturdy construction. Two dogs are comfortably resting inside, highlighting the ample room available for pets.

SAFETY INFORMATION

- Always ensure all connections are securely fastened before allowing pets into the kennel.
- Regularly inspect the kennel for any loose parts, sharp edges, or damaged mesh that could pose a hazard to your pet.
- Do not allow children to play unsupervised near or inside the kennel.
- Position the kennel on a flat, stable surface to prevent tipping.
- Ensure proper ventilation, especially during hot weather, to prevent overheating.
- The roof cover provides protection from sun and rain; however, it is not designed to withstand extreme weather conditions like heavy snow accumulation or strong winds. Remove the cover during such conditions to prevent damage.

SETUP

Assembly of the YITAHOME Outdoor Dog Kennel requires at least two people. Follow the steps below carefully. For a visual guide, refer to the official installation video provided.

Your browser does not support the video tag.

Video 1: YITAHOME Outdoor Dog Kennel Installation Guide.

This official installation video from YITAHOME provides a step-by-step visual guide for assembling the dog kennel. It covers all major components and connection points, demonstrating the process from unboxing to final setup.

Assembly Steps:

1. **Unpack and Organize Components:** Lay out all parts on a clean, flat surface. Refer to the parts list in your physical manual to ensure all components are present.
2. **Assemble the Base Frame:** Connect the horizontal base pipes using the provided connectors and bolts. Ensure all connections are tight and secure. *(Refer to Video 1, 0:10)*
3. **Install Vertical Posts:** Insert the vertical support posts into the designated slots on the base frame. These posts will form the vertical structure of the kennel. *(Refer to Video 1, 0:23)*
4. **Construct the Top Frame:** Assemble the horizontal top pipes and corner connectors to form the upper perimeter of the kennel. Secure these to the vertical posts. *(Refer to Video 1, 0:37)*
5. **Attach Roof Support Bars:** Install the roof support bars across the top frame to create the pitched roof structure. These bars provide stability for the roof cover. *(Refer to Video 1, 0:55)*
6. **Assemble the Roof Frame:** Connect the remaining roof frame components to complete the roof structure. *(Refer to Video 1, 1:15)*
7. **Assemble the Door Frame:** Connect the door frame components. This includes the main door and the smaller rotating feeder door. *(Refer to Video 1, 1:55)*
8. **Attach Chain Link to Door:** Securely attach the chain link mesh to the assembled door frame using the provided wire ties or clips. *(Refer to Video 1, 2:18)*
9. **Install Feeder Bowls:** Attach the rotating feeder bowls to the designated section of the door frame. Ensure they can rotate smoothly for easy feeding. *(Refer to Video 1, 3:24)*




Figure 2: Detail of the rotating feeder bowls for convenient access.

This image provides a close-up view of the rotating feeder bowls integrated into the kennel door. The design allows for easy refilling of food and water without needing to enter the enclosure.

10. **Install the Door:** Mount the assembled door onto the main kennel frame using the provided hinges and bolts. Ensure the door swings freely and the latch mechanism functions correctly. *(Refer to Video 1, 3:45)*
11. **Unroll and Attach Chain Link Mesh:** Carefully unroll the chain link mesh around the perimeter of the kennel. Secure it to the frame using the provided wire ties or zip ties. Start from one corner and work your way around, ensuring the mesh is taut. *(Refer to Video 1, 4:50)*
12. **Disassemble Excess Wire Mesh (if needed):** If the mesh is too long, you may need to untangle and remove excess wire. This involves untwisting the winding parts of the metal wire and rotating counter-clockwise until loose. *(Refer to Video 1, 5:17)*
13. **Wind Bottom Wire:** Secure the bottom edge of the chain link mesh to the base frame by winding the provided wire. Lifting one side of the cage slightly can make this step easier and create more space for operation. *(Refer to Video 1, 6:34)*
14. **Install the Roof Cover:** Drape the waterproof and UV-resistant roof cover over the assembled roof frame. Secure it using the elastic cords or bungee ties through the grommets on the cover and around the frame. Ensure the cover is taut and properly aligned to shed water. *(Refer to Video 1, 7:22)*



Figure 3: Slanted roof design for effective water and snow runoff.

This image highlights the slanted roof design, which effectively prevents the buildup of rainwater and snow, providing continuous protection for your pets.

OPERATING INSTRUCTIONS

Using the Rotating Feeder Bowls:

- To feed or water your pet, simply rotate the feeder bowls outwards from the kennel.
- Fill the stainless steel bowls with appropriate food and water.
- Rotate the bowls back into the kennel. This allows you to provide sustenance without entering the enclosure, minimizing disruption to your pet.

Door Latch Mechanism:

- The kennel features an upgraded door latch for enhanced security.
- To open, slide the latch mechanism upwards and pull the door open.
- To close, push the door shut and slide the latch downwards to secure it. Always ensure the latch is fully engaged to prevent accidental opening.



UPGRADED DOOR LOCK

Extra security, prevents accidental opening

GALVANIZED STEEL PIPE

Resistant to wear for extended lifespan

Figure 4: Enhanced security features of the door lock and durable galvanized steel.

This image details the upgraded door lock, designed for extra security to prevent accidental openings. It also showcases the galvanized steel pipe construction, which is resistant to wear for extended lifespan.

MAINTENANCE

- **Cleaning:** Regularly clean the kennel and feeder bowls with pet-safe cleaning solutions. Rinse thoroughly and allow to dry completely before reuse.
- **Inspection:** Periodically check all bolts, nuts, and connections to ensure they remain tight. Tighten any loose fasteners. Inspect the chain link mesh for any signs of damage, rust, or sharp points.
- **Roof Cover Care:** Clean the roof cover as needed. If the cover shows signs of wear, tears, or significant UV degradation, consider replacing it to maintain optimal protection.
- **Winterization:** In areas with heavy snowfall, remove accumulated snow from the roof cover to prevent structural damage. Consider disassembling and storing the kennel indoors during prolonged periods of harsh winter weather.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Kennel feels unstable or wobbly.	Loose connections or uneven ground.	Check and tighten all bolts and nuts. Relocate the kennel to a flat, level surface.
Door does not close or latch properly.	Misaligned hinges or bent door frame.	Adjust hinges. Inspect the door frame for any bending and gently realign if possible. Ensure no debris is obstructing the latch.
Chain link mesh is sagging or loose.	Insufficiently tightened wire ties or damaged mesh.	Re-tighten or add more wire ties along the frame. If mesh is damaged, consider replacing the section or reinforcing with additional wire.
Roof cover collects water or sags.	Improper installation or insufficient tension.	Ensure the roof frame is correctly assembled with the proper pitch. Re-secure the cover, pulling it taut with all elastic cords. Clear any debris from the roof.

SPECIFICATIONS

Feature	Detail
Brand	YITAHOME
Model Name	Outdoor Dog Kennel
Model Number	MAYIHQaqrZ
Product Dimensions (L x W x H)	90.5" x 90.5" x 78.7" (approx. 7.5' x 7.5' x 6.5')
Item Weight	88.51 Pounds
Material	Heavy-duty galvanized steel (frame and mesh), Durable waterproof and UV-resistant fabric (roof cover)
Included Components	Top cloth + galvanized round tube + iron mesh
Special Feature	Rotating Feeder Bowls, Upgraded Door Lock, Slanted Roof
Target Audience	Dogs (All Breed Sizes), Chickens, Rabbits, Ducks

WARRANTY AND SUPPORT

For any questions regarding product warranty, missing parts, or technical support, please contact YITAHOME customer service directly. Refer to the contact information provided with your purchase documentation or visit the official YITAHOME website for assistance.