

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [FIREBAT](#) /

› [FIREBAT X3 Wired RGB Gaming Mouse Instruction Manual](#)

FIREBAT X3 Gaming Mouse

FIREBAT X3 Wired RGB Gaming Mouse User Manual

Model: X3 Gaming Mouse | Brand: FIREBAT

[Introduction](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

The FIREBAT X3 Wired RGB Gaming Mouse is designed for precision and comfort, suitable for various computing tasks including gaming, office work, and general use. This manual provides detailed instructions for setting up, operating, and maintaining your mouse.

FIREBAT Wired PC Gaming Mouse



6-Button Control



USB-A Connectivity



Plug and Play



RGB Lighting



Ergonomic Design



Up to 3600



Overview of the FIREBAT X3 Wired RGB Gaming Mouse highlighting its main features.

2. SETUP

2.1 Connecting the Mouse

The FIREBAT X3 Gaming Mouse features a simple plug-and-play design for easy setup.

1. Locate an available USB-A port on your computer or laptop.
2. Insert the USB connector of the mouse into the USB-A port.
3. Your operating system will automatically detect and install the necessary drivers. No additional software installation is required for basic functionality.



The FIREBAT X3 mouse connects via a standard USB-A port for immediate use.

3. OPERATION

3.1 Button Functions

The FIREBAT X3 Gaming Mouse is equipped with 6 programmable buttons for enhanced control.

- **Left Button:** Standard click function.
- **Right Button:** Standard right-click function.
- **Scroll Wheel:** Scrolls up and down. Can also be pressed for a middle-click function.
- **DPI Adjustment Key:** Changes the mouse sensitivity (DPI).
- **Forward Button:** Navigates forward in web browsers or file explorers.
- **Back Button:** Navigates backward in web browsers or file explorers.

USB-A Wired Connectivity Plug and Play



6-Button Control



Illustration of the 6-button layout on the FIREBAT X3 Gaming Mouse.

3.2 Adjusting DPI (Sensitivity)

The mouse features 4 adjustable DPI levels to suit different tasks and preferences.

- Press the **DPI Adjustment Key** (located behind the scroll wheel) to cycle through the preset DPI settings.
- The default DPI levels are 1200, 1800, 2400, and 3600.
- Each press will switch to the next DPI level, allowing you to find the optimal sensitivity for your current activity.

Precise Optical Sensor

Extremely high sensitivity and stability

Four Levels Adjustable, Easily cope with various complex environments



DPI & CPI Up to

3600

1200-1800-2400-3600



The DPI adjustment key allows for quick changes in mouse sensitivity.

3.3 RGB Lighting Modes

The FIREBAT X3 mouse features 7 dynamic RGB backlit modes to enhance your setup.

- The RGB lighting automatically cycles through its 7 distinct modes.
- There is no manual button to change the RGB mode; the mouse will continuously display various lighting effects.

RGB Lighting

Taking into account both appearance and performance



The mouse features vibrant RGB lighting with multiple dynamic modes.

3.4 Ergonomic Design and Comfort

The mouse is designed with an ergonomic shape to provide a comfortable grip and reduce hand fatigue during extended use, suitable for both right and left-hand users.

Comfortable Ergonomic Design

No hand fatigue even after long-term use



The ergonomic design ensures comfort during prolonged use.

3.5 Quiet Click Feature

The mouse incorporates a 'Heavy Bass Design' for its key sounds, ensuring soft clicks without excessive noise, which is beneficial in quiet environments.

Key Bass Design

No need to worry about noise



The mouse features quiet clicks, minimizing noise during use.

4. MAINTENANCE

4.1 Cleaning

To ensure optimal performance and longevity, keep your mouse clean.

- Disconnect the mouse from your computer before cleaning.
- Use a soft, lint-free cloth lightly dampened with water or a mild cleaning solution to wipe the surface of the mouse.
- Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the mouse.
- For the optical sensor, use a cotton swab to gently remove any dust or debris.

4.2 Storage

When not in use, store the mouse in a clean, dry environment away from extreme temperatures and direct sunlight.

5. TROUBLESHOOTING

5.1 Mouse Not Responding

- **Check USB Connection:** Ensure the USB cable is securely plugged into a working USB port on your computer. Try a different USB port.
- **Restart Computer:** Sometimes a simple restart can resolve connectivity issues.
- **Test on Another Computer:** If possible, test the mouse on another computer to determine if the issue is with the mouse or your computer's setup.

5.2 Cursor Movement is Erratic or Jumpy

- **Clean Optical Sensor:** Dust or debris on the optical sensor can cause erratic movement. Refer to the cleaning instructions in the Maintenance section.
- **Use a Mouse Pad:** Ensure you are using the mouse on a suitable surface. Reflective, transparent, or uneven surfaces can interfere with the optical sensor.

5.3 RGB Lighting Not Working

- **Check USB Power:** Ensure the mouse is receiving sufficient power through the USB connection.
- **No Manual Control:** Remember that the RGB lighting cycles automatically and does not have a manual control button. If the mouse is functioning otherwise, the lighting should be active.

6. SPECIFICATIONS

| Feature | Detail |
|-------------------------|-----------------|
| Model Number | X3 Gaming Mouse |
| Brand | FIREBAT |
| Connectivity Technology | USB Wired |
| Movement Detection | Optical |

| Feature | Detail |
|--------------------|---|
| DPI Levels | 1200 / 1800 / 2400 / 3600 |
| Number of Buttons | 6 (Programmable) |
| Backlight | 7 RGB Modes |
| Product Dimensions | 5 x 3 x 0.1 inches (12.7 x 7.6 x 0.25 cm) |
| Item Weight | 5.1 ounces (144.6 grams) |
| Ergonomics | Right or Left Hand Use |
| Manufacturer | FIREBAT |

Lightweight And Compact Appearance Frosted Bottom Design

Not too light or too heavy to cause fatigue Smooth use without lag



Physical dimensions and weight of the FIREBAT X3 Gaming Mouse.

7. WARRANTY AND SUPPORT

7.1 Warranty Information

FIREBAT products are manufactured to high-quality standards. For specific warranty details, please refer to

the warranty card included with your product or visit the official FIREBAT website. Typically, products come with a limited warranty covering manufacturing defects.

7.2 Customer Support

If you encounter any issues or have questions regarding your FIREBAT X3 Gaming Mouse, please contact our customer support team:

- **Email:** support@firebatpc.com
- **Website:** www.firebatpc.com

Please provide your product model number (X3 Gaming Mouse) and a detailed description of your issue when contacting support for faster assistance.