Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl 23V 500mA AC-DC Adapter

onerbl AC-DC Adapter Instruction Manual

Model: 23V 500mA AC-DC Adapter (Compatible with Bossdan PB101 P8101 Cordless Stick Vacuum Cleaner)

Introduction

This manual provides essential instructions for the safe and efficient use of your onerbl AC-DC Adapter. This adapter is specifically designed to power and charge the Bossdan Model PB101 and P8101 4-in-1 Lightweight Cordless Stick Vacuum Cleaners. Please read this manual thoroughly before using the product to ensure proper function and longevity.

Safety Instructions

To prevent injury or damage, always follow these basic safety precautions:

- Read all instructions before using the adapter.
- This adapter is for **indoor use only**. Do not expose to rain or moisture.
- Keep the adapter away from water, heat sources, and direct sunlight.
- Do not disassemble, modify, or attempt to repair the adapter. Refer servicing to qualified personnel.
- Ensure the adapter's voltage and current specifications match the requirements of your device.
- Unplug the adapter from the wall outlet during lightning storms or when unused for extended periods.
- Avoid placing heavy objects on the power cord or subjecting it to excessive bending.
- The adapter features **Short Circuit Protection** for enhanced safety.

Package Contents

- 1 x onerbl AC-DC Adapter

Product Overview

Familiarize yourself with the components of your onerbl AC-DC Adapter.



Image: The onerbl AC-DC adapter unit with its integrated power cord, featuring a standard US plug and a barrel connector.



Image: A view of the adapter with its dimensions labeled: 3.1 inches in length, 2.1 inches in width, and 1.2 inches in thickness. The barrel connector is also visible.



Image: The label on the adapter showing model information, input (100-240V AC, 50/60Hz), and safety certifications. The cable length is indicated as 76 inches.



Image: The onerbl AC-DC adapter plugged into a wall outlet, demonstrating its compact design in a typical usage scenario.

Setup

Follow these steps to set up your onerbl AC-DC Adapter:

1. Locate the charging port on your Bossdan PB101 or P8101 Cordless Stick Vacuum Cleaner.
2. Connect the barrel connector of the onerbl AC-DC Adapter firmly into the vacuum cleaner's charging port.
3. Plug the AC prongs of the adapter into a standard AC 100-240V wall outlet. Ensure the connection is secure.

Operating Instructions

Once properly connected, the adapter will begin its function:

- The adapter will automatically supply power to your Bossdan vacuum cleaner for operation or initiate battery charging.
- Refer to your vacuum cleaner's instruction manual for information on its charging indicator lights and battery status.

- **Important Note on Voltage:** The vacuum cleaner's battery voltage is 18.5V. The adapter's output voltage is 23V. This voltage difference is normal and necessary for efficiently charging Li-ion batteries.
- **Battery Lifespan:** Rechargeable batteries have a finite lifespan, typically 1 to 3 years. If your vacuum cleaner is not charging, it may indicate an old or faulty battery rather than an issue with the adapter.

Maintenance

Proper care will extend the life of your adapter:

- Keep the adapter and its cable clean and dry. Use a soft, dry cloth for cleaning.
- Avoid excessive bending, twisting, or crimping of the power cable, especially near the connectors.
- Store the adapter in a cool, dry place when not in use.

Troubleshooting

If you encounter issues, refer to the following common problems and solutions:

- **No Power or Charging:**
  - Ensure the adapter is securely plugged into both the wall outlet and the vacuum cleaner's charging port.
  - Verify that the wall outlet is functional by testing it with another device.
  - Check the vacuum cleaner's battery. If it is completely depleted or faulty, it may not accept a charge. Refer to your vacuum cleaner's manual for battery-specific troubleshooting.
- **Adapter Overheating:**
  - Immediately unplug the adapter from the wall outlet and the device.
  - Ensure the adapter is in a well-ventilated area and not covered.
  - If overheating persists after cooling down, discontinue use and contact support.
- **Incorrect Voltage Warning / Device Incompatibility:**
  - This adapter is specifically designed for Bossdan Model PB101 and P8101 vacuum cleaners. Using it with incompatible devices may cause damage.

Specifications

Input Voltage	AC 100-240V, 50/60Hz
Output Voltage/Current	DC 23V, 500mA (0.5A)
Power Output	11.5W
Connector Type	Barrel Connector
Special Feature	Short Circuit Protection
Color	Black
Cable Length	76 inches
Adapter Dimensions (approx.)	3.1 inches (L) x 2.1 inches (W) x 1.2 inches (T)
Manufacturer	Shenzhen Waweis Technology Co., Ltd

Warranty and Support

For warranty information, technical assistance, or any product-related inquiries, please contact your retailer or the manufacturer, Shenzhen Waweis Technology Co., Ltd. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FC5S6FY4

More documents and user manuals: **https://manuals.plus/**